



## SPM-D11 Synchronizing Unit



**Manual**  
from Software version 6.3xx

**WARNING**

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment. Practice all plant and safety instructions and precautions. Failure to follow instructions can cause personal injury and/or property damage.

The engine, turbine, or other type of prime mover should be equipped with an overspeed (overtemperature, or overpressure, where applicable) shutdown device(s), that operates totally independently of the prime mover control device(s) to protect against runaway or damage to the engine, turbine, or other type of prime mover with possible personal injury or loss of life should the mechanical-hydraulic governor(s) or electric control(s), the actuator(s), fuel control(s), the driving mechanism(s), the linkage(s), or the controlled device(s) fail.

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.

**CAUTION**

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts.

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

**OUT-OF-DATE PUBLICATION**

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, be sure to check the Woodward website:

<http://www.woodward.com/pubs/current.pdf>

The revision level is shown at the bottom of the front cover after the publication number. The latest version of most publications is available at:

<http://www.woodward.com/publications>

If your publication is not there, please contact your customer service representative to get the latest copy.

**Important definitions****WARNING**

Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.

**CAUTION**

Indicates a potentially hazardous situation that, if not avoided, could result in damage to equipment.

**NOTE**

Provides other helpful information that does not fall under the warning or caution categories.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, Woodward assumes no responsibility unless otherwise expressly undertaken.

© Woodward  
All Rights Reserved.

# Revision History

Rev.	Date	Editor	Change
B	04-08-04	TP	LSR/LSXR update
C	04-10-19	TP	1/3-phase measurement functionality updated; linguistic update
D	06-03-28	TP	Minor corrections; Load/var sharing updated; Package harmonization
E	11-06-29	TE	Minor corrections

# Contents

<b>CHAPTER 1. GENERAL INFORMATION .....</b>	<b>6</b>
<b>CHAPTER 2. ELECTROSTATIC DISCHARGE AWARENESS .....</b>	<b>7</b>
<b>CHAPTER 3. INSTALLATION .....</b>	<b>8</b>
Wiring Diagram .....	9
SPM-D11/LSR.....	9
SPM-D11/LSXR.....	10
Reference Point.....	11
Power Supply .....	11
Measuring Inputs.....	12
Voltage .....	12
Current .....	13
Discrete Inputs .....	14
Analog Inputs .....	15
Relay Outputs.....	16
Controller Outputs .....	17
SPM-D11/LSR.....	17
SPM-D11/LSXR.....	18
<b>CHAPTER 4. DESCRIPTION OF FUNCTIONS .....</b>	<b>20</b>
Functional Description.....	20
Table for Terminal 6 = "Enable Control" .....	20
Table for Terminal 6 = "Enable Power Set point Value 2" .....	21
Additional Conditions .....	22
Control Inputs .....	23
Isolation of the Power Supply from the Discrete Inputs.....	24
Operating Conditions.....	25
No Load Control .....	25
Synchronization.....	25
Synch-Check.....	26
Isolated Operation.....	26
Closing the CB Without Synchronization (Dead Bus Start) .....	26
Shutdown .....	27
Mains Parallel Operation.....	27
Load Sharing.....	27
var Sharing.....	28
LED "Gen CB - ON" Flashes.....	28
Control Outputs .....	29
Analog Controller Outputs .....	30

<b>CHAPTER 5. DISPLAY AND OPERATING ELEMENTS .....</b>	<b>33</b>
Brief Explanation of the LEDs and Push Buttons .....	34
LEDs .....	34
Buttons .....	34
Others .....	34
LEDs .....	35
Push Buttons .....	37
LC Display .....	38
Display Monitoring in Automatic Mode: Double Voltage / Frequency Display .....	38
Display Monitoring in Automatic Mode: Alarm Indication .....	38
<b>CHAPTER 6. CONFIGURATION .....</b>	<b>39</b>
Configure Basic Data .....	39
Password Protection .....	40
Direct Configuration .....	41
Configure Basic Settings .....	42
Potential Transformer .....	42
Current Transformer .....	43
Configure Controller .....	44
Idle Control .....	44
Frequency Controller .....	44
Voltage Controller .....	48
Power Factor Control .....	51
Real Power Controller .....	53
Load/Var Sharing .....	57
Synchronization .....	58
Configure Synchronization .....	58
Synchronization Time Monitoring .....	60
Dead Bus Start .....	61
Configure Monitoring .....	62
Generator Reverse/Reduced Power Monitoring .....	62
Generator Overload Monitoring .....	63
Generator Frequency Monitoring .....	64
Generator Voltage Monitoring .....	65
Auto Acknowledge Messages .....	65
Password Configuration .....	66
<b>CHAPTER 7. COMMISSIONING .....</b>	<b>67</b>
<b>APPENDIX A. DIMENSIONS .....</b>	<b>69</b>
<b>APPENDIX B. TECHNICAL DATA .....</b>	<b>70</b>
<b>APPENDIX C. LIST OF PARAMETERS .....</b>	<b>72</b>
<b>APPENDIX D. POWER FACTOR DEFINITION .....</b>	<b>75</b>
<b>APPENDIX E. SERVICE OPTIONS .....</b>	<b>77</b>
Product Service Options .....	77
Returning Equipment for Repair .....	77
Packing a Control .....	78
Return Authorization Number RAN .....	78
Replacement Parts .....	78
How to contact Woodward .....	79
Engineering Services .....	80
Technical Assistance .....	81

# Illustrations and Tables

## Illustrations

Figure 3-1: Wiring diagram SPM-D11/LSR .....	9
Figure 3-2: Wiring diagram SPM-D11/LSXR .....	10
Figure 3-3: Reference point .....	11
Figure 3-4: Power supply .....	11
Figure 3-5: Measuring inputs - Generator .....	12
Figure 3-6: Measuring inputs - Synchronization voltage .....	13
Figure 3-7: Measuring inputs - Current .....	13
Figure 3-8: Digital inputs .....	14
Figure 3-9: Analog inputs .....	15
Figure 3-10: Load sharing .....	15
Figure 3-11: Relay outputs - control outputs I (CB control) .....	16
Figure 3-12: Relay outputs - control outputs II (acknowledgements) .....	16
Figure 3-13: Controller - SPM-D11/LSR - three-position controller .....	17
Figure 3-14: Controller - SPM-D11/LSXR - three-position controller .....	18
Figure 3-15: Controller - SPM-D11/LSXR - Analog controller output - Speed/frequency/real power .....	19
Figure 3-16: Controller - SPM-D11/LSXR - Analog controller output - Voltage/power factor .....	19
Figure 4-1: Control loop .....	30
Figure 4-2: Step response (example) .....	30
Figure 4-3: Step response - controller set-up .....	32
Figure 5-1: Front foil .....	33
Figure 7-1: Dimensions .....	69

## Tables

Table 3-1: Conversion chart - wire size .....	8
Table 4-1: Operating conditions - Terminal 6 = "Enable control" .....	20
Table 4-2: Operating conditions - Terminal 6 = "OFF" .....	21
Table 4-3: Operating conditions - status of measuring inputs and configuration .....	22
Table 4-4: Power set point modes .....	27

# Chapter 1.

## General Information

The SPM-D11 is a synchronizing unit with integrated control functions for generator power levels and load sharing. Through the application of appropriate logic to the discrete inputs the following functions can be realized:

- Synchronization
- Synch-check
- Black start
- Load/var control
- Load/var sharing

The SPM-D starts as a standard unit that may have additional functions added with each package. The model of the SPM-D is designated as follows:

SPM-D11	4	5	B/	xx
<p><b>Packages</b> according to the Package list. These packages can be found in the manual. Each headline points out if the described function is standard or part of a package.</p>				
<p>Mounting [B].. Flush-mounting</p>				
<p>CT's, current transformers, secondary [1] = ../1 A [5] = ../5 A</p>				
<p>Voltage transformers/PT's, secondary [1] = 100 Vac [4] = 400 Vac</p>				
<p>Type</p>				

Examples:

- SPM-D1145B/LSR (LSR package with 400 Vac PT measuring inputs and ../5 A CT measuring inputs)
- SPM-D1111B/LSXR (LSXR package with 100 Vac PT measuring inputs and ../1 A CT measuring inputs)

**Intended Use** The control must only be operated for the uses described in this manual. The prerequisite for a proper and safe operation of the product is correct transportation, storage and installation, as well as careful operation and maintenance.



### NOTE

This manual has been developed for a control fitted with all available options. Inputs/outputs, functions, configuration screens and other details described, which do not exist on your control, may be ignored.

The present manual has been prepared to enable the installation and commissioning of the control. Due to the large variety of parameter settings, it is not possible to cover every combination. The manual is therefore only a guide. In case of incorrect entries or a total loss of functions, the default settings can be taken from the list of parameters located in the rear of this manual.

## Chapter 2.

# Electrostatic Discharge Awareness

---

All electronic equipment is static-sensitive, some components more than others. To protect these components from static damage, you must take special precautions to minimize or eliminate electrostatic discharges.

Follow these precautions when working with or near the control.

1. Before performing maintenance on the electronic control, discharge the static electricity on your body to ground by touching and holding a grounded metal object (pipes, cabinets, equipment, etc.).
2. Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as much as synthetics.
3. Keep plastic, vinyl, and Styrofoam materials (such as plastic or Styrofoam cups, cup holders, cigarette packages, cellophane wrappers, vinyl books or folders, plastic bottles, and plastic ash trays) away from the control, the modules, and the work area as much as possible.
4. **Opening the control cover may void the unit warranty.**  
Do not remove the Printed Circuit Board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
  - Ensure that the device is completely de-energized (all connectors must be disconnected).
  - Do not touch any part of the PCB except the edges.
  - Do not touch the electrical conductors, connectors, or components with conductive devices with your hands.
  - When replacing a PCB, keep the new PCB in the protective antistatic bag it comes in until you are ready to install it. Immediately after removing the old PCB from the control cabinet, place it in the protective antistatic bag.



### CAUTION

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

## Chapter 3. Installation



### WARNING

A circuit breaker must be located near to the control and in a position easily accessible to the operator. This must also bear a sign identifying it as an isolating switch for the control.



### NOTE

Inductive devices connected to the system (such as operating current coils, undervoltage tripping units, or auxiliary/power contacts) must be connected to a suitable interference suppressor.



### WARNING

All technical data and ratings indicated in this chapter are not definite! Only the values indicated in Appendix B: Technical Data on page 70 are valid!

The following chart may be used to convert square millimeters [mm<sup>2</sup>] to AWG and vice versa:

AWG	mm <sup>2</sup>	AWG	mm <sup>2</sup>	AWG	mm <sup>2</sup>	AWG	mm <sup>2</sup>	AWG	mm <sup>2</sup>	AWG	mm <sup>2</sup>
30	0.05	21	0.38	14	2.5	4	25	3/0	95	600MCM	300
28	0.08	20	0.5	12	4	2	35	4/0	120	750MCM	400
26	0.14	18	0.75	10	6	1	50	300MCM	150	1000MCM	500
24	0.25	17	1.0	8	10	1/0	55	350MCM	185		
22	0.34	16	1.5	6	16	2/0	70	500MCM	240		

Table 3-1: Conversion chart - wire size



Wiring Diagram



SPM-D11/LSR




Figure 3-1: Wiring diagram SPM-D11/LSR

## SPM-D11/LSXR




Figure 3-2: Wiring diagram SPM-D11/LSXR

Reference Point




Figure 3-3: Reference point

Terminal	Description	A <sub>max</sub>
0	Reference point: Neutral point of the three-phase system or neutral terminal of the voltage transformer (Measuring reference point); → with three-conductor (delta) systems, do not connect	Sold.lug

Power Supply



**WARNING**

There are two different versions of this unit with different voltage input ratings. Look at the DATA PLATE of the unit to determine the correct voltage input ratings. An incorrect power supply may destroy the unit. The voltage input ratings are:

- $V_{aux} = 24\text{ Vdc}$
- $V_{aux} = 12/24\text{ Vdc}$




Figure 3-4: Power supply

Terminal	Description	A <sub>max</sub>
1	+24 Vdc <i>or</i> +12/24Vdc	2.5 mm <sup>2</sup>
2	0 Vdc	2.5 mm <sup>2</sup>

## Measuring Inputs



**NOTE**  
The unit always assumes a clockwise three-phase system (right-handed rotary field). If the unit is used with a counter-clockwise field (left-handed rotary field), the power factor measurement will not be correct. This may be compensated by adapting the angle adjustment (refer to Current Transformer section on page 43).

### Voltage

**NOTE**  
The SPM-D11 can only operate (monitor) one synchronization point (one power circuit breaker), due to the 1-power-circuit-breaker configuration. The measured voltage at terminals 23/24 is the voltage reference point for the synchronization at terminals 20/21. The synchronization reference voltage can be the mains or busbar voltage.

**NOTE**  
There are generally three variations for connection of the measuring circuit voltage:

- ① Direct connection to a low voltage system
- ② Connection to medium voltage via two-phase isolated transformer (e. g. in the case of a delta connection)
- ③ Connection to medium voltage via single- phase isolated transformer (e. g. Y-connection).

The SPM-D11 may be connected to L1/L2 or L1/N. Regardless of what connection is used, the generator and mains/busbar must always be connected identically. Correct measured values can be achieved for three-phase and single-phase systems if the SPM-D11 is configured accordingly (refer to Current Transformer section on page 43).

### Generator




Figure 3-5: Measuring inputs - Generator

**Note:** Connection corresponding to the mains configuration (see wiring diagram)

Terminal	Measurement	Description	A <sub>max</sub>
Connection of the measuring circuit voltage corresponding to the variant ①, ② or ③			
20	direct or Transformer .../100 V	Generator voltage L1	2.5 mm <sup>2</sup>
21		Generator voltage L2	2.5 mm <sup>2</sup>
0		Reference point: N-terminal of the low voltage system or star point of the voltage transducer (measuring reference point); → do not connect in delta connection installations	Solder lug

## Mains/Busbar




Figure 3-6: Measuring inputs - Synchronization voltage

**Note:** Connection corresponding to the Bus configuration (see wiring diagram).

Terminal	Measurement	Description	$A_{max}$
Connection of the measuring circuit voltage corresponding to variant ①, ② or ③			
23	direct	Synchronization ref. voltage L1	2.5 mm <sup>2</sup>
24	or $\dots/100$ V	Synchronization ref. voltage L2	2.5 mm <sup>2</sup>

## Current

**WARNING**

Before disconnecting the secondary terminals of the current transformer or the connections of the current transformer at the unit, ensure that the transformer is short-circuited.

**NOTE**

Current transducers are generally to be grounded on one side of the secondary.




Figure 3-7: Measuring inputs - Current

Terminal	Measurement	Description	$A_{max}$
25	Transformer $\dots/1$ A o. $\dots/5$ A	Generator current L1, transformer terminal s2 (l)	2.5 mm <sup>2</sup>
26		Generator current L1, transformer terminal s1 (k)	2.5 mm <sup>2</sup>

**NOTE**

If the generator load is always symmetrically, the current may also be measured in L2 or L3. This must be considered when configuring the SPM-D11 (refer to Current Transformer section on page 43). If there is a possibility that the load may be asymmetrical, the current must be measured in L1.

## Discrete Inputs



### WARNING

There are two versions of this unit with different discrete inputs. The discrete inputs have different maximum voltage ratings. Look at the DATA PLATE of the unit to determine the correct voltage input ratings. Applying incorrect voltages to the discrete inputs may destroy the hardware. The voltage input ratings are:

- $V_{\text{Cont, dig. input}} = \pm 1.18 \text{ to } 250 \text{ Vac/dc}$
- $V_{\text{Cont, dig. input}} = 12/24 \text{ Vdc}$




Figure 3-8: Digital inputs

Terminal	Associated zero-terminal	Description (to DIN 40 719 part 3, 5.8.3)	A <sub>max</sub>
NO (make) contact			
<i>A</i>	<i>B</i>		
3	7	Enable CB	2.5 mm <sup>2</sup>
5		Enable isolated operation / dead bus start	2.5 mm <sup>2</sup>
6		Enable control or release power set point value 2 *	2.5 mm <sup>2</sup>
NC (break) contact			
<i>C</i>	<i>D</i>		
4	7	Reply: CB is open	2.5 mm <sup>2</sup>

\* refer to parameter Parameter 14 "Terminal 6" on page 44

## Analog Inputs



**WARNING**

The analog inputs of the SPM-D are not isolated. When using an isolation monitor, we recommend to use two-pole, isolated transmitters.

The analog inputs for active transmitters (0 to 20 mA, 0 to 10V) should only be operated with two-pole, isolated transmitters.




Figure 3-9: Analog inputs

Terminal	Associated zero-terminal	Description (to. DIN 40 719 part 3, 5.8.3)	A <sub>max</sub>
0 to 4 Vdc			
A			
29	0	Real power load sharing	2.5 mm <sup>2</sup>
30		Reactive power load sharing	2.5 mm <sup>2</sup>
0/4 to 20 mA			
B			
28	27	Real power set point value	2.5 mm <sup>2</sup>

All controls that are load sharing must be interconnected via terminal 29 (terminals 30 must also be interconnected for var sharing). If an SPM-D11 is switched off, the load/var sharing line must be disconnected to prevent the disabled SPM-D11 from influencing the other controls.




Figure 3-10: Load sharing

## Relay Outputs




Figure 3-11: Relay outputs - control outputs I (CB control)

Root	Switched	Description	A <sub>max</sub>
<i>A</i>	<i>B</i>		
14	15	Synchronizing pulse, Command: close CB	2.5 mm <sup>2</sup>
39	40	Command: open CB for shutdown	2.5 mm <sup>2</sup>



### NOTE

The relay "open CB for shutdown" is used to automatically open the CB after the power has been reduced (see also Control Outputs on page 29). This relay is not controlled by monitoring functions.




Figure 3-12: Relay outputs - control outputs II (acknowledgements)

### Monitoring relay

#### N.C. functionality

Root	Switched	Description	A <sub>max</sub>
<i>A</i>	<i>B</i>	<b>Note:</b> The relays are de-energized and open in case of an fault.	
37	38	Reverse/reduced load, overload	2.5 mm <sup>2</sup>
41	42	Generator over/under voltage	2.5 mm <sup>2</sup>
43	44	Generator over/under frequency	2.5 mm <sup>2</sup>

### Signal relay

#### N.O. functionality

Root	Switched	Description	A <sub>max</sub>
<i>A</i>	<i>B</i>	<b>Note:</b> The relay is energized and closed when the function is fulfilled.	
18	19	Ready for operation	2.5 mm <sup>2</sup>

#### N.C. functionality

Root	Switched	Description	A <sub>max</sub>
<i>A</i>	<i>B</i>	<b>Note:</b> The relay will be de-energized and opens when the power limit is exceeded.	
16	17	Power limit	2.5 mm <sup>2</sup>



# Controller Outputs



The SPM-D11/[LSR](#) is equipped with two three-position controllers for voltage and frequency (each comprising a form C and form A relay). The SPM-D11/[LSXR](#) permits various analog or PWM output signals to be selected by configuration, which can then be utilized in different ways.

## SPM-D11/[LSR](#)




Figure 3-13: Controller - SPM-D11/[LSR](#) - three-position controller

Terminal		Description	A <sub>max</sub>
8	common	Speed/frequency controller Real power controller	2.5 mm <sup>2</sup>
9	raise		2.5 mm <sup>2</sup>
10	lower		2.5 mm <sup>2</sup>
11	common	Voltage controller Power factor controller	2.5 mm <sup>2</sup>
12	raise		2.5 mm <sup>2</sup>
13	lower		2.5 mm <sup>2</sup>

## SPM-D11/LSXR

The SPM-D11/LSXR controller outputs can be configured for the following signals and may require the use of an external jumper between terminals.

### Versions



#### NOTE

Only one controller output may be configured as three-step controller.

- **Three-step controller** via relay manager
  - Control of n/f: Parameter "**f control type**" = THREESTEP
    - n+/f+ = Relay connected to terminals 45/46
    - n-/f- = Relay connected to terminals 47/48
  - Control of V: parameter "**V control type**" = THREESTEP
    - V+ = Relay connected to terminals 45/46
    - V- = Relay connected to terminals 47/48
- **Analog controller output**
  - Control of n/f: Parameter "**f control type**" = ANALOG
    - Current output (mA) = no external bridge/jumper necessary
    - Voltage output (V) = external bridge/jumper between 8/9
    - Connect the Controller to terminals 9/10
  - Control of V: Parameter "**V control type**" = ANALOG
    - Current output (mA) = no external bridge/jumper necessary
    - Voltage output (V) = external bridge/jumper between 11/12
    - Connect the controller to terminals 12/13
- **PWM controller output**
  - Control of n/f: Parameter "**f control type**" = PWM
    - PWM output = external bridge/jumper between 8/9
    - Connect the controller to terminals 9/10

### Connection of the controllers

Setting: 'THREESTEP' (three-position controller)




Figure 3-14: Controller - SPM-D11/LSXR - three-position controller

Terminal	Description	A <sub>max</sub>
45	raise	2.5 mm <sup>2</sup>
46		2.5 mm <sup>2</sup>
47	lower	2.5 mm <sup>2</sup>
48		2.5 mm <sup>2</sup>

## Setting: 'ANALOG' and 'PWM' (Analog Controller) - Frequency/real power controller




Figure 3-15: Controller - SPM-D11/LSXR - Analog controller output - Speed/frequency/real power

Type	Terminal	Description	$A_{max}$
<b>I</b> Current	8	Speed controller / Frequency controller / Real power controller	2.5 mm <sup>2</sup>
	9		2.5 mm <sup>2</sup>
	10		2.5 mm <sup>2</sup>
<b>V</b> Voltage	8	Speed controller / Frequency controller / Real power controller	2.5 mm <sup>2</sup>
	9		2.5 mm <sup>2</sup>
	10		2.5 mm <sup>2</sup>
<b>PWM</b>	8	Speed controller / Frequency controller / Real power controller	2.5 mm <sup>2</sup>
	9		2.5 mm <sup>2</sup>
	10		2.5 mm <sup>2</sup>

## Setting: 'ANALOG' (Analog Controller) -Voltage / power factor controller




Figure 3-16: Controller - SPM-D11/LSXR - Analog controller output - Voltage/power factor

Type	Terminal	Description	$A_{max}$
<b>I</b> Current	11	Voltage controller Power factor cosphi controller	2.5 mm <sup>2</sup>
	12		2.5 mm <sup>2</sup>
	13		2.5 mm <sup>2</sup>
<b>V</b> Voltage	11	Voltage controller Power factor cosphi controller	2.5 mm <sup>2</sup>
	12		2.5 mm <sup>2</sup>
	13		2.5 mm <sup>2</sup>

# Chapter 4.

## Description of Functions

### Functional Description



#### Table for Terminal 6 = "Enable Control"

With this setting, the control can be used as an SPM-A.

The status of the discrete inputs "Reply: CB is open" and "Enable CB" is displayed via the LEDs "Gen CB - ON" and "Gen CB free" on the pressure-sensitive front membrane. Additional to the input signals the conditions Table 4-3: Operating conditions - must be observed.

Input signal				Operating condition	Cond.	Relay "Command: close CB"	Operating mode SPM-A
LED "Gen-CB ON"	LED "Gen CB free"	Discrete input term. 5: "Enable isolated operation/ dead start"	Discrete input term. 6 "Enable controller"				
0	0	x	0	OFF or automatic idle control	- C1	OFF OFF	OFF
0	0	x	1	Idle operation or synchronization	C A	OFF OFF	CHECK
0	1	0	0	OFF	A	Slip or phase matching	PERMISSIVE
0	1	0	1	Idle operation or synchronization	C A	OFF Slip or phase matching	RUN
0	1	1	0	OFF	A	Synchro-Check	-
0	1	1	1	Idle operation or synchronization or dead bus start	C A B	- Slip or phase matching dead bus start	RUN (extended)
1	x	x	0	OFF	-	OFF	-
1	0	0	1	Mains parallel operation or shut down	- E	OFF OFF	-
1	1	0	1	Mains parallel operation	-	OFF	-
1	1	1	1	Load/var sharing or isolated operation	F D	OFF OFF	-
1	0	1	1	Load/var sharing or isolated operation or shut down	F D E	OFF OFF OFF	-

0: "OFF" / 1: "ON" / x: Signal of no significance (0 or 1)

Table 4-1: Operating conditions - Terminal 6 = "Enable control"

## Table for Terminal 6 = "Enable Power Set point Value 2"

The status of the digital inputs "Reply: CB is open" and "Enable CB" is displayed via the LEDs "GCB closed" and "Release GCB" on the pressure-sensitive front membrane. Additional to the input signals the conditions listed in Table 4-3: Operating conditions - must be observed.

Input signal			Operating condition	Cond.	Relay "Command: close CB"
LED "Gen-CB ON"	LED "Gen CB free"	Discr. input term. 5: "Enable Isolated operation/ dead start"			
0	0	x	OFF or idle operation	- C1	OFF OFF
0	1	0	Idle operation or synchronization	C A	OFF Slip or phase matching
0	1	1	Idle operation or synchronization or dead bus start	C A B	OFF Slip or phase matching Black start
1	0	0	Mains parallel operation or shut down	- E	OFF OFF
1	1	0	Mains parallel operation	-	OFF
1	1	1	Load/var sharing or isolated operation	F D	OFF OFF
1	0	1	Load/var sharing or isolated operation or shut down	F D E	OFF OFF OFF

0: "OFF" / 1: "ON" / x: Signal of no significance (0 or 1)

Table 4-2: Operating conditions - Terminal 6 = "OFF"

## Additional Conditions

The function of the control is also dependent, apart from the digital input signals, on the state of the available measured voltages. The particular function must also be enabled in configuration mode:

Condition		
<b>A</b>	Synchronization Generator circuit breaker	- Generator and synchronization voltage must comply with the following: 50 % < V < 125 % of the rated voltage $V_N$ 80 % < f < 110 % of the rated frequency $f_N$ (after time monitoring expires, the synchronization will be aborted)
<b>B</b>	Dead bus Generator circuit breaker	- Parameter "Dead bus GCB ON" - Synchronization voltage must be less than 5% of the rated voltage - Generator voltage and frequency must be within the configured limits of the dead bus start
<b>C1</b>	Automatic no-load control	- Parameter "Automatic no-load control ON" - The frequency controller complies with the following conditions: Generator voltage > 50 % of the rated voltage $V_N$ - The voltage controller complies with the following conditions: Generator frequency > 90 % of the rated frequency $f_N$
<b>C</b>	No-load operation	- for f control: Generator voltage > 50 % of rated voltage $V_N$ - for V control: Generator frequency > 90 % of rated frequency $f_N$
<b>D</b>	Isolated operation	- Generator voltage > 50 % of rated voltage $V_N$ - For voltage controller: Parameter "Voltage controller in no-load operation ON" - For frequency controller: Parameter "Frequency controller in isolated operation ON".
<b>E</b>	Shut down	- Parameter "Shut down ON"
<b>F</b>	Load/var sharing control	- for load sharing: Parameter "Load sharing ON" - for var sharing: Parameter "var sharing ON"

Table 4-3: Operating conditions - status of measuring inputs and configuration

## Control Inputs



- Release CB**  
Terminal 3
- Terminal 6 = "Release control"  
A signal into this discrete input enables operation of the power circuit breaker. For tests during commissioning, ensuring that no voltage is applied to this input will prevent the power circuit breaker from operating, even if the control functions are enabled.
  - Terminal 6 = "Set point power"  
A signal into this discrete input enables the operation of the breaker and the control functions.

**Reply:**  
**CB is open**  
Terminal 4

The status of the CB must be transmitted to the unit through this input. The input must be energized if the CB is open. The status of this input is checked for its plausibility and is signaled with the LED "Gen CB - ON".

**Enable: Isolated operation/dead bus start**  
Terminal 5

Energizing this input when the breaker is open enables a dead bus start. Energizing this input when the breaker is closed enables the frequency and voltage controllers for isolated operation or load sharing control.

- Enable control**  
**Enable Pset 2**  
Terminal 6
- Terminal 6 = "Release control"  
The frequency and voltage controllers are enabled by energizing this input. For tests during commissioning, ensuring that no voltage is applied to this input will prevent the power circuit breaker from operating, even if the control functions are enabled.
  - Terminal 6 = "Set point power"  
The second set point value or the set point value via analog input is enabled.



### CAUTION

If several generators feed one busbar, it has to be ensured with external interlocking that only one of the generators is released for dead bus start at a time. If several generators are released for dead bus start at the same time, it may happen that the generator circuit breakers close at the same time, which might cause serious damage to the generators!

## Isolation of the Power Supply from the Discrete Inputs



### NOTE

**Please observe the notes about the maximum voltage ratings in the section Discrete Inputs on page 14!**

By means of appropriate external wiring, the common reference point of the discrete inputs (terminal 7) can be galvanically separated from the supply voltage (0 V, terminal 2). This is necessary, for instance, if the discrete inputs are not to be controlled with +24 Vdc and a galvanic separation of the control voltage (e. g. 220 Vdc, 220 Vac) from the supply voltage needs to be ensured.

Wiring should be made as follows:

- Reference points connected with 0 V  
Jumper between terminal 7 and terminal 2 (0 V)
- Reference point of the discrete inputs potential-free:  
Terminal 2: 0 V (supply voltage)  
Terminal 7: 0 V or N (control voltage)



## Operating Conditions



### No Load Control

The generator voltage and generator frequency are adjusted to the configured set point values. The generator circuit breaker is open.

### Synchronization

#### Synchronization with slip

The generator voltage will be corrected to the amplitude and frequency of the synchronization voltage. The close command for the power circuit breaker will be issued, taking into account the inherent switching delay. The synchronization is carried out under the following conditions (see also tables in chapter "Function" at page 20):

- The control is in the automatic mode (LED "Automatic" lights up)
- The synchronization is switched on
- The voltages and frequencies are within the specified range
- The input "Enable CB" is energized (if terminal 6 = OFF)
- The input "Enable CB" is energized to enable the close command and the input "Release control" is energized, to enable the control functions (if terminal 6 = Release control)
- The input "Reply: CB is open" is energized
- The synchronization time monitoring is not switched on or has not tripped

#### Phase Matching Synchronization

The voltage controller will correct the generator voltage to the amplitude of the synchronization voltage. The frequency controller operates in two possible stages:

- Frequency correction: - As long as the difference of the frequency between generator and busbar/mains does not fall below the configured value "df start", the generator frequency is corrected to that of the busbar/mains.
- Phase angle correction: - If the frequency difference between generator and busbar/mains is less than the value "df start", the frequency controller adjusts the phase angle of the generator to that of the busbar/mains, in order to drive the phase difference to zero. The control of the phase angle is stopped only when the frequency difference between the generator and the busbar/mains becomes greater than the value "df start" plus a fixed programmed hysteresis of 0.8 Hz.

The close command for the power circuit breaker is issued under the following conditions:

- The configured limits for voltage and frequency are met
- The phase angle between the systems is less than the maximal permissible angle for at least the configured time
- The input "Enable CB" is energized (if terminal 6 = OFF)
- The input "Enable CB" is energized, to enable the close command and the input "Release control" is energized, to enable the controls (if terminal 6 = Release control)
- The input "Reply: CB is open" is energized

The close command is issued without consideration of the inherent switching delay. In the phase-angle-zero-control mode, the analog input should be selected for the frequency controller.

## Synch-Check

In this condition, the unit can be used as a check-synchronizer. No control is carried out. The relay "Command: CB close" remains energized, as long as the following conditions are met:

- The configured limit for the voltage difference is met (screen "synchronization  $dV_{\max}$ ")
- The configured limits for the frequency difference are met (screen "synchronization  $df_{\max}$  and  $df_{\min}$ ")
- The configured limit for the phase angle is met (screen "slip synchroniz.  $\text{phase}_{\max}$ ")
- The input "Reply: CB is open" is energized
- The parameter "Terminal 6" is configured to "Release control"
- The terminal 6 is not energized (the control is disabled)
- The input "Enable isolated operation / dead bus start" is energized
- The input "Enable CB" is energized

The synchronization time monitoring is disabled.

## Isolated Operation

The generator voltage and frequency are controlled according to the configurable set point values. The generator breaker is closed. To activate the voltage controller, the parameter "volt. controller in isol. oper." must be set to "ON". To activate the frequency controller, the parameter "freq. controller in isol. oper." must be set to "ON". Additionally, the discrete input "Enable isolated operation / dead bus start" must be energized to enable isolated operation.

## Closing the CB Without Synchronization (Dead Bus Start)

A close command for the power circuit breaker will be output without synchronization if the following conditions are met:

- The control is in the automatic mode (LED "Automatic" lights up)
- The parameter "**Gen. circ.break. Dead bus op.**" has been set to "ON"
- The bus bar is not energized ( $V_{SS} < 5 \% V_N$ )
- The generator voltage and frequency are within the configured limits
- The input "Enable isolated operation / dead bus start" is energized
- The input "Enable CB" is energized
- The input "Reply: CB is open" is energized



### CAUTION

If several participants in a power pool are enabled to perform a dead bus start, an external interlock must ensure that it is not possible for two or more units to perform a dead bus start.

## Shutdown

If the parameter "Download and open GCB" has been configured as "ON", the controller can be configured to perform a shutdown function in the following manner:

- Terminal 3 "Enable CB" is de-energized, initiating the shutdown
- The power will be reduced according to the setting configured in "Power controller ramp" (refer to section Power Set point Value on page 54)
- When the real power falls below 10 % of the generator rated power, the relay "Command: open CB" will open

## Mains Parallel Operation

In mains parallel operation both circuit breakers are closed and the real power and the power factor  $\cos \phi$  are controlled to the configured set point values, provided that the controllers are configured to enabled. If the parameter "terminal 6 = Release control" is set, terminal 6 must also be energized, so that the controllers operate.

### Selection of the power set point value

- If the generator is connected in parallel with the mains via the CB, initially a partial load is assumed.
- When the partial load pre-run is completed (or deactivated) the following table is valid for the selection of the power set point mode:

Parameter "Terminal 6"	Condition "Terminal 6"	Parameter "Power set point external"	active set point value
Release control	x	ON	External: via 0 to 20 mA
		OFF	Internal: Power controller Pset2
Set point power	1	ON	External: via 0 to 20 mA
	0	OFF	Internal: Power controller Pset2
		x	Internal: Power controller Pset1

0: "OFF" / 1: "ON" / x: Signal of no significance (0 or 1)

Table 4-4: Power set point modes

- If an external signal has been selected for the parameter "Power set point external", the correct signal type must be selected on the following configuration screen.
- The power set point upper limit must be configured as the value "Power controller P max"
- The power set point lower limit must be configured as the value "Power controller P min"
- The power set point has a configurable ramp rate. This slope can be configured in the parameter "Power controller Ramp".

## Load Sharing

The SPM-D11 is designed so that when several generators are operating in parallel (isolated operation) on a common mains bus, the real power of the isolated system (in reference to the relevant rated load) is shared equally among the generators.

**Isolated/mains parallel operation.** Each controller participating in load sharing influences the genset to which it is assigned in such a manner that the preset rated frequency (main control variable) remains constant. All units are interlinked via an analog signal against which any deviation in real power (generator power) can be determined for each genset. This control variable (secondary variable) is taken into consideration in controlling the frequency. The weighting, with which the secondary and the main control variable (= "reference variable") are processed, can be set via a weighting factor (parameters "Act. load share Factor"). In settled state, the isolated system has the set rated frequency, whereby the total real power (in reference to the relevant rated power) is subdivided equally amongst those gensets involved.

**Note** – The frequency regulators of the generators must be suitably configured for parallel operation (i.e. droop operation mode)

**Note** – Other SPM-D11 units, which are not participating in load sharing, must not be connected to the load sharing signal line (terminal 29)

**Prerequisite** – The following values and adjustments of each unit in the load sharing system must be identical

- All units must have identical configured rated frequencies
- All units must have the "Load sharing" function configured to "ON"
- All units must have the same status signal for "Enable CB" (either all logic "1" or all logic "0")
- All units must have the same status signal for "Reply: CB closed" (either all logic "1" or all logic "0")
- Only one unit may have the parameter "Gen. circ.break. Dead bus op" configured as "ON"

The "Gen. circ.break. Dead bus op" parameter can be enabled for several units, provided that a control is available to override the function via the digital inputs "Enable CB" or "Enable isolated parallel operation".

## var Sharing

The SPM-D11 is designed so that when several generators are operating in parallel (isolated operation) on a common mains bus, the reactive power of the isolated system (in reference to the relevant rated load) is shared equally among the generators.

**Isolated/mains parallel operation.** Each controller participating in var sharing influences the genset to which it is assigned in such a manner that the preset rated voltage (main control variable) remains constant. All units are interlinked via an analog signal against which any deviation in reactive power (generator power) can be determined for each genset. This control variable (secondary variable) is taken into consideration in controlling the voltage. The weighting, with which the secondary and the main control variable (= "reference variable") are processed, can be set via a weighting factor (parameters "React. load share Factor"). In settled state, the isolated system has the set rated voltage, whereby the total reactive power (in reference to the relevant rated power) is subdivided equally amongst those gensets involved.

**Note** – The voltage regulators of the generators must be suitably configured for parallel operation (i.e. droop operation mode)

**Note** – Other SPM-D11 units, which are not participating in var sharing, must not be connected to the load sharing signal line (terminal 30)

**Prerequisite** – The following values and adjustments of each unit in the var sharing system must be identical

- All units must have identically configured rated voltage
- All units must have the parameter "Reactive power Load-share" configured as "ON"
- All units must have the same status signal for "Enable CB" (either all logic "1" or all logic "0")
- All units must have the same status signal for "Reply: CB closed" (either all logic "1" or all logic "0")

The "Gen. circ.break. Dead bus op" parameter can be enabled for several units, provided that a control is available to override the function via the digital inputs "Enable CB" or "Enable isolated parallel operation".

## LED "Gen CB - ON" Flashes

**LED "Gen CB - ON" flashes:** Incorrect signal state of the "Reply: CB is open" on terminal 4.

Possible faults:

- Reply "closed" is present (= 0 V) and the generator and mains/busbar voltage not synchronized

If the LED flashes, one must check to see whether the input on terminal 4 is wired correctly. If the terminal is wired correctly, there will be **0 V** applied to the input when the **power circuit breaker is closed**.

## Control Outputs



**Synchronization pulse:** Energizing this relay will close the CB. The relay de-energizes after the close pulse is output. Exception: "Synch-check" operating mode.  
**Command: Close CB**  
 Terminals 14/15

**Readiness for operation** The relay contact is closed when the control is ready for operation. The relay will de-energize if any of the following occurs:  
 Terminals 18/19

- a) The internal self-monitoring system signals an alarm condition. In this case a trouble-free function of the control cannot be guaranteed and other appropriate corrective measures must be taken.
- b) The synchronization time monitoring system is enabled and the configured time has expired before synchronization has occurred.

**Command: open CB** The contact for this function is a N.O. contact. In normal operations, this contact is continuously energized. It is de-energized when the "Shut down" function is enabled.  
**(for shut down)**  
 Terminal 39/40

### Prerequisites:

- The parameter "Download and open GCB" is configured to ON
- The circuit breaker is closed

The controller can be configured to perform a shutdown function in the following manner:

- Terminal 3 "Enable CB" is re-energized, initiating the shutdown
- The power will be reduced
- When the real power falls below 10 % of the generator rated power, the relay "Command: open CB" will open

This relay is reserved for shut down functions and operates independently from the watchdogs.

**Power limit** This relay serves for controlling the power to a configured limit. The relay opens when the power limit value is exceeded for the configured time and closes again, when the power falls below the limit value minus the configured hysteresis. Using this relay, it is possible for example to disconnect loads or activate further generators.  
 Terminal 16/17

## Analog Controller Outputs



The analog PID controller forms a closed-loop control loop together with the controlled system (usually a first-order lag element). The parameters of the PID controller (proportional-action coefficient  $K_p$ , derivative-action time  $T_v$  and reset time  $T_n$ ) can be modified individually.




Figure 4-1: Control loop

If an abrupt disturbance variable is applied to the control loop, the reaction of the controlled system can be recorded at the output as a function of time (step response).




Figure 4-2: Step response (example)

Various values can be derived from the step response; these are required for adjusting the controller to its optimum setting:

**Rise time  $T_{rise}$ :** Period starting when the value of the control variable leaves a predefined tolerance range for this variable following a jump in the disturbance variable or reference input variable and ending the first time the value re-enters this range.

**Settling time  $T_{sett}$ :** Period starting when the value of the control variable leaves the predefined tolerance range for the control variable following a step in the disturbance variable or reference input variable and ending when the value re-enters this range permanently.

**Overshoot  $x_m$ :** Highest transient deviation from the set point value during the transition from one steady-state condition to a new steady-state condition, following a change in value of the disturbance variable or reference input variable ( $x_{m\text{ Optimal}} \leq 10\%$ ).

**Permanent control deviation  $x_d$ :** The resultant deviation between set point value and output variable in the steady-state condition (PID controller:  $x_d = 0$ ).

From these values, the values  $K_p$ ,  $T_n$  and  $T_v$  can be derived. It is possible, to determine the optimal controller settings by calculating compensation or adjustment of the time constants, T-sum rule, or symmetrical optimum. Other setting procedures and information may be obtained from current literature.



**CAUTION**

The following must be observed regarding the controller setting:

- Ensure that the emergency shutdown system is ready for use.
- While determining the critical frequency, pay attention to the amplitude and frequency.
- If the two values change in an uncontrollable manner:

**→ EMERGENCY SHUTDOWN ←**

**Initial state:** The initial state determines the start position of the controller. If the controller is switched off, the initial state can be used to output a fixed controller position. Even when the analog controller is switched off, the initial state can be freely adjusted (e.g. the speed controller can be controlled in a static manner).

<div>Controller output</div> <div>Initial state 000%</div>	<b>Initial state</b> <span>0 to 100 %</span>
	Analog controller output setting with controller switched off.

**General settings:** The setting rule described below only serves as an example. Whether this method is suitable for setting your particular control system is not and cannot be taken into account, as each controlled system behaves uniquely.

There are various methods of setting a controller. The setting rules of Ziegler and Nichols are explained below (determination for abrupt disturbances on the system input); this setting method assumes a pure lag element connected in series with a first-order lag system.

1. Controller operated as a P-only controller  
(where  $T_n = \infty$  [screen setting:  $T_n = 0$ ],  $T_v = 0$ ).
2. Increase gain  $K_p$  (P gain) until the control loop oscillates continuously at  $K_p = K_{p\text{crit}}$ .



CAUTION

If the control starts to oscillate uncontrollably, perform an emergency shutdown and change the screen setting accordingly.

3. Measuring of the cycle duration  $T_{\text{crit}}$
4. Set the parameters:

PID controller

$$\begin{aligned} K_p &= 0,6 \times K_{p\text{crit}} \\ T_n &= 0,5 \times T_{\text{crit}} \\ T_v &= 0,125 \times T_{\text{crit}} \end{aligned}$$

PI controller

$$\begin{aligned} K_p &= 0,45 \times K_{p\text{crit}} \\ T_n &= 0,83 \times T_{\text{crit}} \end{aligned}$$




Figure 4-3: Step response - controller set-up

<div>Pr.-sensitivity</div> <div><math>K_p = 000</math></div>	<div>P gain (<math>K_p</math>) Proportional-action coefficient</div> <div>1 to 240</div> <div>The proportional-action coefficient <math>K_p</math> indicates the closed-loop control system gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The optimum setting depends on the behavior of the system. If the gain is too low, the control action becomes slow. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.</div>
<div>Reset time</div> <div><math>T_n = 00.0s</math></div>	<div>Reset time (<math>T_n</math>)</div> <div>0.2 to 60.0 s</div> <div>The reset time <math>T_n</math> represents the I-component of the PID controller. The reset time corrects for any offset (between set point and process variable) over time until the process variable and the set point are the same. This parameter defines how quickly the reset attempts to correct for any offset. If <math>T_n</math> is configured as 0.00 s, the I-component of the PID loop is disabled.</div>
<div>Derivative act. time</div> <div><math>T_v = 0.00s</math></div>	<div>Derivative-action time (<math>T_v</math>)</div> <div>0.00 to 6.00 s</div> <div>The derivative-action time <math>T_v</math> represents the D-component of the PID controller. The D-component of the controller output becomes effective with large variations of the offset, e.g. in case of load-shedding. The lower the derivative-action time is configured, the higher the controller reaction is. If <math>T_v</math> is configured as 0.00 s, the D-component of the PID loop is disabled.</div>



## Chapter 5.

# Display and Operating Elements

The foil of the front plate is made of coated plastic. All keys have been designed as touch-sensitive membrane switch elements. The display is a LC-display, consisting of 2 rows each with 16 characters, which are indirectly illuminated red. Contrast of the display is infinitely variable by a rotary potentiometer at the left side.




Figure 5-1: Front foil

## Brief Explanation of the LEDs and Push Buttons



### LEDs

No	Description	Function
1	Bus CB Free	Non-functional
2	Gen CB Free	Enable CB
3	Automatic	Automatic mode
4	CB close	Close command to the CB issued
5	Synchroscope	Display of phase position
6	f-	Governor output: frequency lower (reduce speed)
7	f+	Governor output: frequency raise (increase speed)
8	V-	Governor output: voltage lower (reduce excitation)
9	V+	Governor output: voltage raise (increase excitation)
10	Gen CB - ON	Reply: CB is closed
11	Bus CB - ON	Non-functional

### Buttons

No	Description	Function
12	Display↓	Scroll display
12	Select	Confirm selection
13	Digit↑	Increase digit
14	Clear	Acknowledge alarm
14	Cursor→	Shift input position one digit to the right

### Others

No	Description	Function
15	LC-Display	LC-Display
	Potentiometer	Adjust LCD contrast

LEDs



1	<b>Bus CB Free</b> here: non-functional Color: green	<b>Enable mains circuit breaker</b> <hr/> <b>NOTE:</b> This LED is non-functional, as this is a "One-power-circuit-breaker configuration".						
2	<b>Gen CB Free</b> Color: green	<b>Enable generator circuit breaker</b> <hr/> The LED "Gen CB Free" indicates that the power circuit breaker has been enabled for operation. The status of the LED corresponds to the status of the discrete input "Enable CB".						
3	<b>Automatic</b> Color: green	<b>Automatic mode</b> <hr/> The LED "automatic" illuminates when the control is in automatic mode. It will extinguish as soon as you switch to the configuration mode.						
4	<b>CB close</b> Color: green	<b>CB close</b> <hr/> The LED "CB close" illuminates when the control outputs a close command to the power circuit breaker. The status of the LED corresponds to the status of the relay "synchronizing pulse command: close CB".						
5	LED-row: <b>too fast</b> → Color: red/yellow/green	<b>Phase position / synchroscope</b> <hr/> The row of LEDs indicates the current phase position between the two voltages indicated on the display. The green LED in the middle of the 15 LEDs indicates that the measured phase angle between the voltage systems is less than 12 ° electrically. The phase position is only displayed in the automatic mode and only if the difference between the frequency values is smaller than 2 Hz and both voltages are within the specified permissible ranges. These ranges are defined as follows:  <table><tr><td><b>Frequency ranges</b></td><td>Generator and mains</td><td>80 to 110 % <math>f_N</math></td></tr><tr><td><b>Voltage ranges</b></td><td>Generator and mains</td><td>50 to 125 % <math>V_N</math></td></tr></table> There are two different directions of rotation: <b>left → right</b> . If the LED's run from left to right, the generator frequency is too high, i. e., the generator or the variable bus frequency is too fast. <b>right → left</b> . If the LED's run from right to left, the generator frequency is too low, i. e., the generator or the variable bus frequency is too slow.	<b>Frequency ranges</b>	Generator and mains	80 to 110 % $f_N$	<b>Voltage ranges</b>	Generator and mains	50 to 125 % $V_N$
<b>Frequency ranges</b>	Generator and mains	80 to 110 % $f_N$						
<b>Voltage ranges</b>	Generator and mains	50 to 125 % $V_N$						

6	<b>f-</b> Color: yellow	<b>Governor output decrease frequency</b>
	<i>Three position controller</i>	The LED "f-" indicates if the control outputs a pulse to decrease the frequency. The status of the LED corresponds to the status of the relay "speed lower".
	<i>Analog controller</i>	If the actuator output signal of the controller is changing to reduce the frequency, the LED illuminates.
7	<b>f+</b> Color: yellow	<b>Governor output increase frequency</b>
	<i>Three position controller</i>	The LED "f+" indicates if the control outputs a pulse to increase the frequency. The status of the LED corresponds to the status of the relay "speed raise".
	<i>Analog controller</i>	If the actuator output signal of the controller is changing to increase the frequency, the LED illuminates.
8	<b>V-</b> Color: yellow	<b>Governor output reduce voltage</b>
	<i>Three-position controller</i>	The LED "V-" indicates if the control outputs a pulse to decrease voltage. The status of the LED corresponds to the status of the relay "voltage lower".
	<i>Analog controller</i>	If the actuator output signal of the controller is changing to reduce the voltage, the LED illuminates.
9	<b>V+</b> Color: yellow	<b>Governor output increase voltage</b>
	<i>Three-position controller</i>	The LED "V+" indicates if the control outputs a pulse to increase voltage. The status of the LED corresponds to the status of the relay "voltage raise".
	<i>Analog controller</i>	If the actuator signal of the controller is changing to increase the voltage, the LED illuminates.
10	<b>Gen CB - ON</b> Color: green	<b>Power circuit breaker ON</b>
		The LED "Gen CB - ON" signals the response of the generator circuit breaker. The LED illuminates if the discrete input "Reply: CB is open" is not energized and will extinguish as soon as the discrete input is energized. (see also chapter "LED "Gen CB - ON" Flashes" on page 28).
11	<b>Bus CB – ON</b> here: non-functional Color: green	<b>Mains power circuit breaker ON</b>
		<b>NOTE:</b> This LED is non-functional, as this is a "One-power-circuit-breaker configuration".

# Push Buttons



Configuration may be performed by manually inputting the desired set points utilizing the pushbuttons and the LC display. In order to facilitate configuring the parameters, the push buttons have been enabled with an AUTOROLL function. This permits the user to advance to the next setting, configuration screen, digit, and/or cursor position more rapidly by pressing and holding the corresponding pushbutton.

12	Display / Select	<b>Display / Select</b>
		<b>Automatic mode:</b> <u>Display</u> - By pressing this button, the user may navigate through the displayed measured parameters and alarm messages. <b>Configuration:</b> <u>Select</u> - Advances the LC display to the next configuration screen. If any values in a configuration screen have been modified with the "Digit↑" or "Cursor→", then the "Select" button must be pressed to save the new setting. By pressing this pushbutton again, the user causes the system to display the next configuration screen.
13	Digit↑	<b>Digit ↑</b>
		<b>Automatic mode:</b> <u>Digit↓</u> - no function <b>Configuration:</b> <u>Digit↑</u> - Numerical values over the cursor are increased by one digit. The increase is restricted by the admissible limits (refer to the list of parameters included in the appendix). If the maximum admissible number is reached, the number automatically returns to the lowest admissible number.
14	Clear / Cursor →	<b>Clear / Cursor→</b>
		<b>Automatic mode:</b> <u>Clear</u> - Alarms that have occurred may be acknowledged by pressing this button as long as the fault that triggered the alarm is no longer present. <b>Configuration:</b> <u>Cursor→</u> - This button moves the cursor one position from left to right. When the cursor is under the last digit that may be changed, it may be moved to the first number of the value by pressing the "Cursor→" button again.

## LC Display



15

LC-Display **LC-Display**

The two-line LC display outputs corresponding text messages and values depending on the mode that the SPM-D is operating. In the configuration mode, the monitoring parameters may be changed. When the SPM-D is in the automatic mode, the measured values are displayed.

### Display Monitoring in Automatic Mode: Double Voltage / Frequency Display

LCD type 1 (V configured)

```
B: 000 V 00.00Hz
G: 000 V 00.00Hz
```

#### Double voltage and double frequency displays, Generator values

The generator and synchronization voltage and frequency are displayed. The phase angle between the generator and synchronization voltage is displayed by the synchroscope (LED strip).

LCD type 2 (kV configured)

```
B: 00,0kV 00.00Hz
G: 00,0kV 00.00Hz
```

B ..... Synchronization voltage and frequency  
G ..... Generator voltage and frequency

LCD type 1 (V configured)

```
Gen 000V i0.95
    000A 000kW
```

#### Generator values

Generator values are monitored:

G ..... Generator values

- upper line:
  - Line voltage L1-L2
  - phase angle
- bottom line:
  - current L1
  - Real power

LCD type 2 (V configured)

```
Gen 00,0kV i0.95
    000A 000MW
```



#### NOTE

Refer to the appendix Power Factor Definition on page 75 for the phase angle display.

### Display Monitoring in Automatic Mode: Alarm Indication

```
-----
xxxxxxxxxxxxxxxxxx
```

#### Alarm indication, bottom line

The indications are displayed according to the following list:

Type of alarm	Displayed text
Synchronization time is exceeded	Synchr. time
Wire break 0/4-20mA input for set point value	Wirebreak P <sub>set</sub> .
Generator underfrequency	Gen. underfrequency.
Generator overfrequency	Gen. overfrequency.
Generator undervoltage	Gen.undervoltage.
Generator overvoltage	Gen.overvoltage.
Generator overload	Gen.overload.
Generator reverse-/reduced load	Reverse/reduced load.

# Chapter 6. Configuration



**CAUTION**

Please note that configuration should not be carried out while the control unit is in operation.



**NOTE**

A list of parameters may be found in the List of Parameters on page 72.

The configuration mode will be enabled through the front face panel by simultaneously pressing the "Digit↑" and "Cursor→" buttons. The user may advance through the configuration screens by pressing the "Select" button. Pressing and holding the "Select" button will enable the "AUTOSCROLL" function, permitting the user to rapidly advance through the configuration screens. Note that it is possible to back up to previous configuration screens, but the user may only move back up to four (4) screens and cannot back up from the first configuration screen to the last configuration screen. If the controller is left idle for 10 minutes, the controller automatically returns to the automatic mode.

## Configure Basic Data



SPRACHE/LANGUAGE

-----

Language selection

English / German

The desired language for the controller to operate in is set by this parameter. The screens (configuration and display screens) can be displayed either in German or English.

Software version

x.xxxx

Software version

Indicates the software version currently installed.

Password Protection

The unit is equipped with a three-level code hierarchy. This permits access to different levels of selected parameters and configuration privileges. A distinction is made between:

- **Code level 0 (CL0)** - User: Third party  
This code level does not allow access to the parameters. The configuration function is locked.
- **Code level 1 (CL1)** - User: Customer  
This code level authorizes the user to change selected parameters. Authorization for changing the pass code is not permitted at this level.
- **Code level 2 (CL2)** - User: Commissioner  
This code level grants full access privileges to all parameters. Authorization is also granted to changing pass codes. In this level, the code protection can be turned OFF (see below).

<div>Enter code</div> <div>XXXX</div>	<div>Enter code number</div> <div>0000 to 9999</div>
<p>When entering the configuration mode, the unit generates a random number. The appropriate code is now entered and confirmed with the "Select" button. If the random number was confirmed without being changed, the code level of the unit remains unchanged. Two four-digit code numbers (0000-9999) exist for accessing the parameters. The "Third Party" level does not have a code assigned since this level does not obtain access privileges to the configuration (protected by the code). If an incorrect pass code is entered, the control unit changes to code level 0.</p>	



**NOTE**

Once the code level has been set, it will remain unchanged, even after repeatedly entering the configuration mode. In the event that an incorrect code number is entered, the code level is set to CL0 and locked to the third party user level, thus preventing access to any user (reference: change passwords on page 40). Two hours after the last operation, the unit automatically reverts to code level CL0. By entering the correct code number, the appropriate privileges will be granted again.

The default code number for code level 1 (CL1) is "0001"!  
The default code number for code level 2 (CL2) is "0002"!  
Only in code level 2 can the password protection be disabled!

<div>Enter Password Protection</div> <div>ON</div>	<div>Password protection</div> <div>ON/OFF</div>
<p><b>ON</b> .....The password for code level 1 or 2 must be entered to access configuration. If a wrong code number was entered, the configuration will be blocked.</p> <p><b>OFF</b> .....All users have direct access to all parameters, the pass code is not required.</p>	



Direct Configuration



NOTE

To carry out direct configuration, you require a direct configuration cable (revision B or higher: part number 5417-557), the LeoPC1 program (supplied with the cable), and the corresponding configuration files. Please consult the online help installed when the program is installed for a description of the LeoPC1 PC program and its setup.

The parameters of the unit can be read via the configuration plug at any time. The parameters can only be altered via direct configuration if the password protection disabled or the unit is in code level 2. If the password protection is enabled and the unit is in code level 0 or 1, the password (code number) for code level 2 must be entered via direct configuration, to modify the parameters. The ability to modify parameters via the display is not affected by the password being entered through LeoPC1.

Direct para.	Configuration via the lateral plug	YES/NO
YES	YES..... Configuration via the configuration plug is enabled. The following further conditions must be met in order to carry out configuration via the configuration plug: <ul style="list-style-type: none"><li>- A connection must be established via the direct configuration cable between the control and the PC</li><li>- The baud rate of the LeoPC1 program must be set to 9600 Baud</li><li>- The corresponding configuration file must be used (file name: "*.cfg")</li></ul>	
	NO..... Configuration via the configuration plug is disabled.	

## Configure Basic Settings



### WARNING

The following values must be entered correctly to ensure proper monitoring of the generator. Failure to do so may lead to incorrect measuring of parameters resulting in damage to or destruction of the generator and/or personal injury or death!

Parameter 1	<b>Rated generator frequency</b>	<b>48.0 to 62.0 Hz</b>
<div>Rated Frequency fn = 00.0Hz</div>	Enter the rated frequency of the generator (or the utility mains) which in most cases is 50 Hz or 60 Hz.	
Parameter 2	<b>Generator set point frequency</b>	<b>48.0 to 62.0 Hz</b>
<div>Generator freq. Set point=00.0Hz</div>	The set point frequency of the generator is to be entered in this screen. It will be needed for the frequency controller while in no-load operation.	
<b>Potential Transformer</b>		
Parameter 3	<b>Secondary generator voltage (potential transformer)</b>	<b>1] 50 to 125 V, [4] 50 to 440 V</b>
<div>Gen. voltage secondary 000V</div>	The secondary generator voltage (busbar voltage) is set here in V. This information serves to show the primary voltage in the display. For voltages of 400 V measured without a potential transformer, 400 V must be entered here.	
Parameter 4	<b>Secondary mains voltage (potential transformer)</b>	<b>1] 50 to 125 V, [4] 50 to 440 V</b>
<div>Mains voltage secondary 000V</div>	Secondary mains voltage (busbar voltage) is set here in V. This entry serves to indicate the primary voltages in the display. In the case of measured voltages of 400 V without a potential transformer, 400 V must be entered here.	
Parameter 5	<b>Primary generator voltage (potential transformer)</b>	<b>0.1 to 65.0 kV</b>
<div>Gen. voltage primary 00.000kV</div>	The primary generator voltage is set here in kV. This entry serves to show the primary voltage in the display. For voltages of 400 V measured without a potential transformer, 0.40 kV must be entered here.	
Parameter 6	<b>Primary mains voltage (potential transformer)</b>	<b>0.1 to 65.0 kV</b>
<div>Mains voltage primary 00.000kV</div>	The primary mains voltage (busbar voltage) is set her in kV. The entry is serves to show the primary voltages on the display. In the case of measured voltages of 400 V without a potential transformer 0.40 kV must be set here.	
Parameter 7	<b>Rated voltage</b>	<b>[1] 50 to 125 V, [4] 70 to 420 V</b>
<div>Rated voltage Vn = 000V</div>	This value is used, among other things, to determine the permissible range for the synchronization.	
Parameter 8	<b>Generator set point voltage</b>	<b>[1] 50 to 125 V, [4] 50 to 440 V</b>
<div>Gen. voltage Set point 000V</div>	This value of the voltage specifies the set point of the generator voltage for no-load and isolated operation	

## Current Transformer

Parameter 9

Generator current transformer

10 to 9,990/x A

Current transf.  
Generator 0000/x

For the indication and control of the generator current, it is necessary to enter the current transducer ratio. The ratio must be selected in a manner to ensure that at maximum power, at least 60 % of the transformer rated current is flowing. Lower percentage values may lead to malfunctions. Moreover, additional inaccuracies occur in the control and monitoring functions.

{X} / 1 A..... Secondary rated current = 1 A at primary rated current = {X} A;  
{X} / 5 A..... Secondary rated current = 5 A at primary rated current = {X} A;



### NOTE

Starting with software version 6.3640 it is possible to perform power measurement for single-phase or three-phase generators with the SPM-D11. The necessary settings have to be made in the following two screens.

Parameter 10

Connection type generator

1W / 1W2

Connection type  
Gen. 1W2

from version 6.3640

1W..... Power measurement in single-phase system  
1W2..... Power measurement in three-phase system

Parameter 11

Angle adjustment generator current

-180° to 180°

Angle adjustment  
Gen. Curr. 000

from version 6.3640

The angle adjustment allows the use of current transformers, which are installed in a different current path than L1, for measurement. The angle adjustment serves to adjust the shift between current and voltage.

## Single-phase System

The voltage  $V_{LIN}$  is shifted by 30° compared with  $V_{L1L2}$ . This difference must be corrected for power measurement. Additionally, the phase of the current measurement must be taken in consideration.

Current transformer in phase	Connection type generator	Angle adjustment
L1	1W	-030°
L2	1W	090°
L3	1W	-150°

## Three-phase System with Symmetrical Load

For three-phase systems, the angle must be corrected only if the current is measured in L2 or L3, or if a counter clockwise rotating field is present. If the load is not symmetrical, the current **must** be measured in L1.

Current transformer in phase	Connection type generator	Angle adjustment for rotating field right	Angle adjustment for rotating field left
L1	1W2	000	-060
L2	1W2	120	060
L3	1W2	-120	-180

Parameter 12

Generator rated power

[1] 100 to 9,999 kW; [4] 5 to 9,999 kW

Rated power  
Gen. = 0000kW

Value of the generator rated power.

## Configure Controller



Entering the values in the subsequent screens will change the parameters of the controller.



**CAUTION**  
Incorrect entries may lead to wrong measuring values and result in damage to the generator!

### Idle Control

Parameter 13	<b>Automatic no-load control</b>	<b>ON/OFF</b>
<div>Automatic idle Running ON</div>	<b>ON</b> ..... With the generator power circuit breaker open, frequency and voltage are controlled to the adjusted set point values in spite of the controller not being enabled (see also chapter "Function" on page 20).	
	<b>OFF</b> ..... No-load control is carried out only with controller enabled (see also chapter "Function" on page 20).	
Parameter 14	<b>Function of terminal 6</b>	<b>Release control / Set point power</b>
<div>Terminal 6 -----</div>	<b>Release control</b> The controller is enabled via the discrete input on terminal 6. The power circuit breaker is enabled separately via terminal 3 (Enable CB). Changing the set point value is not possible.	
	<b>Set point power:</b> The power set point value is changed by energizing terminal 6. Enabling of the controller occurs along with enabling of the power circuit breaker via terminal 3 (Enable CB).	

### Frequency Controller

The SPM-D11/LSR is equipped with a three-position controller for frequency and does not contain the following screens. Only the screens for setting the three-position controller are available. With the extended version SPM-D11/LSXR, several controller output signals can be selected via the screens, which are listed by the controller model.

Parameter 15	<b>Frequency controller type</b>	<b>THREESTEP/ANALOG/PWM</b>
<div>f control type -----</div>	<b>THREESTEP</b> The frequency controller operates as three-step controller and issues raise (f+) and lower (f-) pulses via the configured relays. Only one of the two controllers (the frequency or the voltage controller) can be used for relay output at a time.	
	<b>ANALOG</b> .....The frequency controller operates as a continuous controller with an analog output signal (mA or V).	
	<b>PWM</b> .....The frequency controller operates as a continuous controller with a pulse-width-modulated output signal and constant level.	

LSXR Package only

**Note:** The controller setting and the following screens differ, depending on which type of controller is selected here.

## Three-Step Controller (SPM-D11/LSR and SPM-D11/LSXR: Setting 'THREESTEP')

Parameter 16	<b>Frequency controller</b>	<b>ON/OFF</b>
<div>Freq. controller ON</div> <p>LSXR Package: setting 'THREESTEP'</p>	<p><b>ON</b>..... The generator frequency is controlled. The control is executed in various manners depending on the task (no load / isolated operation / synchronization). The following screens of this function are displayed.</p> <p><b>OFF</b>..... Control is not carried out, and the following screens of this function are not displayed.</p>	
Parameter 17	<b>Isolated operation frequency controller</b>	<b>ON/OFF</b>
<div>Freq. controller Isol. oper. ON</div> <p>LSXR Package: setting 'THREESTEP'</p>	<p>The setting of this screen has no influence on the load sharing control.</p> <p><b>ON</b>..... In isolated operation the frequency controller is enabled.</p> <p><b>OFF</b>..... In isolated operation the frequency controller is disabled.</p>	
Parameter 18	<b>Frequency controller set point ramp</b>	<b>0.1 to 99.9 Hz/s</b>
<div>Freq. Controller Ramp =.00.0Hz/s</div> <p>LSXR Package: setting 'THREESTEP'</p>	A change in set point is supplied to the controller via a ramp. The slope of the ramp is used to alter the rate at which the controller changes the set point value. The more rapidly the change in the set point is to be carried out, the greater the value must be which is entered here.	
Parameter 19	<b>Frequency controller insensitivity</b>	<b>0.02 to 1.00 Hz</b>
<div>Freq. controller Dead band=0.00Hz</div> <p>LSXR Package: setting 'THREESTEP' only</p>	<p><b>No load/Isolated operation:</b> The measured generator frequency is controlled so that it does not deviate from the configured frequency by more than the value configured in this dead band setting while operating in a steady state.</p> <p><b>Synchronization:</b> The measured generator frequency is controlled so that the differential frequency does not exceed this dead band setting while operating in a steady state. The mains or busbar frequency is used as the set point value.</p>	
Parameter 20	<b>Minimum ON period – frequency controller</b>	<b>10 to 250 ms</b>
<div>Freq. controller Time pulse&gt;000ms</div> <p>LSXR Package: setting 'THREESTEP' only</p>	The minimum ON period of the relay should be selected in such a manner that the downstream control element responds reliably to the pulse length set here. The smallest possible time must be set in order to ensure optimum control behavior.	
Parameter 21	<b>Frequency controller gain</b>	<b>0.1 to 99.9</b>
<div>Freq. controller Gain Kp 00.0</div> <p>LSXR Package: setting 'THREESTEP' only</p>	The gain factor $K_p$ influences the ON time of the relays. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled resulting in longer ON time periods. The optimum setting depends on the behavior of the system. If the gain is too low, the control action becomes slow. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.	

## Analog Controller Outputs (SPM-D11/LSXR: Settings 'ANALOG' and 'PWM')

Parameter 22

Controller output signal

see table

f control output  
xxxxxxx

only LSXR Package  
with 'ANALOG' setting

This configuration screen only appears if the frequency controller is configured as ANALOG type! The range of the analog output signal is adjusted here. To choose between a current signal in mA or a voltage signal in V, the appropriate jumpers must be connected to the output terminals. (see chapter "Controller Outputs" on page 17). The following output signals are possible:

Type	Setting in above configuration screen	Jumper between terminal 8/9	Adjustment range	Adjustment range min.	Adjustment range max.
Current	+/-20mA (+/-10V)	no	+/-20mA	-20 mA	+20 mA
	+/-10mA (+/-5V)		+/-10mA	-10 mA	+20 mA
	0 to 10mA (0-5V)		0 to 10mA	0 mA	10 mA
	0 to 20mA (0-10V)		0 to 20mA	0 mA	20 mA
	4 to 20mA		4 to 20mA	4 mA	20 mA
	10 to 0mA (5 to 0V)		10 to 0mA	10 mA	0 mA
	20 to 0mA (10 to 0V)		20 to 0mA	20 mA	0 mA
	20 to 4mA		20 to 4mA	20 mA	4 mA
Voltage	+/-20mA (+/-10V)	yes	+/-10V	-10 Vdc	+10 Vdc
	+/-10mA (+/-5V)		+/-5V	-5 Vdc	+5 Vdc
	+/-3V		+/-3V	-3 Vdc	+3 Vdc
	+/-2.5V		+/-2.5V	-2.5Vdc	+2.5 Vdc
	+/-1V		+/-1V	-1 Vdc	+1 Vdc
	0 to 10mA (0- to 5V)		0 to 5V	0 Vdc	5 Vdc
	0.5V to 4.5V		0.5 to 4.5V	0.5 Vdc	4.5 Vdc
	0 to 20mA (0 to 10V)		0 to 10V	0 Vdc	10 Vdc
	10 to 0mA (5 to 0V)		5 to 0V	5 Vdc	0 Vdc
	4.5V to 0.5V		4.5 to 0.5V	4.5 Vdc	0.5 Vdc
	20 to 0mA (10 to 0V)		10 to 0V	10 Vdc	0 Vdc

Parameter 23

PWM signal level

3.0 to 10.0 V

f control output  
Level PWM 00.0V

only LSXR Package  
with 'PWM' setting

This configuration screen only appears if the frequency controller is configured as PWM type! The voltage level of the PWM signal is adjusted here.

Parameter 24

PWM signal logic

positive / negative

PWM-signal  
Logic -----

only LSXR Package  
with 'PWM' setting

This configuration screen only appears if the frequency controller is configured as PWM type!

**positive** .....If the controller output signal is at 100 %, the adjusted PWM level is output continuously, at 0 % output signal the output the PWM level is 0 V.

**negative** .....If the controller output signal is at 100 %, 0 V is output continuously, 0 % output signal corresponds to the adjusted PWM level.

Parameter 25

Initial frequency controller state

0 to 100%

f control output  
Init.state 000%

only LSXR Package  
with 'ANALOG' or 'PWM' setting

This parameter is the start point for the output signal when the frequency controller parameter is configured as OFF. The percentage value relates to the range between the minimum and maximum values that control unit can output (see below).

Parameter 26

<b>Freq. controller</b> <b>ON</b>
--------------------------------------

LSXR Package  
with 'ANALOG' or 'PWM' setting

**Frequency controller****ON/OFF**

**ON**..... The generator frequency is controlled. The generator frequency is controlled in various manners depending on the task (no load / isolated operation / synchronization). The following screens of this function are displayed.

**OFF**..... Control is not carried out and the following screens of this function are not displayed.

Parameter 27

<b>Freq. controller</b> <b>Isol. oper. ON</b>
--------------------------------------------------

LSXR Package  
with 'ANALOG' or 'PWM' setting

**Frequency controller – isolated operation****ON/OFF**

The setting of this screen has no influence on the load share control.

**ON**..... In isolated operation the frequency controller is enabled.

**OFF**..... In isolated operation the frequency controller is disabled.

Parameter 28

<b>Freq. controller</b> <b>Ramp 00.0Hz/s</b>
-------------------------------------------------

LSXR Package  
with 'ANALOG' or 'PWM' setting

**Frequency controller set point ramp****0.1 to 99.9 Hz/s**

A change in set point is supplied to the controller via a ramp. The slope of the ramp is used to alter the rate at which the controller follows the set point value. The more rapidly the set point should change, the greater this setting should be.

Parameter 29

<b>f control output</b> <b>(max.) 000%</b>
-----------------------------------------------

only LSXR Package  
with 'ANALOG' or 'PWM' setting

**Maximum value frequency controller****0 to 100%**

Upper limit of the analog controller output.

Parameter 30

<b>f control output</b> <b>(min.) 000%</b>
-----------------------------------------------

only LSXR Package  
with 'ANALOG' or 'PWM' setting

**Minimum value frequency controller****0 to 100%**

Lower limit of the analog controller output.

Parameter 31

<b>Freq. controller</b> <b>Gain Kp 000</b>
-----------------------------------------------

only LSXR Package  
with 'ANALOG' or 'PWM' setting

**P gain of the frequency controller****1 to 240**

The proportional-action coefficient KP indicates the closed-loop control system gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The optimum setting depends on the behavior of the system. If the gain is too low, the control action becomes slow. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value. Refer to "Analog Controller Outputs" on page 30.

Parameter 32

<b>Freq. controller</b> <b>Reset Tn 00.0s</b>
--------------------------------------------------

only LSXR Package  
with 'ANALOG' or 'PWM' setting

**Reset time frequency controller****0.0 to 60.0 s**

The reset time Tn represents the I-component of the PID controller. The reset time corrects for any offset (between set point and process variable) over time until the process variable and the set point are the same. This parameter defines how quickly the reset attempts to correct for any offset. If Tn is configured as 0.00 s, the I-component of the PID loop is disabled. Refer to "Analog Controller Outputs" on page 30.

Parameter 33

**Freq. controller**  
**Derivat.Tv 0.00s**

only **LSXR** Package  
with 'ANALOG' or 'PWM' setting

**Derivative-action time frequency controller****0.00 to 6.00 s**

The derivative-action time TV represents the D-component of the PID controller. The D-component of the controller output becomes effective with large variations of the offset, e.g. in case of load-shedding. The lower the derivative-action time is configured, the higher the controller reaction is. If TV is configured as 0.00 s, the D-component of the PID loop is disabled. Refer to "Analog Controller Outputs" on page 30.

**Voltage Controller**

The SPM-D11/**LSR** is provided with a three-step controller for voltages and does not contain the following screen. Moreover, only the screens for setting the three-step controller exist. Several controller output signals can be selected using the following screen with the SPM-D11/**LSRX**. Depending on the selected controller type, the following screens belonging to it appear.

Parameter 34

**V contr. type**  
**xxxxxxx**

**LSRX** Package only

**Voltage controller type****THREESTEP/ANALOG**

**THREESTEP:** The voltage controller operates as three-step controller and issues raise (V+) and lower (V-) pulses via the respective relays. Only one of the two controllers (the frequency or the voltage controller) can be used for relay output at a time.

**ANALOG.....**The voltage controller operates as continuous controller with an analog output signal (mA or V).

**Note:** The controller setting and the following screens are different, depending on the controller type selected here.

**Three-Position Controller (SPM-D11/**LSR** and SPM-D11/**LSRX**: Setting 'THREESTEP')**

Parameter 35

**Volt. controller**  
**ON**

**LSRX** Package:  
setting 'THREESTEP'

**Voltage controller****ON/OFF**

**ON** .....Generator voltage control is carried out. The generator voltage is controlled in various manners depending on the task (no load / isolated operation / synchronization). The following screens of this function are displayed.

**OFF** .....Control is not carried out, and the following screens of this function are not displayed.

Parameter 36

**Volt. controller**  
**Isol. oper. ON**

**LSRX** Package:  
setting 'THREESTEP'

**Voltage controller isolated mode****ON/OFF**

The setting of this screen has no influence on the load share control.

**ON** .....In isolated operation the voltage controller is enabled.

**OFF** .....In isolated operation the voltage controller is disabled.

Parameter 37

**Volt. controller**  
**Ramp = 00V/s**

**LSRX** Package:  
setting 'THREESTEP'

**Voltage controller set point ramp****1 to 99 V/s**

A change in set point is supplied to the controller via a ramp. The slope of the ramp is used to alter the rate at which the controller follows the set point value. The more rapidly the set point should change, the greater should be the value set here.



Parameter 38

**Volt. controller  
Dead band= 00,0V**

LSXR Package:  
setting 'THREESTEP' only

**Voltage controller insensitivity****[1] 0.1 to 15.V, [4] 0.5 to 60.0 V**

**No load/Isolated operation:** The measured generator voltage is controlled so that it does not deviate from the configured voltage by more than the value configured in this dead band setting while operating in a steady state.

**Synchronization:** The measured generator voltage is controlled so that the differential voltage does not exceed this dead band setting while operating in a steady state. The mains or busbar voltage is used as the set point value.

Parameter 39

**Volt. controller  
Time pulse>000ms**

LSXR Package:  
setting 'THREESTEP' only

**Minimum voltage controller ON period****20 to 250 ms**

The minimum ON period of the relay should be selected in such a manner that the downstream control element responds reliably to the pulse length that has been set here. The smallest possible time must be set in order to ensure optimum control behavior.

Parameter 40

**Volt. controller  
Gain Kp 00.0**

LSXR Package:  
setting 'THREESTEP' only

**Voltage controller gain factor****0.1 to 99.9**

The gain factor  $K_p$  influences the ON time of the relays. The gain factor  $K_p$  influences the ON time of the relays. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled resulting in longer ON time periods. The optimum setting depends on the behavior of the system. If the gain is too low, the control action becomes slow. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

## Analog Controller Outputs (SPM-D11/LSXR: Setting 'ANALOG')

Parameter 41

**V control output  
-----**

only LSXR Package  
with 'ANALOG' setting

**Controller output signal****see table**

The range of the analog output signal is adjusted here. To choose between a current signal in mA or a voltage signal in V, the appropriate jumpers must be connected to the output terminals. (see chapter Relay Outputs on page 16).

The following output signals are possible:

Type	Setting in above configuration screen	Jumper between terminal 11/12	Adjustment range	Adjustment range min.	Adjustment range max.
Current	+/-20mA (+/-10V)	no	+/-20mA	-20 mA	+20 mA
	+/-10mA (+/-5V)		+/-10mA	-10 mA	+10 mA
	0 to 10mA (0 to 5V)		0 to 10mA	0 mA	10 mA
	0 to 20mA (0 to 10V)		0 to 20mA	0 mA	20 mA
	4 to 20mA		4 to 20mA	4 mA	20 mA
	10 to 0mA (5 to 0V)		10 to 0mA	10 mA	0 mA
	20 to 0mA (10 to 0V)		20 to -0mA	20 mA	0 mA
	20 to 4mA		20 to 4mA	20 mA	4 mA
Voltage	+/-20mA (+/-10V)	yes	+/-10V	-10 Vdc	+10 Vdc
	+/-10mA (+/-5V)		+/-5V	-5 Vdc	+5 Vdc
	+/-3V		+/-3V	-3 Vdc	+3 Vdc
	+/-2.5V		+/-2,5V	-2,5Vdc	+2,5 Vdc
	+/-1V		+/-1V	-1 Vdc	+1 Vdc
	0 to 10mA (0 to 5V)		0-5V	0 Vdc	5 Vdc
	0.5V to 4.5V		0,5 to 4,5V	0,5 Vdc	4,5 Vdc
	0 to 20mA (0 to 10V)		0 to 10V	0 Vdc	10 Vdc
	10 to 0mA (5 to 0V)		5 to 0V	5 Vdc	0 Vdc
	4.5V to -0.5V		4,5 to 0,5V	4,5 Vdc	0,5 Vdc
	20 to 0mA (10 to 0V)		10 to 0V	10 Vdc	0 Vdc

Parameter 42

**V control output**  
**Init.state 000%**

only **LSXR** Package  
with 'ANALOG' setting

**Voltage controller - initial state****0 to 100%**

This parameter is the start point for the output signal when the frequency controller parameter is configured as OFF. The percentage value relates to the range between the minimum and maximum values that control unit can output (see below).

Parameter 43

**Volt. controller**  
**ON**

**LSXR** Package  
with 'ANALOG' setting

**Voltage controller****ON/OFF**

**ON** .....Generator voltage control is carried out. The generator voltage is controlled in various manners depending on the task (no load / isolated operation / synchronization). The following screens of this function are displayed.

**OFF** .....Control is not carried out, and the following screens of this function are not displayed.

Parameter 44

**Volt. controller**  
**Isol. oper. ON**

**LSXR** Package  
with 'ANALOG' setting

**Voltage controller isolated mode****ON/OFF**

The setting of this screen has no influence on the load share control.

**ON** .....In isolated operation the voltage controller is enabled.

**OFF** .....In isolated operation the voltage controller is disabled.

Parameter 45

**Volt. Controller**  
**Ramp = 00V/s**

**LSXR** Package  
with 'ANALOG' setting

**Voltage controller set point ramp****1 to 99 V/s**

A change in set point is supplied to the controller via a ramp. The slope of the ramp is used to alter the rate at which the controller follows the set point value. The more rapidly the set point should change, the greater should be the value set here.

Parameter 46

**V control output**  
**(max.) 000%**

only **LSXR** Package  
with 'ANALOG' setting

**Voltage controller maximum output****0 to 100 %**

Upper limit of the analog controller output.

Parameter 47

**V control output**  
**(min.) 000%**

only **LSXR** Package  
with 'ANALOG' setting

**Voltage controller minimum output****0 to 100 %**

Lower limit of the analog controller output.

Parameter 48

**Volt. controller**  
**Gain Kp 000**

only **LSXR** Package  
with 'ANALOG' setting

**Voltage controller P-gain****1 to 240**

The proportional-action coefficient  $K_P$  indicates the closed-loop control system gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The optimum setting depends on the behavior of the system. If the gain is too low, the control action becomes slow. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value. Refer to "Analog Controller Outputs" on page 30.

Parameter 49

**Volt. controller**  
**Reset Tn 00.0s**

only **LSXR** Package  
with 'ANALOG' setting

**Voltage controller reset time****0.0 to 60.0 s**

The reset time  $T_n$  represents the I-component of the PID controller. The reset time corrects for any offset (between set point and process variable) over time until the process variable and the set point are the same. This parameter defines how quickly the reset attempts to correct for any offset. If  $T_n$  is configured as 0.00 s, the I-component of the PID loop is disabled. Refer to "Analog Controller Outputs" on page 30.

Parameter 50	<b>Voltage controller - derivative-action time</b>	<b>0.00 to 6.00 s</b>
<div>Volt. controller Derivat.Tv=0.00s</div> <div>only LSXR Package with 'ANALOG' setting</div>	<p>The derivative-action time TV represents the D-component of the PID controller. The D-component of the controller output becomes effective with large variations of the offset, e.g. in case of load-shedding. The lower the derivative-action time is configured, the higher the controller reaction is. If TV is configured as 0.00 s, the D-component of the PID loop is disabled. Refer to "Analog Controller Outputs" on page 30.</p>	

Power Factor Control



**NOTE**  
Refer to the appendix Power Factor Definition on page 75 for this.

Parameter 51	<b>Power factor controller</b>	<b>ON/OFF</b>
<div>Pow. fact. control ON</div>	<p><b>ON</b>..... A load-independent control of the power <math>\phi</math> factor is carried out during mains/parallel operation. The power factor cannot be measured accurately and the controller is automatically locked to prevent instability when small currents (less than 5 % of the CT secondary rated current) are detected. The following screen masks of this option will be displayed.</p> <p><b>OFF</b>..... The frequency is not controlled, and the following screens of this option will not be displayed.</p>	
Parameter 52	<b>Power factor controller set point</b>	<b>i0.70 to 1.00 to c0.70</b>
<div>Pow. fact. control Set point = 0.00</div>	<p>While operating in a mains/parallel operation, the reactive load is controlled so that this preset power factor is maintained when the generator is in a steady state. The letters "i" stands for "inductive = lagging" (overexcited generator) and "c" for "capacitive = leading" (underexcited generator) reactive load. This parameter is only enabled when operating in mains/parallel.</p>	
Parameter 53	<b>Set point ramp of the power factor controller</b>	<b>0.01 to 0.30 /s</b>
<div>Pow. fact. control Ramp 0.00/s</div>	<p>The set point ramp determines how fast the power factor set point approaches its target value. The slope of the ramp is linear.</p>	

**NOTE**

Refer to the parameter settings for the voltage controller under Voltage Controller starting on page 48. The parameter settings performed for the voltage controller may be applied to the power factor controller as well.

**Three-Position Controller (SPM-D11/LSR and SPM-D11/LSXR: Setting 'THREESTEP')**

Parameter 54

**Power factor controller insensitivity****0.5 to 25.0 %**

<b>Pow. fact. control</b> <b>Dead band 00.0%</b>
-----------------------------------------------------

LSXR Package:  
setting 'THREESTEP' only

The control automatically calculates the amount of reactive load which corresponds to the power factor <sub>set point</sub>. In mains/parallel operation, the reactive load is controlled so that it does not deviate from the configured power factor set point by more than the value configured in this dead band (%) setting while operating in a steady state. The percentage value refers to the generator nominal power.

Parameter 55

**Power factor controller gain****0.1 to 99.9**

<b>Pow. fact. control</b> <b>Gain Kp=00.0</b>
--------------------------------------------------

LSXR Package:  
setting 'THREESTEP' only

The gain factor Kp influences the ON time of the relays. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled resulting in longer ON time periods. The optimum setting depends on the behavior of the system. If the gain is too low, the control action becomes slow. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

**Analog Controller (SPM-D11/LSXR: Setting 'ANALOG')**

Parameter 56

**Power factor controller gain****1 to 240**

<b>Pow. fact. control</b> <b>Gain Kp 000</b>
-------------------------------------------------

only LSXR Package  
with 'ANALOG' setting

The proportional-action coefficient KP indicates the closed-loop control system gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The optimum setting depends on the behavior of the system. If the gain is too low, the control action becomes slow. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value. Refer to "Analog Controller Outputs" on page 30.

Parameter 57

**Power factor controller reset time****0.0 to 60.0 s**

<b>Pow. fact. control</b> <b>Reset Tn 00.0s</b>
----------------------------------------------------

only LSXR Package  
with 'ANALOG' setting

The reset time Tn represents the I-component of the PID controller. The reset time corrects for any offset (between set point and process variable) over time until the process variable and the set point are the same. This parameter defines how quickly the reset attempts to correct for any offset. If Tn is configured as 0.00 s, the I-component of the PID loop is disabled. Refer to "Analog Controller Outputs" on page 30.

Parameter 58

**Power factor controller – derivative action time****0.00 to 6.00 s**

<b>Pow. fact. control</b> <b>Derivat.Tv 0.00s</b>
------------------------------------------------------

only LSXR Package  
with 'ANALOG' setting

The derivative-action time TV represents the D-component of the PID controller. The D-component of the controller output becomes effective with large variations of the offset, e.g. in case of load-shedding. The lower the derivative-action time is configured, the higher the controller reaction is. If TV is configured as 0.00 s, the D-component of the PID loop is disabled. Refer to "Analog Controller Outputs" on page 30.

## Real Power Controller

Parameter 59

Power controller ON
------------------------

### Real power controller

ON/OFF

**ON**..... During mains/parallel operation the real power is controlled to the pre-selected set point value. The following screens of this option are displayed.

**OFF**..... The power is not controlled, and the following screens of this option not displayed.

## Power Limitation

Parameter 60

Power controller P max.= 000 %
-----------------------------------

### Maximum power limitation (maximum demand)

10 to 120 %

If limiting control of the generator maximum real power is required, a value in percent referring to the generator rated power is set in this screen. The value "Pmax" limits only the set value of the real power controller and has no function in isolated operation.

Parameter 61

Power controller P min.= 000 %
-----------------------------------

### Minimum power limitation (minimum power)

0 to 50 %

If limiting control of the generator minimum real power is required, a value in percent referring to the generator rated power is set in this screen. The value "Pmin" limits only the set value of the real power controller and has no function in isolated operation.

## Part Load Lead

Parameter 62

Warm up load Set point = 000%
----------------------------------

### Limit value partial load

5 to 110 %

If the engine requires a warming-up period a lower fixed power set point value can be specified. The limit value of partial load refers to the generator rated power.

Parameter 63

Warm up load time 000s
---------------------------

### Period of partial load limit

0 to 600 s

If a warm up load set point value has been selected, the time period for this warm up is configured in this parameter. The time period for the partial load imitates at the closing of the generator circuit breaker. If a warm up period is not desired, enter "0" for this parameter.

## Shut Down

Parameter 64

Download and open GCB ON
-----------------------------

### Shut down

ON / OFF

**ON**..... The generator set will shut down if the input "enable GCB" is removed. Refer to the Shutdown section on page 27 for more information).

**OFF**..... If "enable GCB" is removed, the CB will not be opened in isolated operation. In parallel isolated operation the generator CB remains closed.

## Power Set point Value

**NOTE**

The SPM-D11 does not take the connection to the utility into consideration. This means that if the plant generates excess power, power will be exported to the utility. If the plant does not generate enough power to meet demand, then power will be imported from the utility. This power controller does not perform process control.

Parameter 65	<b>Set value 1 Real power controller</b>	<b>0 to 9,999 kW</b>
<div>Power controller</div> <div>P set1 = 0000kW</div>	Setting of the internal power set value 1 (Pset 1). If this set point is selected, this is the reference value for controlling the real power.	
Parameter 66	<b>Set value 2 Real power controller</b>	<b>0 to 9,999 kW</b>
<div>Power controller</div> <div>P set2 = 0000kW</div>	Setting of the internal power set value 2 (Pset2). If this set point is selected, this is the reference value for controlling the real power.	
Parameter 67	<b>External set value</b>	<b>ON/OFF</b>
<div>Power set point</div> <div>External ON</div>	Selection of the external power set point. If this set point is selected, the real power is controlled to the external power set reference value.	
Parameter 68	<b>External set point value: Range</b>	<b>0 to 20 / 4 to 20 mA</b>
<div>Analog input</div> <div>0..00mA</div>	<p>The analog reference signal input of the real power controller can be switched between 0 to 20 mA and 4 to 20 mA depending on the remote set point signal.</p> <p><b>0 to 20 mA</b>....Minimum value of the set point value: 0 mA; Maximum value: 20 mA.</p> <p><b>4 to 20 mA</b>....Minimum value of the set point value: 4 mA; Maximum value: 20 mA. Wire break monitoring is performed.</p>	
Parameter 69	<b>Scaling the minimum value</b>	<b>0 to 8,000 kW</b>
<div>External setp.</div> <div>0mA 0000kW</div>	The minimum value of the real power set point is defined here.	
Parameter 70	<b>Scaling the maximum value</b>	<b>0 to 8,000 kW</b>
<div>External setp.</div> <div>20mA 0000kW</div>	The maximum value of the real power set point is defined here.	
Parameter 71	<b>Display of the current set point value</b>	<b>0 to 8,000 kW</b>
<div>External setp.</div> <div>Value = 000kW</div>	This screen is not used to enter a value, but to display the current measured value, calculated into kW, of the analog input. This permits the mA signal to be validated even if the engine is stopped.	
Parameter 72	<b>Real power controller set point ramp</b>	<b>1 to 999 kW/s</b>
<div>Power controller</div> <div>Ramp 000 kW/s</div>	A change in set point is supplied to the controller via a ramp. The slope of the ramp is used to alter the rate at which the controller follows the set point value. The more rapidly the set point should change, the greater should be the value set here. This ramp will also be used to reduce the power with a Shutdown (refer to page 27).	

### Three-Position Controller (SPM-D11/LSR and SPM-D11/LSXR: Setting 'THREESTEP')

Parameter 73

Power controller
Dead band= 00.0%

LSXR Package:  
setting 'THREESTEP' only

#### Real power controller insensitivity

0.1 to 25.0 %

In mains/parallel operation the real power will be controlled so that it does not deviate from the configured power factor set point by more than the value configured in this dead band (%) setting while operating in a steady state. This percentage is based on the generator nominal power.

Parameter 74

Power controller
Gain Kp 00.0

LSXR Package:  
setting 'THREESTEP' only

#### Gain of real load controller

0.1 to 99.9

The gain factor Kp influences the ON time of the relays. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled resulting in longer ON time periods. The optimum setting depends on the behavior of the system. If the gain is too low, the control action becomes slow. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

Parameter 75

Power controller
Sens. red. *0.0

LSXR Package:  
setting 'THREESTEP' only

#### Sensitivity reduction of real power controller

1.0 to 9.9

If the controller does not issue an actuating pulse at least 5 seconds after reaching steady state condition, the sensitivity will be reduced by the entered factor.

**Example:** In case of a dead band of 2.5 % and a factor 2.0 the dead band will be increased to 5.0 % after 5 seconds. If the system deviation afterwards exceeds 5.0 %, the original dead band (2.5 %) of the controller will be set automatically. Using this entry, frequent unnecessary actuation processes can be avoided, thus extending the life of the actuating device.

### Analog controller (SPM-D11/LSXR: Setting 'ANALOG' & 'PWM')

Parameter 76

Power controller
Gain Kp 000

only LSXR Package  
with 'ANALOG' or 'PWM' setting

#### P gain of the real power controller

1 to 240

The proportional-action coefficient KP indicates the closed-loop control system gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The optimum setting depends on the behavior of the system. If the gain is too low, the control action becomes slow. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value. Refer to "Analog Controller Outputs" on page 30.

Parameter 77

Power controller
Reset Tn 00.0s

only LSXR Package  
with 'ANALOG' or 'PWM' setting

#### Reset time of the active load controller

0.0 to 60.0 s

The reset time Tn represents the I-component of the PID controller. The reset time corrects for any offset (between set point and process variable) over time until the process variable and the set point are the same. This parameter defines how quickly the reset attempts to correct for any offset. If Tn is configured as 0.00 s, the I-component of the PID loop is disabled. Refer to "Analog Controller Outputs" on page 30.

Parameter 78

Power controller
Derivat. Tv 0.00s

only LSXR Package  
with 'ANALOG' or 'PWM' setting

#### Derivative action time of the active load controller

0,00 to 6,00 s

The derivative-action time TV represents the D-component of the PID controller. The D-component of the controller output becomes effective with large variations of the offset, e.g. in case of load-shedding. The lower the derivative-action time is configured, the higher the controller reaction is. If TV is configured as 0.00 s, the D-component of the PID loop is disabled. Refer to "Analog Controller Outputs" on page 30.

Power Limit

The generator power is monitored for exceeding the configured threshold value. The excess is signaled with the relay "Power limit". As long as the power is below the threshold value, the relay is energized (the contact is closed). If the power has exceeded the threshold value for at least the configured delay, the relay contact will be opened. The relay contact will close, after the power is below the threshold value minus the configured hysteresis for at least a fixed delay of 1 second. Using this relay and external circuits it is possible to disconnect loads or activate further generators.



NOTE

This watchdog is not part of the generator protection functions. No message is displayed when the watchdog is triggered, only a relay is energized.  
The overload protection is intended for a generator that has been configured for equivalent operations (see page 63).

Parameter 79	Generator power monitoring	ON/OFF
<div>Gen.active-power Monitoring ON</div>	ON .....The generator real power is monitored. The following screens of this option are displayed. OFF .....There is no active power monitoring performed and the following screens of this option are not displayed.	
Parameter 80	Generator power monitoring threshold	0 to 150 %
<div>Power monitoring Threshold =000%</div>	The threshold relates to the rated power of the generator.	
Parameter 81	Generator power monitoring hysteresis	0 to 100 %
<div>Power monitoring Hysteresis =000%</div>	The hysteresis relates to the rated power of the generator. This value is how much below the threshold limit that the monitored power must drop for the controller to terminate the power threshold limit surpassed operations.	
Parameter 82	Generator power monitoring delay	0 to 600 s
<div>Power monitoring Delay time =000%</div>	To open the relay contact, the threshold has to be exceeded continuously for the time configured here.	



## Load/Var Sharing

Parameter 83

**Active power**  
**Load-share ON**

### Load sharing

ON/OFF

- ON**..... Real power is distributed among the generators operating in parallel. The generator outputs are distributed depending on the set values. The following screens of this function are displayed
- OFF**..... There is no load sharing control performed, and the following screens of this function are not displayed.

Parameter 84

**Act. load share**  
**Factor =00%**

### Load sharing reference variable

10 to 99 %

The higher the weighing factor is configured, the more influence the main control variable (frequency) has on the control. The lower the weighing factor is configured, the greater the influence of the secondary control variable (generator real power).

The value of the analog signal depends on the measured real power in relation to the rated power.

Therefore, there is the following relation between real power and analog signal:

0 to 4 V of the analog signal corresponds with 0 to 100 % of the rated power

Example for a rated power of 400 kW:

Currently measured power	Analog signal
100 kW	1 V
200 kW	2 V
400 kW	4 V

Parameter 85

**Reactive power**  
**Load-share ON**

### var sharing

ON/OFF

- ON**..... Re-active power is distributed among the several generators operating in parallel. The generator outputs are distributed depending on the set values. The following screens of this function are displayed:
- OFF**..... There is no var sharing control performed, and the following screens of this function are not displayed.

Parameter 86

**React. load share**  
**Factor =00%**

### var sharing reference variable

10 to 99 %

The higher the weighing factor is configured, the more influence the main control variable (voltage) has on the control. The lower the weighing factor is configured, the greater the influence of the secondary control variable (generator reactive power).

The value of the analog signal depends on the measured reactive power in relation to the rated power.

Therefore, there is the following relation between reactive power and analog signal:

0 to 5V of the analog signal corresponds with 85% of the capacitive rated power to 85% of the inductive rated power

Example for a rated power of 400 kW:

Actual reactive power (without display)	Analog signal	
-340 kW	0 V	85% of the rated power capacitive = negative reactive power
0 kW	2.5V	0% of the rated power no reactive power
+340 kW	5 V	85% of the rated power inductive = positive reactive power

# Synchronization



## Configure Synchronization



### CAUTION

Please consider that the unit does not have an internal rotating field monitoring. The unit assumes always a clockwise phase rotation direction of all voltage systems, which are measured.

A rotating field monitoring must be provided by the customer in order to avoid a CB closure with a counter-clockwise rotating field.

Parameter 87	Synchronization functions	ON/OFF
<div>Synchronizing functions ON</div>	<div>ON .....Frequency and voltage matching for the generator and busbar is performed and a close command is issued. The subsequent screens of this function are displayed.</div> <div>OFF .....No synchronization occurs, but no-load control functions are performed if necessary. No close command is issued. The subsequent screens of this function are not displayed.</div>	
Parameter 88	Max. permissible differential frequency (positive slip)	0.02 to 0.49 Hz
<div>Synchronization df max = 0.00Hz</div>	The prerequisite for initiating a close command that the differential frequency must be lower than the value configured here. This value specifies the upper frequency limit. A positive value indicates that the generator frequency is greater than the busbar frequency.	
Parameter 89	Max. permissible differential frequency (negative slip)	0.00 to 0.49 Hz
<div>Synchronization df min =-0.00Hz</div>	The prerequisite for initiating a close command that the differential frequency must be higher than the value configured here. This value specifies the lower frequency limit. A negative value indicates that the generator frequency is less than the busbar frequency.	
Parameter 90	Max. permissible differential voltage	[1] 1 to 20 V, [4] 1 to 60 V
<div>Synchronization dV max = 00V</div>	A close command will not be issued until the measured differential voltage of the generator and busbar falls below the value configured here.	
Parameter 91	Minimum pulse period of close relay	0.04 to 0.50 s
<div>Synchronization Brk.hold T&gt;0.00s</div>	The length of the close command pulse can be adjusted to the requirement of the subordinate switching circuit.	

Parameter 92

**Phase matching**  
**ON**

**Phase matching control****ON/OFF**

**ON**..... The synchronization is performed with phase matching control and the power circuit breaker closure is dependent upon the phase angle (refer to "Phase Matching Synchronization" on page 25). Only the parameters relating to phase matching are displayed.

**OFF**..... Synchronization is performed when the frequency and voltage differential are within the specified ranges. The circuit breaker is closed at the synchronous point (refer to "Synchronization with slip" on page 25). Only the parameters relating to slip synchronization are displayed.

Parameter 93

**Slip synchroniz.**  
**Max phase < 00°**

Phase matching control = OFF

**Max. perm. differential angle in case of phase-angle-zero-control****0 to 60°**

This configuration screen is displayed only if the phase matching control is disabled! A connect command is only issued when the phase angle differential is less than the value configured in this screen.

**Synchronization with slip** - When operating in the "slip synchronization" mode this phase angle may be set as the maximum value that a close breaker command may be issued. This is determined by the formula:

$$\Delta\phi = T_{\text{Close}} * 360^\circ * \Delta f$$

Example: If the frequency difference is 0.5Hz and the delay of the circuit breaker delay is 80ms the delta phi is determined as follows:

$$T_{\text{Close}} = 80\text{ms}, \Delta f = 0.5\text{Hz} \Rightarrow \Delta\phi = 0.08\text{s} * 360 * 0.5 = 14.4^\circ$$

As an example if the desired synchronization window is to be limited to a maximum of 10°, then the limit value of 10° would be entered here. If this parameter is not required, then the angle must be configured as 60°

**Synch-check** - In the operation mode "Synch-check" the phase angle differential must be less than the value configured here for the relay "Command: close CB" to be energized.

Parameter 94

**Slip synchroniz.**  
**TClose GCB=000ms**

Phase matching control = OFF

**Inherent delay of CB****40 to 300 ms**

This configuration screen is displayed only if the phase matching control is disabled! All circuit breakers have an inherent delay from the time the close command is issued until the circuit breaker contacts are closed. That time is configured in this screen. This permits the controller to issue the breaker closure command with enough lead-time so that the breaker contacts close at the synchronous point.

Parameter 95

**Phase matching**  
**Max phase < 00°**

Phase matching control = ON

**Max. permissible differential angle****0 to 60°**

This configuration screen is displayed only if the phase matching control is enabled! A connect command is only issued when the phase angle differential is less than the value configured in this screen.

Parameter 96

**Phase matching**  
**Dwell time 00.0s**

Phase matching control = ON

**Phase matching control breaker transition dwell time****0.2 to 10.0 s**

This configuration screen is displayed only if the phase matching control is enabled! Once the controller detects that the phase angle matching has been achieved, a timer is started. Only after the expiration of this dwell time is the connect command issued. If the controller detects that one of the synchronization parameters has left the required range, the dwell timer is reset.

Parameter 97	Phase matching control gain	1 to 36
<div>Phase matching Gain00</div> <div>Phase matching control = ON</div>	<p>This configuration screen only appears, if the phase matching control is configured ON!</p> <p>When phase matching control is enabled, this gain determines how much the output signal is changed depending on phase difference. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled resulting in longer ON time periods. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.</p> <p>Prior to setting the value for this gain, the frequency controller must be enabled and properly adjusted.</p>	
Parameter 98	Differential frequency for starting phase matching control	0.02 to 0.25 Hz
<div>Phase matching df start0.00Hz</div> <div>Phase matching control = ON</div>	<p>This configuration screen is displayed only if the phase matching control is enabled! The control enables phase matching when the generator and busbar/mains frequency differential falls below the value configured here.</p>	

Synchronization Time Monitoring

Parameter 99	Synchronization time monitoring	ON/OFF
<div>Sync.time contr. AlarmON</div>	<p><b>ON</b> .....The synchronization timer is enabled. When a synchronization operation is initiated, this timer starts to count down. If the timer expires prior to the synchronization being completed and the breaker closing, the warning message "Synchronization time" is displayed. In addition to the warning message the "Ready for operation" relay is de-energized and the synchronization operation is terminated. The alarm condition may be reset by pressing and holding the "Clear" pushbutton for at least 3 seconds or removing one of the required conditions for synchronization (e.g. de-energize terminal 3 "Release CB"). The subsequent screens of this function are displayed.</p> <p><b>OFF</b> .....The synchronization time is not monitored and the control will continue to attempt to synchronize until the circuit breaker is successfully closed or the synchronization it terminated. The subsequent screens of this function are not displayed.</p>	
Parameter 100	Final value for synchronization time monitoring	10 to 999 s
<div>Sync.time contr. Delay time000s</div>	<p>If the synchronization time monitoring has been enabled, the control will attempt to synchronize for up to the time period configured here.</p>	

# Dead Bus Start



If the busbar is in a voltage-free state (dead bus), a direct closing (dead bus start) of the generator circuit breaker (GCB) may be carried out.

Parameter 101	<div>Gen. circ.break. Dead bus op. ON</div>	<b>Dead bus start of power circuit breaker</b> <b>ON/OFF</b>
		<b>ON</b> ..... Enabling of the dead bus start function. To close the generator circuit breaker on to the voltage-free busbar additional conditions must be met [see chapter "Closing the CB Without Synchronization (Dead Bus Start)" starting on page 26]. The following screens of this function are displayed. <b>OFF</b> ..... Dead bus starts are not performed and the following screens of this function are not displayed.
Parameter 102	<div>Dead bus op. GCB df max = 0.00Hz</div>	<b>Maximum differential frequency for CB dead bus start</b> <b>0.05 to 5.00 Hz</b>
		The prerequisite for issuing the close command is that the generator frequency may not deviate from the rated frequency by more than this set value. Example: If the generator is rated at 60Hz and 5.00Hz is configured here, the circuit breaker will be issued a close command when the generator achieves 55Hz.
Parameter 103	<div>Dead bus op. GCB dV max = 00V</div>	<b>Maximum differential voltage for CB dead bus start</b> <b>[1] 1 to 20 V, [4] 1 to 60 V</b>
		The prerequisite for issuing the close command is that the generator voltage may not deviate from the rated voltage by more than this set value. Example: If the generator is rated at 460 Volts and 60V is configured here, the circuit breaker will be issued a close command when the generator achieves 400 Volts.

## Configure Monitoring



### Generator Reverse/Reduced Power Monitoring

Generator real power is monitored to ensure it does not fall below a preset limit. The watchdog assigned to this relay is at terminals 37/38. The relay contact is a N.O. contact. When operating in normal operations the relay is continuously energized. If the monitored values leave the configured range, the relay will de-energize, the contact will open, and the message "Reverse/reduced power" will be displayed. If the fault conditions exist for less than 1 second, the relay returns to normal operations. The fault message on the display may be cleared automatically or by pressing the "Clear" button (see chapter Auto Acknowledge Messages at page 65).

Parameter 104	Reverse/reduced load monitoring	ON/OFF
Reverse/min.pow. Monitoring ON	ON .....Monitoring of reverse or reduced generator real power is performed. The following screens of this function are displayed.	
	OFF .....There is no reverse or reduced power monitoring and the following screens of this function are not displayed	
Parameter 105	Reverse/reduced power monitoring threshold value	-99 to 99 %
Reverse/min.pow. Threshold = 00%	The threshold value refers to the configured rated power of the generator. <b>Reduced power monitoring:</b> A reduced power condition is detected if the measured real power drops below the (positive) limit value. <b>Reverse power monitoring:</b> A reverse power condition is detected if the measured real power drops below the (negative) limit value. A reverse power condition can only be detected if the current is at least 2% of the CT's rating. This must be considered when configuring the reverse power protection.	
Parameter 106	Delay of reverse/reduced load monitoring	0.1 to 99.9 s
Reverse/min.pow. Delay 00.0s	The generator real power must remain below the threshold value without interruption for at least the period of time specified in this screen for a fault condition to be recognized.	

Generator Overload Monitoring

Generator real power is monitored to ensure it does not exceed a preset limit. The watchdog assigned to this relay is at terminals 37/38. The relay contact is a N.O. contact. When operating in normal operations the relay is continuously energized. If the monitored values leave the configured range, the relay will de-energize, the contact will open, and the message "Gen. overload" will be displayed. If the fault conditions exist for less than 1 second, the relay returns to normal operations. The fault message on the display may be cleared automatically or by pressing the ""Clear" button (see chapter Auto Acknowledge Messages at page 65).

Parameter 107	Overload monitoring	ON / OFF
Gen. overload Monitoring ON	ON..... Monitoring of generator real power for overload is performed. The following screens of this function are displayed.	
	OFF..... There is no real power overload monitoring and the following screens of this function are not displayed.	
Parameter 108	Generator overload threshold	0 to 150 %
Gen. overload Threshold =000%	The threshold value refers to the configured generator rated power.	
Parameter 109	Generator overload monitoring delay	0 to 99 s
Gen. overload Delay time = 00s	The generator real power must remain above the threshold value without interruption for at least the period of time specified in this screen for a fault condition to be recognized. If 0 seconds is configured here, the delay time is approximately 80ms.	

## Generator Frequency Monitoring

Generator frequency is monitored to ensure it does not exceed or fall below the threshold value. The watchdog assigned to this relay is at terminals 43/44. The relay contact is a N.O. contact. When operating in normal operations the relay is continuously energized. If the monitored values leave the configured range, the relay will de-energize, the contact will open, and the message "Gen. overfreq." or "Gen. underfreq." will be displayed. If the fault conditions exist for less than 1 second, the relay returns to normal operations. The fault message on the display may be cleared automatically or by pressing the "Clear" button (see chapter Auto Acknowledge Messages at page 65).

Parameter 110	<b>Generator frequency monitoring</b>	<b>ON/OFF</b>
<b>Gen. frequency-Monitoring ON</b>	<b>ON</b> .....Generator frequency monitoring is enabled. The generator frequency is monitored for overfrequency and underfrequency. The following screens of this function are displayed. <b>OFF</b> .....There is no frequency monitoring, and the following screens of this function are not displayed.	
Parameter 111	<b>Threshold value: Generator overfrequency</b>	<b>40.0 to 70.0 Hz</b>
<b>Gen. overfreq. f &gt; 00.00Hz</b>	If the value of the generator frequency exceeds the value set here, an overfrequency alarm is issued.	
Parameter 112	<b>Generator overfrequency threshold delay</b>	<b>0.04 to 9.98 s</b>
<b>Gen. overfreq. Delay time=0.00s</b>	In order to initiate an overfrequency alarm, the measured frequency must exceed and remain above the configured threshold without interruption for at least the time specified in this screen.	
Parameter 113	<b>Threshold value: Generator underfrequency</b>	<b>40.0 to 70.0 Hz</b>
<b>Gen. underfreq. f &lt; 00,00Hz</b>	If the value of the generator frequency falls below the value set here, an underfrequency alarm is issued.	
Parameter 114	<b>Generator underfrequency threshold delay</b>	<b>0.04 to 9.98 s</b>
<b>Gen. underfreq. Delay time=0.00s</b>	In order to initiate an underfrequency alarm, the measured frequency must fall below and remain below the configured threshold without interruption for at least the time specified in this screen.	



## Generator Voltage Monitoring

The line voltages  $V_{L1}/V_{L2}$  of the generator are monitored to ensure they do not exceed or fall below the threshold values. The watchdog assigned to this relay is at terminals 41/42. The relay contact is a N.O. contact. When operating in normal operations the relay is continuously energized. If the monitored values leave the configured range, the relay will de-energize, the contact will open, and the message "Gen. overvoltage" or "Gen. undervoltage" will be displayed. If the fault conditions exist for less than 1 second, the relay returns to normal operations. The fault message on the display may be cleared automatically or by pressing the "Clear" button (see chapter Auto Acknowledge Messages at page 65).

Parameter 115	<b>Generator voltage monitoring</b>	<b>ON / OFF</b>
<b>Gen.voltage-Monitoring ON</b>	<b>ON</b> ..... The generator voltage monitoring is enabled. The generator voltage is monitored with regard to overvoltage and undervoltage. The following screens of this function are displayed. <b>OFF</b> ..... No overvoltage or undervoltage monitoring is performed and the following screens of this function are not displayed.	
Parameter 116	<b>Threshold value: Gen. overvoltage</b>	<b>[1] 20 to 150 V; [4] 20 to 520 V</b>
<b>Gen. overvoltage U &gt; 000V</b>	If the value of the generator voltage exceeds the value set here, an overvoltage alarm is issued.	
Parameter 117	<b>Generator overvoltage threshold delay</b>	<b>0.04 to 9.98 s</b>
<b>Gen. overvoltage Delay time=0.00s</b>	In order to initiate an overvoltage alarm, the measured voltage must exceed and remain above the configured threshold without interruption for at least the time specified in this screen.	
Parameter 118	<b>Threshold value: Gen. undervoltage</b>	<b>[1] 20 to 150 V; [4] 20 to 520 V</b>
<b>Gen. undervoltage U &lt; 000V</b>	If the value of the generator voltage falls below the value set here, an undervoltage alarm is issued.	
Parameter 119	<b>Generator undervoltage threshold delay</b>	<b>0,04 to 9,98 s</b>
<b>Gen. undervoltage Delay time=0.00s</b>	In order to initiate an undervoltage alarm, the measured voltage must fall below and remain below the configured threshold without interruption for at least the time specified in this screen.	

## Auto Acknowledge Messages

Parameter 120	<b>Messages auto acknowledgment</b>	<b>EIN/AUS</b>
<b>Auto-acknowledge messages ON</b>	<b>ON</b> ..... When fault conditions are no longer detected and the clear message delay time has expired, the corresponding message is automatically deleted. <b>OFF</b> ..... When fault conditions are no longer detected and the corresponding message continues to be displayed. Pressing the "Clear" button for at least 3 seconds will clear the fault message. The following screen is not displayed.	
Parameter 121	<b>Clear messages delay</b>	<b>1 to 99 s</b>
<b>Acknowledge Message aft. 00s</b>	This screen only appears if the screen "Messages auto-acknowledgement" is set to ON. Clearing the messages occurs after the specified time.	

## Password Configuration



### NOTE

Once the code level is entered, access to the configuration menus will be allowed for two hours or until another password is entered into the control. If a user needs to exit a code level then code level CL0 should be entered. This will block any configuration of the control. A user may return to CL0 by allowing the entered password to expire after two hours or by changing any one digit on the random number generated on the password screen and entering it into the unit.

Parameter 122	Code level 1 (Customer)	0000 to 9999
<div>Define level 1 code0000</div>	<p>This parameter is only accessible with code level 2 rights. After the password has been set for this parameter, only the personnel who are assigned this password will have access rights to this code level. When the CL1 (Customer) password is entered, only select parameters may be accessed. Refer to page 40 for more information to password protection.</p> <p>The default setting for this code level is</p>	CL1 = 0 0 0 1
Parameter 123	Code level 2 (Commissioner)	0000 to 9999
<div>Define level 2 code0000</div>	<p>This parameter is only accessible with code level 2 rights. After the password has been set for this parameter, only the personnel who are assigned this password will have access rights to this code level. When the CS2 (Commissioner) password is entered, all parameters may be accessed. Refer to page 40 for more information to password protection.</p> <p>The default setting for this code level is</p>	CL2 = 0 0 0 2

## Chapter 7. Commissioning



### **DANGER - HIGH VOLTAGE**

When commissioning the control, please observe all safety rules that apply to the handling of live equipment. Ensure that you know how to provide first aid in the event of an uncontrolled release of energy and that you know where the first aid kit and the nearest telephone are. Never touch any live components of the system or on the back of the system.

**LIFE THREATENING**



### **WARNING**

Only a qualified technician may commission unit. The "EMERGENCY-STOP" function must be operational prior to commissioning of the system, and must not depend on the unit for its operation.



### **CAUTION**

Prior to commissioning ensure that all measuring devices are connected in correct phase sequence. The connect command for the unit circuit breaker must be disconnected at the unit circuit breaker. The field rotation must be monitored for proper rotation. Any absence of or incorrect connection of voltage measuring devices or other signals may lead to malfunctions and damage the unit, the engine, and/or components connected to the unit!



### **CAUTION**

Please consider that the unit does not have an internal rotating field monitoring.

The unit assumes always a clockwise phase rotation direction of all voltage systems, which are measured.

A rotating field monitoring must be provided by the customer in order to avoid a CB closure with a counter-clockwise rotating field.

### **Procedure**

1. Disconnect the close command connections at the power circuit breaker.
2. After checking the unit wiring and ensuring all voltage-measuring devices are phased correctly, apply the control system voltage (i.e. 12/24 Vdc).
3. Before accessing the configuration mode, make sure to reset the discrete input "configuration locked" (connect to 0 V or disconnect). By simultaneously pressing the two push buttons "Digit↑" and "Cursor→", the configuration mode is accessed. After entering the access code number, the unit may be configured according to the application requirements (see the chapter regarding the parameters). The "automatic" LED will darken when in the configuration mode.
4. Set all parameters according to Chapter Configuration on page 39. The setting limits can be either read from the description in the controller display or from the list of parameters at the end of the operating manual.
5. After applying the measuring variables, the unit will display the measured values. These values should be confirmed with a calibrated measuring instrument. **It is possible to issue an asynchronous close command in case of an active dead bus start if a measuring voltage has been wired incorrectly or not at all!**

6. Verify the status of all control and auxiliary inputs and the appropriate LEDs on the display of the control are illuminated. Verify the status of all control and auxiliary outputs as well as the settings of the controller outputs.
7. Synchronizing the power circuit breaker:
  - a) Disconnect the breaker operation connection to the power circuit breaker;
  - b) The voltage to which the system has to synchronize must be within the permissible range
  - c) The signal "Enable CB" must be enabled.
  - e) When the generator voltage exceeds 50 % of the configured rated value, the frequency controller starts to operate. Set the parameters of the controller in such a way that the set point value is controlled in an optimum manner.
  - f) Prior to the automatic closing of the circuit breaker ensure that all measuring inputs are wired and applied correctly. Upon reaching the synchronous point check whether all conditions for synchronizing have been met. This test is best done using a differential voltage meter direct at the power circuit breaker.
8. Dead bus start
  - a) Disconnect the breaker operation connection to the power circuit breaker.
  - b) Check all conditions and measuring voltages and test the close command.
  - c) Allow the generator circuit breaker to close automatically.
9. After successful closing of the power circuit breaker the LED "Gen CB - ON" must illuminate.

# Appendix A. Dimensions




Figure 7-1: Dimensions

## Appendix B.

### Technical Data

<b>Measuring values, voltage</b> -----	
- Measuring voltage	Rated value ( $V_{\text{rated}}$ ) $\sim/\Delta$ ..... [1] 66/115 Vac [4] 230/400 Vac
	Maximum value $V_{\text{Ph-Ph}}$ (UL/cUL) ..... [1] max. 150 Vac [4] max. 300 Vac
	Rated voltage $V_{\text{Ph-ground}}$ ..... [1] 150 Vac [4] 300 Vac
	Rated surge voltage ..... [1] 2.5 kV [4] 4.0 kV
- Measuring frequency	..... 40.0 to 70.0 Hz
- Accuracy	..... Class 1
- Linear measuring range up to	..... $1.3 \times V_N$
- Input resistance	..... [1] 0.21 M $\Omega$ , or [4] 0.696 M $\Omega$
- Maximum power consumption per path	..... 0.15 W
<b>Measuring values, current</b> ----- <b>isolated</b>	
- Measuring current	..... [1] ..1 A, or [5] ..5 A
- Accuracy	..... Class 1
- Linear measuring range up to	..... $3.0 \times I_N$
- Maximum power consumption per path	..... < 0.15 VA
- Rated short-time current (1 s)	..... [1] $50.0 \times I_N$ , or [5] $10.0 \times I_N$
<b>Ambient variables (Attention! Please observe actual ratings on data plate!)</b> -----	
- Power supply ( $V_{\text{aux}}$ )	..... 24 Vdc (18 to 32 Vdc)
- <i>or alternatively</i>	..... 12/24 Vdc (9.5 to 32 Vdc)
- Intrinsic consumption	..... max. 12 W
- Ambient temperature	..... -20 to 70 °C
- Ambient humidity	..... 95 %, not condensing
<b>Discrete inputs (Attention! Please observe actual ratings on data plate!)</b> ----- <b>isolated</b>	
- Input range ( $V_{\text{Cont, dig. input}}$ )	..... 18 to 250 Vac/dc
- <i>or alternatively</i>	..... 12/24 Vdc
- Input resistance	..... approx. 68 k $\Omega$
- <i>or alternatively</i>	..... approx. 6.8 k $\Omega$
<b>Relay outputs</b> ----- <b>isolated</b>	
- Make contact	..... potential free
- Contact material	..... AgCdO
- General purpose (GP) ( $V_{\text{Cont, relay output}}$ )	
AC	..... 2.00 Aac@250 Vac
DC	..... 2.00 Adc@24 Vdc 0.36 Adc@125 Vdc 0.18 Adc@250 Vdc
- Pilot duty (PD) ( $V_{\text{Cont, relay output}}$ )	
AC	.....
DC	..... 1.00 Adc@24 Vdc 0.22 Adc@125 Vdc 0.10 Adc@250 Vdc

<b>Analog inputs</b>	-----	<b>freely scaleable</b>
- Resolution	.....	10 Bit
- 0/4 to 20 mA input	.....	load 250 $\Omega$
<b>Analog outputs</b>	-----	<b>freely scaleable</b>
- Resolution	.....	12 Bit
- 0/4 to 20 mA	.....	external load max. 500 $\Omega$
- 0 to 10 Vdc	.....	internal source resistance 500 $\Omega$
- PWM signal	.....	max. 10 Vdc, approx. 500 Hz
<b>Load sharing</b>	-----	
- Voltage	.....	0 to 4 Vdc
- Resistance	.....	approx. 5 k $\Omega$
<b>Housing</b>	-----	
- Type	.....	APRANORM DIN 43 700
- Dimensions (W $\times$ H $\times$ D)	.....	144 $\times$ 72 $\times$ 122 mm
- Front cutout (W $\times$ H)	.....	138 [+1.0] $\times$ 67 [+0.7] mm
- Wiring	.....	Screw-type terminals depending on plug connector 1.5 mm <sup>2</sup> or 2.5 mm <sup>2</sup>
- Recommended tightening torque	.....	0.4 Nm or 0.5 Nm use 60/75 °C copper wire only use class 1 wire only or equivalent
- Weight	.....	approx. 800 g
<b>Protection</b>	-----	
- Protection system	.....	IP42 from front for proper installation IP54 from front with gasket (gasket: P/N 8923-1037) IP21 from back
- Front foil	.....	insulating surface
- EMV test (CE)	.....	tested according to applicable EN guidelines
Listings		CE marking, UL listing for ordinary locations UL/cUL listed, Ordinary Locations, File No.: E231544

# Appendix C.

## List of Parameters

Product number P/N \_\_\_\_\_ Rev \_\_\_\_\_

Version SPM-D11 \_\_\_\_\_

Project \_\_\_\_\_

Serial number S/N \_\_\_\_\_ Date \_\_\_\_\_

Option	Parameter 100/400V; 1/5 A	Adjustment range	Standard setting	Customer settings
--------	------------------------------	------------------	---------------------	-------------------

### CONFIGURE GENERAL PARAMETERS

SPRACHE/LANGUAGE	german/english	english	<input type="checkbox"/> G <input type="checkbox"/> E	<input type="checkbox"/> G <input type="checkbox"/> E
Software version		6.3xxx		
Enter code	0000 to 9.999	XXXX		
Password Protection	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
Direct para.	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N

### CONFIGURE BASIC SETTINGS

Rated Frequency fn	48.0 to 62.0 Hz	50.0 Hz		
Generator freq. Set point	48.0 to 62.0 Hz	50.0 Hz		
Gen. voltage secondary	[1] 50 to 125 V, [4] 50 to 440 V	400 V		
Mains voltage secondary	[1] 50 to 125 V, [4] 50 to 440 V	400 V		
Gen. voltage primary	0.1 to 65.0 kV	0.4 kV		
Mains voltage primary	0.1 to 65.0 kV	0.4 kV		
Rated voltage Vn	[1] 50 to 125 V, [4] 70 to 420 V	400 V		
Gen. voltage Set point	[1] 50 to 125 V, [4] 50 to 440 V	400 V		
Current transf. Generator	10 to 9,999/x A	1000/x A		
Connection type Gen.	1W/1W2	1W2	<input type="checkbox"/> 1W <input type="checkbox"/> 1W2	<input type="checkbox"/> 1W <input type="checkbox"/> 1W2
Angle adjustment Gen. Curr	-180° to 180°	000		
Rated power Gen.	[1] 100 to 9,999 kW [4] 5 to 9,999 kW	100 kW		

### CONFIGURE CONTROLLER

Automatic idle - Running	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
Terminal 6	Release control/Set point power	Release control	<input type="checkbox"/> RC <input type="checkbox"/> SP	<input type="checkbox"/> RC <input type="checkbox"/> SP
f control type	ANALOG/PWM	ANALOG		
Freq. controller	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
Freq. controller Isol. oper.	ON/OFF	AUS	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
Freq. controller Ramp.	0.1 to 99.9 Hz/s	5.0 Hz/s		
Freq. controller Dead band	0.02 to 1.00 Hz	0.10 Hz		
Freq. controller Time pulse	10 to 250 ms	80 ms		
Freq. controller Gain Kp	0.1 to 99.9	15.0		
f control output	see table	+/-20 mA (+/-10 V)		
f control output Level PWM	3.0 to 10.0 V	10.0 V		
PWM-signal Logic	positive/negative	positive		
f control output Init.state	0 to 100 %	50 %		
f control output (max.)	0 to 100 %	100 %		
f control output (min.)	0 to 100 %	0 %		
Freq. controller Gain Kp	1 to 240	15		
Freq. controller Reset Tn	0.0 to 60.0 s	2.5 s		
Freq. controller Derivat.Tv	0.00 to 6.00 s	0.00 s		



Option	Parameter 100/400V; 1/5 A	Adjustment range	Standard setting	Customer settings	
	V contr. type	THREESTEP/ANALOG	ANALOG	<input type="checkbox"/> T <input type="checkbox"/> A	<input type="checkbox"/> T <input type="checkbox"/> A
	Volt. controller	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Volt. controller Isol. oper.	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Volt. controller Ramp	1 to 99 V/s	25 V/s		
	Volt. controller Dead band	[1] 0.1 to 15.V, [4] 0.5 to 60.0 V	2.0 V		
	Volt. controller Time pulse>	20 to 250 ms	80 ms		
	Volt. controller Gain Kp	0.1 to 99.9	15.0		
	V control output	see table	+/-20 mA (+/-10 V)		
	V control output Init.state	0 to 100 %	50 %		
	V control output (max.)	0 to 100 %	100 %		
	V control output (min.)	0 to 100 %	0 %		
	Volt. controller Gain Kp	1 to 240	15		
	Volt. controller Reset Tn	0.0 to 60.0 s	2.5 s		
	Volt. controller Derivat.Tv	0.00 to 6.00 s	0.00 s		
	Pow.fact.control	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Pow.fact.control Set point	i0.70 to 1.00 to c0.70	1.00		
	Pow.fact.control Ramp	0.01 to 0.30 /s	0.01 /s		
	Pow.fact.control Dead band	0.5 to 25.00 %	2.5 %		
	Pow.fact.control Gain Kp	0.1 to 99.9	15.0		
	Pow.fact.control Gain Kp	1 to 240	15		
	Pow.fact.control Reset Tn	0.0 to 60.0 s	2.5 s		
	Pow.fact.control Derivat.Tv	0.00 to 6.00 s	0.00 s		
	Power controller	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Power controller P max	10 to 120 %	100 %		
	Power controller P min	0 to 50 %	0 %		
	Warm up load Set point	5 to 100 %	20 %		
	Warm up load time	0 to 600 s	15 s		
	Download and open GCB	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Power controller P set1 =	0 to 9,999 kW	300 kW		
	Power controller P set2 =	0 to 9,999 kW	500 kW		
	Power set point External	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Analog input	0 to 20 / 4 to 20 mA	0 to 20 mA		
	External setp. 0mA, 4mA	0 to 9,999 kW	0 kW		
	External setp. 20mA	0 to 9,999 kW	500 kW		
	Power controller Ramp	1 to 999 kW/s	50 kW/s		
	Power controller Dead band=	0.1 to 25.0 %	2.5 %		
	Power controller Gain Kp	0.1 to 99.9	15.0		
	Power controller Sens.red.	1.0 to 9.9	2.0		
	Power controller Gain Kp	1 to 240	15		
	Power controller Reset Tn	0.0 to 60.0 s	2.5 s		
	Power controller Derivat.Tv	0.00 to 6.00 s	0.00 s		
	Gen.active-power Monitoring	ON/AUS	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Power monitoring threshold	0 to 150 %	80%		
	Power monitoring hysteresis	0 to 100 %	20 %		
	Power monitoring delay time	0 to 60 s	10 s		
	Active power Load-share	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Act. load share Factor	10 to 99 %	50 %		
	Reactive power Load-share	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	React.load share Factor	10 to 99 %	50 %		

Option	Parameter 100/400V; 1/5 A	Adjustment range	Standard setting	Customer settings	
CONFIGURE SYNCHRONIZATION					
	Synchronizing functions	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Synchronization df max	0.02 to 0.49 Hz	0.18 Hz		
	Synchronization df min	0.00 to -0.49 Hz	-0.10 Hz		
	Synchronization dV max	[1] 1 to 20 V; [4] 1 to 60 V	24 V		
	Synchronization Brk.hold T>	0.04 to 0.50 s	0.20 s		
	Phase matching	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Phase matching Max phase <	0 to 60°	7 °		
	Slip synchroniz. TClose GCB	40 to 300 ms	80 ms		
	Slip synchroniz.Max phase <	0 to 60 °	7 °		
	Phase matching Dwell time	0.2 to 10.0 s	10.0 s		
	Phase matching Gain	1 to 36	2		
	Phase matching df start	0.02 to 0.25 Hz	0.20 Hz		
CONFIGURE SYNCHRONIZATION TIME MONITORING					
	Sync.time contr.	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Sync.time contr. Delay time	10 to 999 s	120 s		
CONFIGURE DEAD BUS START					
	Gen. circ.break.Gen.schalte	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Dead bus op. GCB df max	0.05 to 5.00 Hz	0.25 Hz		
	Dead bus op. GCB dV max	[1] 1 to 20 V; [4] 1 to 60 V	40 V		
CONFIGURE MONITORING					
	Reverse/min.pow. Monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Reverse/min.pow. Threshold	-99 to 99 %	-20 %		
	Reverse/min.pow. Delay	0.1 to 99.9 s	1.0 s		
	Gen. overload Monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Gen. overload Threshold.	0 to 150 %	120 %		
	Gen. overload Delay time	0 to 99 s	20 s		
	Gen.frequency- Monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Gen. overfreq. f >	40.0 to 70.0 Hz	55.0 Hz		
	Gen. overfreq. Delay time	0.04 to 9.98 s	3.00 s		
	Gen. underfreq. f <	40.0 to 70.0 Hz	45.0 Hz		
	Gen. underfreq. Delay time	0.04 to 9.98 s	3.00 s		
	Gen.voltage- Monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Gen. overvoltage U >	[1] 20 to 150 V; [4] 20 to 520 V	460 V		
	Gen. overvoltage Delay time	0.04 to 9.98 s	3.00 s		
	Gen. undervoltage U <	[1] 20 to 150 V; [4] 20 to -520 V	340V		
	Gen. undervoltage Delay time	0.04 to 9.98 s	3.00 s		
	Auto-acknowledge Messages	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Acknowledge Message aft	1 to 99 s	1 s		
CONFIGURE PASSWORD					
	Define level 1 code	0000 to 9999	0001		
	Define level 2 code	0000 to 9999	0002		

## Appendix D.

# Power Factor Definition

The phasor diagram is used from the generator's view. This defines the following definitions.

Power Factor is defined as a ratio of the real power to apparent power. In a purely resistive circuit, the voltage and current waveforms are in step resulting in a ratio or power factor of 1.00 (often referred to as unity). In an inductive circuit the current lags behind the voltage waveform resulting in usable power (real power) and unusable power (reactive power). This results in a positive ratio or lagging power factor (i.e. 0.85lagging). In a capacitive circuit the current waveform leads the voltage waveform resulting in usable power (real power) and unusable power (reactive power). This results in a negative ratio or a leading power factor (i.e. 0.85leading).

Inductive: Electrical load whose current waveform lags the voltage waveform thus having a lagging power factor. Some inductive loads such as electric motors have a large startup current requirement resulting in lagging power factors.	Capacitive: Electrical load whose current waveform leads the voltage waveform thus having a leading power factor. Some capacitive loads such as capacitor banks or buried cable result in leading power factors.
-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Different power factor displays at the unit:

i0.91 (inductive) lg.91 (lagging)	c0.93 (capacitive) ld.93 (leading)
--------------------------------------	---------------------------------------

Reactive power display at the unit:

70 kvar (positive)	-60 kvar (negative)
--------------------	---------------------

Output at the interface:

+	-
---	---

In relation to the voltage, the current is

lagging	leading
---------	---------


The generator is

over excited	under excited
--------------	---------------

Control: If the control unit is equipped with a power factor controller

A voltage lower "-" signal is output as long as the measured value is "more inductive" than the reference set point Example: measured = i0.91; set point = i0.95	A voltage raise "+" signal is output as long as the measured value is "more capacitive" than the reference set point Example: measured = c0.91; set point = c0.95
---------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------

Phasor diagram:



## Appendix E. Service Options

### Product Service Options



The following factory options are available for servicing Woodward equipment, based on the standard Woodward Product and Service Warranty (5-01-1205) that is in effect at the time the product is purchased from Woodward or the service is performed. If you are experiencing problems with installation or unsatisfactory performance of an installed system, the following options are available:

- Consult the troubleshooting guide in the manual.
- Contact Woodward technical assistance (see "How to Contact Woodward" later in this chapter) and discuss your problem. In most cases, your problem can be resolved over the phone. If not, you can select which course of action you wish to pursue based on the available services listed in this section.

### Returning Equipment for Repair



If a control (or any part of an electronic control) is to be returned to Woodward for repair, please contact Woodward in advance to obtain a Return Authorization Number. When shipping the control(s), attach a tag with the following information:

- name and location where the control is installed
- name and phone number of contact person
- complete Woodward part numbers (P/N) and serial number (S/N)
- description of the problem
- instructions describing the desired repair



#### CAUTION

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

## Packing a Control

Use the following materials when returning a complete control:

- protective caps on any connectors
- antistatic protective bags on all electronic modules
- packing materials that will not damage the surface of the control
- at least 100 mm (4 inches) of tightly packed, industry-approved packing material
- a packing carton with double walls
- a strong tape around the outside of the carton for increased strength

## Return Authorization Number RAN

When returning equipment to Woodward, please telephone and ask for the Customer Service Department in Stuttgart [+49 (0) 711-789 54-0]. They will help expedite the processing of your order through our distributors or local service facility. To expedite the repair process, contact Woodward in advance to obtain a Return Authorization Number, and arrange for issue of a purchase order for the control(s) to be repaired. No work can be started until a purchase order is received.



### NOTE

We highly recommend that you make arrangement in advance for return shipments. Contact a Woodward customer service representative at +49 (0) 711-789 54-0 for instructions and for a Return Authorization Number.

## Replacement Parts



When ordering replacement parts for controls, include the following information:

- the part numbers P/N (XXXX-XXX) that is on the enclosure nameplate
- the unit serial number S/N, which is also on the nameplate

# How to contact Woodward



Please contact following address if you have questions or if you want to send a product for repair:

Woodward GmbH  
Handwerkstrasse 29  
70565 Stuttgart - Germany

Phone: +49 (0) 711-789 54-0 (8.00 - 16.30 German time)  
Fax: +49 (0) 711-789 54-100  
e-mail: stgt-info@woodward.com

For assistance outside Germany, call one of the following international Woodward facilities to obtain the address and phone number of the facility nearest your location where you will be able to get information and service.

Facility	Phone number
USA	+1 (970) 482 5811
India	+91 (129) 409 7100
Brazil	+55 (19) 3708 4800
Japan	+81 (476) 93 4661
The Netherlands	+31 (23) 566 1111

You can also contact the Woodward Customer Service Department or consult our worldwide directory on Woodward’s website ([www.woodward.com](http://www.woodward.com)) for the name of your nearest Woodward distributor or service facility.  
[For worldwide directory information, go to [www.woodward.com/ic/locations](http://www.woodward.com/ic/locations).]

## Engineering Services



Woodward Industrial Controls Engineering Services offers the following after-sales support for Woodward products. For these services, you can contact us by telephone, by e-mail, or through the Woodward website.

- Technical support
- Product training
- Field service during commissioning

**Technical Support** is available through our many worldwide locations, through our authorized distributors, or through GE Global Controls Services, depending on the product. This service can assist you with technical questions or problem solving during normal business hours. Emergency assistance is also available during non-business hours by phoning our toll-free number and stating the urgency of your problem. For technical engineering support, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference technical support.

**Product Training** is available on-site from several of our worldwide facilities, at your location, or from GE Global Controls Services, depending on the product. This training, conducted by experienced personnel, will assure that you will be able to maintain system reliability and availability. For information concerning training, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference *customer training*.

**Field Service** engineering on-site support is available, depending on the product and location, from our facility in Colorado, or from one of many worldwide Woodward offices or authorized distributors. Field engineers are experienced on both Woodward products as well as on much of the non-Woodward equipment with which our products interface. For field service engineering assistance, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference *field service*.



Technical Assistance



If you need to telephone for technical assistance, you will need to provide the following information. Please write it down here before phoning:

Contact

Your company \_\_\_\_\_

Your name \_\_\_\_\_

Phone number \_\_\_\_\_

Fax number \_\_\_\_\_

Control (see name plate)

Unit no. and Revision:    P/N: \_\_\_\_\_    REV: \_\_\_\_\_

Control type                      SPM-D11 \_\_\_\_\_

Serial number                      S/N \_\_\_\_\_

Description of your problem

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Please be sure you have a list of all parameters available.

We appreciate your comments about the content of our publications.

Please send comments to: [stgt-documentation@woodward.com](mailto:stgt-documentation@woodward.com)

Please include the manual number from the front cover of this publication.



**Woodward GmbH**

Handwerkstrasse 29 - 70565 Stuttgart - Germany  
Telefon +49 (0) 711-789 54-0 • Fax +49 (0) 711-789 54-100  
[stgt-info@woodward.com](mailto:stgt-info@woodward.com)

**Homepage**

<http://www.woodward.com/power>

Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.

Complete address/phone/fax/e-mail information  
for all locations is available on our website ([www.woodward.com](http://www.woodward.com)).

2011/6/Stuttgart