

37302



Option SC02
IKD Coupling

Functional Description
GCP-30 from Software Version 3.4000

Manual 37302

**WARNING**

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment. Practice all plant and safety instructions and precautions. Failure to follow instructions can cause personal injury and/or property damage.

The engine, turbine, or other type of prime mover should be equipped with an overspeed (overtemperature, or overpressure, where applicable) shutdown device(s), that operates totally independently of the prime mover control device(s) to protect against runaway or damage to the engine, turbine, or other type of prime mover with possible personal injury or loss of life should the mechanical-hydraulic governor(s) or electric control(s), the actuator(s), fuel control(s), the driving mechanism(s), the linkage(s), or the controlled device(s) fail.

**CAUTION**

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts.

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

IMPORTANT DEFINITIONS**WARNING**

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

**CAUTION**

Indicates a potentially hazardous situation which, if not avoided, could result in damage to equipment.

**NOTE**

provides other helpful information that does not fall under the warning or caution categories.

Woodward Governor Company reserves the right to update any portion of this publication at any time. Information provided by Woodward Governor Company is believed to be correct and reliable. However, no responsibility is assumed by Woodward Governor Company unless otherwise expressly undertaken.

© Woodward Governor Company
All Rights Reserved

Contents



CHAPTER 1. GENERAL INFORMATION.....	4
CHAPTER 2. OPTION SC02.....	5
Connection	5
Configuration	6

Chapter 1.

General Information



CAUTION

This brief manual can only be used together with the complete manual.

This manual describes the following options:

- **Option SC02**
 - **Woodward IKD 1** (2 pcs; details in manual 37135), coupling to
 - **Woodward GCP-30 Series**

The option SC02 allows to operate the above mentioned devices at the CAN engine bus.


The connected devices have to be enabled using the configuration.

Chapter 2. Option SC02

The **Option SC02** enables to operate the GCP together with 2 expansion cards IKD1.

- IKD1 digital expansion board (unit 1) from Woodward,
- IKD1 digital expansion board (unit 2) from Woodward,

Connection



A (Y1)	B (Y2)	C (Y3)	D (Y4)	E (Y5)	
CAN-L [1]	CAN-H [1]	GND	CAN-H	CAN-L	CAN bus (engine bus)

[1]..may be used for feeding through the CAN bus to other participants or for connecting the termination resistor.

Configuration



NOTE

Please take the following functions of the IKD 1 from the Woodward manual 37135.



NOTE

You find the following configuration screens in the GCP after the counter configuration screens.

Configure IKDx	JA
-------------------	----

[x = 1/2]

Configuration of the IKDx **YES/NO**

To ensure a fast proceeding in the extensive configuration screens, different parameter groups are grouped in blocks. A setting to "YES" or "NO" has no influence on the fact whether a control, monitoring, etc. is performed or not. The entry has only the following effects:

- YES**The configuration screens of the following blocks are displayed and can either be enabled ("Select" button) or parameter changes can be performed ("Cursor→", "Digit↑" or "Select" buttons). A decision whether the parameters are processed will not be made.
- NO**The parameters of the following block are skipped, i.e. they are not displayed and cannot be changed.

IKDx on bus	NO
-------------	----

IKDx JA [x = 1/2]

IKD 1.x on bus **YES/NO**

- YES**The IKD 1 functions are activated. Moreover, it is monitored whether the IKD 1.{x} is connected to the engine bus. If this parameter is set to YES, but the IKD 1.{x} is not connected to the CAN bus, an interface error will be triggered in the GCP.
- NO**The functions of the IKD 1 are locked and no communication monitoring to IKD1.{x} is performed.

Note to IKD 1 interface error - The "interface error Y1Y5" with alarm class 1 is triggered, if the GCP does not receive a message from an operating IKD 1 for about 5 s.

IKD 1 Discrete Inputs

The parameters are at the end of the GCP configuration file. Please note that you may have to perform additional settings (e.g. normally open/closed, delay, alarm class, etc.) directly at the IKD 1 via direct configuration if necessary. Please observe the IKD 1 manual about this.

```
Error text DI{x}
IKD{y} (term. {z})
[x = 1..8] / [y = 1/2] / [z = 5..12]
```

Configuration of the IKD 1.y alarm texts

The discrete input {x} (term. {y}) on the IKD 1.{z} displays the text configured here at the GCP display.

Example: Discrete input 5 on the IKD 1.1

```
Error text DI5 IKD1
      (term. 9)
```

Configuration of the IKD 1.1 alarm texts

The discrete input 5 (term. 9) on the IKD 1.1 displays the text configured here at the GCP display.

IKD 1 Relay Outputs

The parameters are at the end of the GCP configuration file. Please note that you may have to perform additional settings directly at the IKD 1 via direct configuration if necessary. Please observe the IKD 1 manual about this.

```
Assignment {x}.
relay on IKD{y}
      [x = 1..8] / [y = 1/2]
```

Configuration of the relay outputs on the IKD 1.y

The relay {x} on the IKD 1.{y} energizes if the configured logical condition is fulfilled.

Example: Relay 2 on the IKD 1.2

```
Assignment 2. relay
      on IKD2
```

Configuration of the 2nd relay on the IKD 1.2

The relay 2 on the IKD 1.2 energizes if the configured logical condition is fulfilled.

Relay Manager

No.	Outputs	Comment
...	...	
98	IKD 1.[1] - discrete input [1]	
99	IKD 1.[1] - discrete input [2]	
100	IKD 1.[1] - discrete input [3]	
101	IKD 1.[1] - discrete input [4]	
102	IKD 1.[1] - discrete input [5]	
103	IKD 1.[1] - discrete input [6]	
104	IKD 1.[1] - discrete input [7]	
105	IKD 1.[1] - discrete input [8]	
106	IKD 1.[2] - discrete input [1]	
107	IKD 1.[2] - discrete input [2]	
108	IKD 1.[2] - discrete input [3]	
109	IKD 1.[2] - discrete input [4]	
110	IKD 1.[2] - discrete input [5]	
111	IKD 1.[2] - discrete input [6]	
112	IKD 1.[2] - discrete input [7]	
113	IKD 1.[2] - discrete input [8]	
...	...	
134	Communication with IKD1.[1] okay	
135	Communication with IKD1.[2] okay	
..	..	

Send Telegram 'Guidance Bus of the GCP-30'

MUX	No.	Content (words)	Unit	Comment
...		
4/1	13	IKD 1 alarms		Bit 15 = 1 IKD 1.[1] - discrete input [8] Bit 14 = 1 IKD 1.[1] - discrete input [7] Bit 13 = 1 IKD 1.[1] - discrete input [6] Bit 12 = 1 IKD 1.[1] - discrete input [5] Bit 11 = 1 IKD 1.[1] - discrete input [4] Bit 10 = 1 IKD 1.[1] - discrete input [3] Bit 9 = 1 IKD 1.[1] - discrete input [2] Bit 8 = 1 IKD 1.[1] - discrete input [1] Bit 7 = 1 Bit 6 = 1 Bit 5 = 1 Bit 4 = 1 Bit 3 = 1 Bit 2 = 1 Bit 1 = 1 Bit 0 = 1
...		
22/2	68	IKD 1.[2] alarms		Bit 15 = 1 IKD 1.[2] - discrete input [1] Bit 14 = 1 IKD 1.[2] - discrete input [2] Bit 13 = 1 IKD 1.[2] - discrete input [3] Bit 12 = 1 IKD 1.[2] - discrete input [4] Bit 11 = 1 IKD 1.[2] - discrete input [5] Bit 10 = 1 IKD 1.[2] - discrete input [6] Bit 9 = 1 IKD 1.[2] - discrete input [7] Bit 8 = 1 IKD 1.[2] - discrete input [8] Bit 7 = 1 Bit 6 = 1 Bit 5 = 1 Bit 4 = 1 Bit 3 = 1 Bit 2 = 1 Bit 1 = 1 Bit 0 = 1
...		

We appreciate your comments about the content of our publications.
Please send comments to: icinfo@woodward.com
Please include the manual number from the front cover of this publication.



Woodward Governor Company
Leonhard-Reglerbau GmbH
Handwerkstrasse 29 - 70565 Stuttgart - Germany
Phone +49 (0) 711-789 54-0 • Fax +49 (0) 711-789 54-100
sales-stuttgart@woodward.com

Homepage

<http://www.woodward.com/smart-power>

Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.

Complete address/phone/fax/e-mail information
for all locations is available on our website (www.woodward.com).

04/9/S