

37353A



MFR 13 Packages Protection Relay



Manual
Version 3.1xxx

Manual 37353A

**WARNING**

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment. Practice all plant and safety instructions and precautions. Failure to follow instructions can cause personal injury and/or property damage.

The engine, turbine, or other type of prime mover should be equipped with an overspeed (overtemperature, or overpressure, where applicable) shutdown device(s), that operates totally independently of the prime mover control device(s) to protect against runaway or damage to the engine, turbine, or other type of prime mover with possible personal injury or loss of life should the mechanical-hydraulic governor(s) or electric control(s), the actuator(s), fuel control(s), the driving mechanism(s), the linkage(s), or the controlled device(s) fail.

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.

**CAUTION**

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts.

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

**OUT-OF-DATE PUBLICATION**

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, be sure to check the Woodward website:

<http://www.woodward.com/pubs/current.pdf>

The revision level is shown at the bottom of the front cover after the publication number. The latest version of most publications is available at:

<http://www.woodward.com/publications>

If your publication is not there, please contact your customer service representative to get the latest copy.

Important definitions**WARNING**

Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.

**CAUTION**

Indicates a potentially hazardous situation that, if not avoided, could result in damage to equipment.

**NOTE**

Provides other helpful information that does not fall under the warning or caution categories.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, Woodward assumes no responsibility unless otherwise expressly undertaken.

© Woodward
All Rights Reserved.

Revision History

Rev.	Date	Editor	Changes
NEW	06-03-02	TP	Release based on 37142B
A	07-07-18	TP	Zero voltage monitoring parameters corrected; description of inverse time overcurrent monitoring improved

Contents

CHAPTER 1. GENERAL INFORMATION.....	7
Introduction	7
Measurement Value Logging	8
Package Functional Descriptions	9
CHAPTER 2. ELECTROSTATIC DISCHARGE AWARENESS.....	10
CHAPTER 3. INSTALLATION	11
Wiring Diagram	11
Power Supply (Packages GP / GPX / GPX-I / GPY-I / K08).....	12
Wide Range Power Supply (Package GPY-I-N).....	12
Measuring Inputs.....	13
Voltage.....	13
Current.....	14
Discrete Inputs	15
Outputs.....	16
Relay Outputs (Standard / Packages GPX / GPX-I / GPY-I / GPY-I-N / K08)	16
Pulse Output (Packages GPY-I / GPY-I-N)	16
Analog Outputs (Packages GPY-I / GPY-I-N)	17
Interface (Packages GPX-I / GPY-I / GPY-I-N / K08).....	18
Modbus Interface	18
DPC - Direct Configuration Interface	19
CHAPTER 4. FUNCTIONAL DESCRIPTION	20
Control Inputs.....	20
Control Outputs	21
Direction of Power.....	22
Power Factor Definition.....	23
Alarms	25
Alarm Messages	25
Alarm Acknowledgement.....	25
CHAPTER 5. DISPLAY AND OPERATING ELEMENTS.....	26
Brief Description of LEDs and Push Buttons	26
LEDs.....	27
Push Buttons	28
LC Display.....	29
Display in Automatic Mode (First Line of the Display: Measured Values).....	29
Display in Automatic Mode (Second Line of the Display: Measured Values)	29
Display in Automatic Mode (Second Line of the Display: Alarm Indication).....	30

CHAPTER 6. CONFIGURATION	31
Basic Data	32
Configuration Access.....	32
Password.....	32
Change Passwords	33
Direct Configuration.....	34
Measurement.....	35
Voltage Measurement	35
Potential Transformer Configuration	35
Current Measurement	36
Rated Values (Packages GPX / GPX-I / GPY-I / GPY-I-N / K08).....	37
Power Measurement	37
Control Functions	38
Synchronization (Packages GPX / GPX-I / GPY-I / GPY-I-N / K08).....	38
Type of Monitoring.....	40
Protection.....	41
Overvoltage Monitoring	41
Undervoltage Monitoring	42
Zero Voltage Monitoring	43
Voltage Asymmetry Monitoring	44
Overfrequency Monitoring.....	45
Underfrequency Monitoring.....	46
Independent Time-Overcurrent Monitoring	47
Inverse Time-Overcurrent Monitoring	49
Inverse Time-Overcurrent Monitoring with Voltage Restraint	52
Ground Fault Monitoring, Calculated (Packages GP / K08)	54
Overload Monitoring	55
Reverse/Reduced Power Monitoring	56
Unbalanced Load Monitoring	57
Reactive Power Monitoring	58
Relay Configuration	59
Auto Acknowledgement of the Relays	59
Auto Acknowledgement of Messages	60
Changing the Relay Assignment.....	61
Pulse Output of the Positive Active Energy (Packages GPY-I / GPY-I-N).....	63
Analog Outputs (Packages GPY-I / GPY-I-N).....	64
Interface (Packages GPX-I / GPY-I / GPY-I-N / K08).....	66
Screens for Modbus RTU Slave Protocol	66
General Interface Screens	67
CHAPTER 7. COMMISSIONING.....	68
APPENDIX A. DIMENSIONS	70
APPENDIX B. TECHNICAL DATA	71
APPENDIX C. MEASURED QUANTITIES AND ACCURACY	73
APPENDIX D. INTERFACE TELEGRAM.....	74
Communication Interface Addresses	74
Transmission Message	74
Receive Message.....	77
Description of the Data Format.....	78
Examples.....	79
Bit Change at Tripping of a Watchdog Function	79
Framework Data for the Interfaces.....	79
Framework Data for Modbus RTU Slave	79
APPENDIX E. LIST OF PARAMETERS	80

APPENDIX F. SERVICE OPTIONS	86
Product Service Options	86
Returning Equipment for Repair	86
Packing a Control	87
Return Authorization Number RAN	87
Replacement Parts.....	87
How to Contact Woodward	88
Engineering Services	89
Technical Assistance	90

Illustrations and Tables

Illustrations

Figure 3-1: Wiring diagram	11
Figure 3-2: Power supply.....	12
Figure 3-3: Wide range power supply.....	12
Figure 3-4: Measuring inputs - voltages	13
Figure 3-5: Measuring inputs - synchronizing voltage	13
Figure 3-6: Measuring inputs - current	14
Figure 3-7: Discrete inputs.....	15
Figure 3-8: Relay outputs	16
Figure 3-9: Pulse output.....	16
Figure 3-10: Analog outputs	17
Figure 3-11: Interfaces.....	18
Figure 4-1: Direction of power	22
Figure 5-1: Front panel	26
Figure 6-1: Diagram for independent time-overcurrent monitoring	47
Figure 6-2: Inverse time-overcurrent - characteristic "normal inverse"	50
Figure 6-3: Inverse time-overcurrent - characteristic "very inverse"	51
Figure 6-4: Inverse time-overcurrent - characteristic "extremely inverse"	51
Figure 6-5: Characteristic of the inverse time-overcurrent monitoring with voltage restraint (knee curve setting 20 %)	52
Figure 7-1: Dimensions.....	70
Figure 7-2: Interface, power factor scaling	78
Figure 7-3: Interface - Modbus connection	79

Tables

Table 3-1: Conversion chart - wire size	12
Table 4-1: Alarm messages.....	25
Table 5-1: Alarm messages.....	30
Table 6-1: Release delay of the relays	60
Table 6-2: Protective function output to relay	62
Table 6-3: Analog outputs, table of values	64
Table 7-1: Analog outputs, table of values	85

Chapter 1. General Information



Introduction



The MFR 13 is an intelligent protection unit. The primary values are measured over integrated voltage and current measuring inputs and converted into configurable limit values which are displayed and monitored. These values can be monitored for exceeding/falling below the configured value.

The detailed model description for the MFR 13 reads as follows:

MFR1315	B/	ABDEF..Z	
			Packages according to the package list. These packages can be found in the manual. Each chapter headline points out if the described function is standard or part of a package.
			Mounting [B].. Flush-mounting
			Current transformer, secondary [1] = ../1 A [5] = ../5 A
			Voltage transformer/PTs, secondary [1] = 100 Vac [4] = 400 Vac
			Type

Examples:

- [MFR1341B/GPX](#) (flush mounted, standard unit with 400 Vac PT and ../1 A CT inputs with 8 configurable relays, true RMS busbar voltage measuring, and synch-check function)
- [MFR1315B/ GPY-I-N](#) (flush mounted, standard unit with 100 Vac PT and ../5 A CT inputs with 8 configurable relays, 3 analog outputs, pulse output, true RMS busbar voltage measuring synch-check function, RS-485 Modbus RTU Slave interface, and wide-range power supply)

Measurement Value Logging



Voltage

Voltage is displayed as three-phase r.m.s measurement of the phase-neutral and/or phase-phase voltages.

Packages [GPX](#) / [GPX-I](#) / [GPY-I](#) / [GPY-I-N](#) utilize single-phase r.m.s. measurement of the synchronizing voltage V_{L1-L2} .

This device can be ordered with the following measuring voltage input ranges (rated voltages). Please indicate the measuring voltage input required when ordering (refer to Technical Data on page 71):

- 66 V/115 V [1]
- 230 V/400 V [4]

Frequency

Frequency measurement is extracted from the digitally filtered measuring voltages. The frequency is measured three-phase if the measured voltage exceeds 15% of the nominal voltage. This ensures rapid and precise measurement of the frequency. However the frequency is still measured correctly even if voltage is only applied to one phase.

Current

Three-phase measurement of the r.m.s. value.

- ../1 A [1]
- ../5 A [5]

Ground fault

The ground fault current is a calculation of the vectorial sum of the three phase currents ([Package GP](#)). This measurement is suitable for line-to-ground monitoring in a solidly or resistance grounded mains (e.g. In phase-to-phase low voltage mains). The line-to-ground current should at least represent 10% of the current transformer rated current in order to ensure reliable operation.

Active power

The active load is measured through real time multiplication of either the three phase-to-neutral voltages and the three-phase conductor currents or single-phase measurement of voltage V_{12} and the current I_1 .

Reactive power

The reactive power is calculated from the measured single-phase voltage V_{12} and the single-phase current I_1 .

Power factor

Power factor is calculated time difference between the digitally filtered voltage V_{12} and current I_1 . The power factor is accurately measured for both clockwise and counter-clockwise phase sequences.

Active energy

Active energy combines a time measurement with the measured positive active load. The counter is incorporated in the non-volatile memory and only computes positive energy. The memory is updated every 3 minutes with a resolution of 0.1 kWh. The unit automatically increases the engineering unit of measure when the maximum value has been reached. This permits a measuring range up to 4,290 GWh. This counter is not Physikalisch-Technische Bundesanstalt (PTB) calibrated.

Package Functional Descriptions



Depending on the model, the unit is equipped with the following functions

Function	Package					
	GP	GPX	GPX-I	GPY-I	GPY-I-N	K08

General functions						
1 ready for operation relay output (normally open contact)	✓	✓	✓	✓	✓	✓
Additional freely configurable relay outputs (2 change-over contacts)	✓	✓	✓	✓	✓	✓
1 synch-check relay output (normally open contact)		✓	✓	✓	✓	✓
Additional freely configurable relay outputs (4 change-over contacts)		✓	✓	✓	✓	✓
Discrete input for blocking of protective functions or remote acknowledgment	✓	✓	✓	✓	✓	✓
3 Analog outputs - 20/0/4 to +20 mA				✓	✓	
Open-collector pulse output for kWh				✓	✓	
Interface, bi-directional			✓ [#]	✓ [#]	✓ [#]	✓ [#]
Wide-range power supply (90 to 265 Vac/dc)					✓	

[#] = RS485/Modbus RTU Slave

Protective functions						
Three phase over / under voltage monitoring (2 levels)	V>, V<	✓	✓	✓	✓	✓
Zero voltage monitoring	V ≠ 0	✓	✓	✓	✓	✓
Voltage asymmetry monitoring	Vas>	✓	✓	✓	✓	✓
Three-phase over / under frequency monitoring (2 levels)	f>, f<	✓	✓	✓	✓	✓
Overload monitoring	P>	✓	✓	✓	✓	✓
Reverse/reduced power monitoring	-P<	✓	✓	✓	✓	✓
Unbalanced load monitoring	Ias>	✓	✓	✓	✓	✓
Reactive power monitoring (loss of excitation monitoring)	-Q<, Q>	✓	✓	✓	✓	✓
Ground fault monitoring, calculated from I _{L1} +I _{L2} +I _{L3}	I _E >>	✓				✓
Independent time-overcurrent monitoring	I>, I>>, I>>>	✓	✓	✓	✓	✓
Inverse time overcurrent monitoring (according to IEC)	I _a >	✓	✓	✓	✓	✓
Inverse time-overcurrent monitoring with voltage restraint	I>, I>> (V<)	✓	✓	✓	✓	✓
Synchro-Check			✓	✓	✓	✓

Intended Use The unit must only be operated in the manner described by this manual. The prerequisite for a proper and safe operation of the product is correct transportation, storage, and installation as well as careful operation and maintenance.



NOTE

This manual has been developed for all available packages. Inputs/outputs, functions, configuration screens, and other details described, which do not exist on your unit, may be ignored.

The present manual has been prepared to enable the installation and commissioning of the unit. Due to the large variety of parameter settings, it is not possible to cover every combination. The manual is therefore only a guide. In case of incorrect entries or a total loss of functions, the default settings may be taken from the list of parameters enclosed at the rear of this manual.

Chapter 2.

Electrostatic Discharge Awareness

All electronic equipment is static-sensitive, some components more than others. To protect these components from static damage, you must take special precautions to minimize or eliminate electrostatic discharges.

Follow these precautions when working with or near the control.

1. Before doing maintenance on the electronic control, discharge the static electricity on your body to ground by touching and holding a grounded metal object (pipes, cabinets, equipment, etc.).
2. Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as easily as synthetics.
3. Keep plastic, vinyl, and Styrofoam materials (such as plastic or Styrofoam cups, cigarette packages, cellophane wrappers, vinyl books or folders, plastic bottles, etc.) away from the control, modules, and work area as much as possible.
4. **Opening the control cover may void the unit warranty.**
Do not remove the printed circuit board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
 - Ensure that the device is completely voltage-free (all connectors have to be disconnected).
 - Do not touch any part of the PCB except the edges.
 - Do not touch the electrical conductors, connectors, or components with conductive devices or with bare hands.
 - When replacing a PCB, keep the new PCB in the plastic antistatic protective bag it comes in until you are ready to install it. Immediately after removing the old PCB from the control cabinet, place it in the antistatic protective bag.



CAUTION

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Chapter 3. Installation

Wiring Diagram




Figure 3-1: Wiring diagram

WARNING
 All technical data and ratings indicated in this chapter are not definite! Only the values indicated under Technical Data on page 71 are valid!

CAUTION
 A circuit breaker must be located near to the unit and in a position easily accessible to the operator. This must also bear a sign identifying it as an isolating switch for the unit.

NOTE
 Inductive devices connected to the system (such as operating current coils, undervoltage tripping units, or auxiliary/power contacts) must be connected to a suitable interference suppressor.

The following chart may be used to convert square millimeters [mm²] to AWG and vice versa:

AWG	mm ²	AWG	mm ²	AWG	mm ²						
30	0.05	21	0.38	14	2.5	4	25	3/0	95	600MCM	300
28	0.08	20	0.5	12	4	2	35	4/0	120	750MCM	400
26	0.14	18	0.75	10	6	1	50	300MCM	150	1000MCM	500
24	0.25	17	1.0	8	10	1/0	55	350MCM	185		
22	0.34	16	1.5	6	16	2/0	70	500MCM	240		

Table 3-1: Conversion chart - wire size

Power Supply (Packages GP / GPX / GPX-I / GPY-I / K08)




Figure 3-2: Power supply

Terminal	Description	A _{max}
Standard power supply unit (Packages GP / GPX / GPX-I / GPY-I / K08)		
8	18 to 30 Vdc	2.5 mm ²
7	0 V reference point	2.5 mm ²

Wide Range Power Supply (Package GPY-I-N)




Figure 3-3: Wide range power supply

Terminal	Description	A _{max}
Wide range power supply unit (Package GPY-I-N)		
8	90 to 265 Vac/dc	2.5 mm ²
7	0 V reference point	2.5 mm ²

Measuring Inputs



Voltage




Figure 3-4: Measuring inputs - voltages

Terminal	Measurement	Description	A _{max}
1	400V direct	Measuring voltage L1	2.5 mm ²
2	or trans-	Measuring voltage L2	2.5 mm ²
3	former	Measuring voltage L3	2.5 mm ²
4	../100V	Neutral point of the 3-phase system/transf.	2.5 mm ²

Synchronizing Voltage (Packages GPX / GPX-I / GPY-I / GPY-I-N / K08)



NOTE

Connection of the phase voltage L3 to terminal 72 (synchronizing voltage) is necessary if

- the generator voltage is connected as a three-wire-system and
- the power measurement of the generator power must be three-phase.

If the input for balancing the measuring system is not connected, minor inaccuracies will occur during the three-phase power measurement. Functionality will not be affected if the voltage L3 is not connected and the power measurement is configured as single-phase.




Figure 3-5: Measuring inputs - synchronizing voltage

Terminal	Measurement	Description	A _{max}
70	400V direct	Synchronizing voltage L1	2.5 mm ²
71	or via transf.	Synchronizing voltage L2	2.5 mm ²
72	../100V	Synchronizing voltage L3 (not measured)	2.5 mm ²

Current



WARNING

Prior to disconnecting the current transformer connections or the connections of the transformer which are located at the unit, ensure that the transformer is short-circuited.



NOTE

Grounding of the secondary of a current transformer must always be single-sided.




Figure 3-6: Measuring inputs - current

Terminal	Measurement	Description	A _{max}
40	Transformer ../1 A or ../5 A	Generator current L1, transformer terminal s1 (k)	4 mm ²
41		Generator current L1, transformer terminal s2 (l)	4 mm ²
42		Generator current L2, transformer terminal s1 (k)	4 mm ²
43		Generator current L2, transformer terminal s2 (l)	4 mm ²
44		Generator current L3, transformer terminal s1 (k)	4 mm ²
45		Generator current L3, transformer terminal s2 (l)	4 mm ²

Discrete Inputs




Figure 3-7: Discrete inputs

Terminal	Assigned common	Description (according to DIN 40 719 Part 3, 5.8.3)	A_{max}
<i>A</i>	<i>B</i>		
5	6	Blocking of protective functions / remote acknowledgement	2.5 mm ²

Outputs



Relay Outputs (Standard / Packages GPX / GPX-I / GPY-I / GPY-I-N / K08)




Figure 3-8: Relay outputs

Terminal			Description	
<i>Make-contact</i>				A_{max}
Root	closing			
A	B			
9	10		Relay 1	2.5 mm ²
31	32		Relay 8 Pkgs. GPX / GPX-I / GPY-I / GPY-I-N / K08	2.5 mm ²
<i>Change-over contact</i>				
closing	Root	opening		
C	D	E		
11	12	13	Relay 2	2.5 mm ²
14	15	16	Relay 3	2.5 mm ²
19	20	21	Relay 4 Pkgs. GPX / GPX-I / GPY-I / GPY-I-N / K08	2.5 mm ²
22	23	24	Relay 5 Pkgs. GPX / GPX-I / GPY-I / GPY-I-N / K08	2.5 mm ²
25	26	27	Relay 6 Pkgs. GPX / GPX-I / GPY-I / GPY-I-N / K08	2.5 mm ²
28	29	30	Relay 7 Pkgs. GPX / GPX-I / GPY-I / GPY-I-N / K08	2.5 mm ²

Pulse Output (Packages GPY-I / GPY-I-N)




Figure 3-9: Pulse output

Terminal		Description	A_{max}
A	60	Pulse output (Open Collector)	2.5 mm ²
B	61		

Analog Outputs (Packages GPY-I / GPY-I-N)



NOTE

All 20 mA outputs are isolated from each other.




Figure 3-10: Analog outputs

Terminal		Description	A_{max}
0 to 20 / 4 to 20 -20 to $+20$ mA I_A 0 V A B			
51	50	Analog output 1 Packages GPY-I / GPY-I-N	1.5 mm ²
53	52	Analog output 2 Packages GPY-I / GPY-I-N	1.5 mm ²
55	54	Analog output 3 Packages GPY-I / GPY-I-N	1.5 mm ²

Interface (Packages GPX-I / GPY-I / GPY-I-N / K08)



Modbus Interface

	X1	X2	X3	X4	X5
Interface	B (inverted)	A (non-inverted)	GND	B (inverted)	A (non-inverted)
	RS-485 Modbus RTU Slave				

Figure 3-11: Interfaces

Terminal					Description
(X1)	(X2)	(X3)	(X4)	(X5)	
B	A	GND	B	A	RS-485, Modbus RTU Slave

i NOTE The Modbus interface connection may be performed at the terminals X1 through X3 or X3 through X5. The terminals X1 and X4 as well as X2 and X5 are connected internally.

DPC - Direct Configuration Interface



NOTE

Configuration with the direct configuration cable DPC (P/N 5417-557) is possible. A laptop/PC, the DPC cable, the program LeoPC1 version 3.1.1 or higher (included on CD Rom with unit), and the proper configuration files are required. Please consult the online help installed when the program is installed for a description of the LeoPC1 program and its setup.



WARNING

Only the DPC cable may be connected to the DPC interface. If other devices or lines are connected, the unit may be destroyed. Especially the connection of live lines (like phone lines) will destroy the unit.



CAUTION

The connection cable delivered with the DPC must be used between DPC and the unit to ensure proper functionality of the unit. An extension or utilization of different cable types for the connection between the unit and DPC may result a malfunction of the unit. This may possibly result in damage to components of the system. If an extension of the data connection line is required, only the serial cable (RS-232) between DPC and laptop/PC may be extended. It is recommended to use an industry standard cable for this.



NOTE

If the parameter "Direct config." is enabled on the control, communication via the CAN bus interface on terminals X1/X5 is disabled.

If the control unit detects that the engine is running (ignition speed exceeded), the direct configuration port is disabled.

Chapter 4. Functional Description

Control Inputs



Blocking of protective functions / Remote acknowledgement
Terminal 5/6

Energizing this discrete input disables various protective functions. This functionality may be desired if the control is used for generator protection. This keeps the control from recognizing fault conditions (i.e. undervoltage, underfrequency) when the generator is not operating. If blocking of these protective functions is not required, the discrete input should not be connected to any potential source.

The following protective functions cannot be blocked via this discrete input:

- Overvoltage monitoring
- Overfrequency monitoring
- Zero voltage monitoring
- Ground fault monitoring (calculated)

External acknowledgement of the relays via the discrete input "Blocking of protective functions / remote acknowledgement"

If the unit should not automatically reset the relays after the fault is no longer present, the parameter "**Auto clearing Relays**" must first be configured "**OFF**" (refer to "Auto Acknowledgement of the Relay" on page 59).

External Clearing ON

OFF Alarms that cannot be blocked will not automatically reset after the fault condition is no longer present. Pressing the "Clear" button resets the relays.

ON All alarm messages are reset if terminals 5/6 ("Blocking of protective functions / remote acknowledgement") are energized. Alarms that cannot be blocked are only reset after the fault is no longer present.

Control Outputs



NOTE

A description of the relay manager may be found in **Changing the Relay Assignment** starting on page 61.

Relay 1 Output relay (type: make contact, N.O.)
Terminal 9/10 The "relay manager" controls this relay.



NOTE

The "ready for operation" function is always assigned to relay 1. However, other protective functions may also be assigned to relay 1 additionally. Relay 1 is always configured as Normally Closed (break contact) and will de-energize if the unit is not ready for operation.

Relay 2, 3 Output relay (type: change-over contact)
Terminal 11 through 16 The "relay manager" controls these relays.

Packages GPX / GPX-I Output relay (type: change-over contact)
GPY-I / GPY-I-N / K08 The "relay manager" controls these relays.

Relay 4 to 7
Terminal 19 through 30

Packages GPX / GPX-I Output relay (type: make contact, N.O.)
GPY-I / GPY-I-N / K08 The synch-check function is assigned to this relay.

Relay 8
Terminal 31/32



NOTE

For units with **Packages GPX / GPX-I / GPY-I / GPY-I-N / K08**, the synch-check function is assigned to relay 8. Therefore, relay 8 cannot be configured with the relay manager.

Direction of Power



If the unit's current transformers are wired according to the pin diagram shown, the following values are indicated:

Positive generator active load

The generator supplies active load.

**Inductive generator power factor
Positive reactive power**

The generator is overexcited and supplies inductive reactive power.




Figure 4-1: Direction of power

Power Factor Definition



The phasor diagram is used from the generator's view. This defines the following definitions.

Power Factor is defined as a ratio of the real power to apparent power. In a purely resistive circuit, the voltage and current waveforms are in step resulting in a ratio or power factor of 1.00 (often referred to as unity). In an inductive circuit the current lags behind the voltage waveform resulting in usable power (real power) and unusable power (reactive power). This results in a positive ratio or lagging power factor (i.e. 0.85lagging). In a capacitive circuit the current waveform leads the voltage waveform resulting in usable power (real power) and unusable power (reactive power). This results in a negative ratio or a leading power factor (i.e. 0.85leading).

Inductive: Electrical load whose current waveform lags the voltage waveform thus having a lagging power factor. Some inductive loads such as electric motors have a large startup current requirement resulting in lagging power factors.	Capacitive: Electrical load whose current waveform leads the voltage waveform thus having a leading power factor. Some capacitive loads such as capacitor banks or buried cable result in leading power factors.
-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Different power factor displays at the unit:

i0.91 (inductive) lg.91 (lagging)	c0.93 (capacitive) ld.93 (leading)
--------------------------------------	---------------------------------------

Reactive power display at the unit:

70 kvar (positive)	-60 kvar (negative)
--------------------	---------------------

Output at the interface:

+ (positive)	- (negative)
--------------	--------------

Compared with the voltage, the current is ...

lagging	leading
---------	---------


The generator is ...

over excited	under excited
--------------	---------------

Control: If the control unit is equipped with a power factor controller, ...

a voltage lower "-" signal is output as long as the measured value is "more inductive" than the reference set point Example: measured = i0.91; set point = i0.95	a voltage raise "+" signal is output as long as the measured value is "more capacitive" than the reference set point Example: measured = c0.91; set point = c0.95
---------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------

Phasor diagram:



Alarms



Alarm Messages

Table 4-1 contains a list of all alarm messages that the control may monitor for depending on how the unit is configured:

Alarm type		Alarm text
Overvoltage, level 1	Standard	Overvolt.1
Overvoltage, level 2	Standard	Overvolt.2
Undervoltage, level 1	Standard	Und.volt.1
Undervoltage, level 2	Standard	Und.volt.2
Asymmetry	Standard	Asymmetry
Overfrequency, level 1	Standard	Overfreq.1
Overfrequency, level 2	Standard	Overfreq.2
Underfrequency, level 1	Standard	Und.freq.1
Underfrequency, level 2	Standard	Und.freq.2
Independent time-overcurrent, level 1	Standard	Ov.curr. 1
Independent time-overcurrent, level 2	Standard	Ov.curr. 2
Independent time-overcurrent, level 3	Standard	Ov.curr. 3
Inverse time-overcurrent	Standard	I>(invers)
Inverse time-overcurrent with voltage restraint	Standard	I>(invers)
Ground fault, calculated, level 1	Standard	Earthcur.1
Ground fault, calculated, level 2	Standard	Earthcur.2
Overload	Standard	Overload
Reverse-/reduced power	Standard	Rev. power
Unbalanced load	Standard	Unbalance
Reactive power, capacitive	Standard	React.pow-
Reactive power, inductive	Standard	React.pow+

Table 4-1: Alarm messages

Alarm Acknowledgement

A fault/alarm is indicated by the "Alarm" LED.

By pressing the "Clear" button, the active faults are acknowledged. The following distinction is made between fault conditions:

The fault ...

- is still active** As long as the fault is still present, it cannot be acknowledged. The flashing "Alarm" LED on the front panel indicates that the alarm is still active.
- is no longer active** When the active fault has been eliminated, the flashing "Alarm" LED changes to steady illumination. If the parameter "Auto clearing displays" is configured "ON", the LED extinguishes after the resetting time has expired. If the parameter "Auto clearing displays" is configured "OFF", the LED is extinguished only after pressing the "Clear" button.

Chapter 5. Display and Operating Elements

The pressure-sensitive membrane of the front panel consists of a plastic coating. All keys have been designed as touch-sensitive membrane switch elements. The display is an LC-display, consisting of 2 rows of 16 characters each, with indirect green lighting. The contrast of the display can be infinitely adjusted via a rotary potentiometer positioned on the right side of the control. The configuration plug is located on the right side of the unit as well. Please connect the direct configuration cable there (DPC).




Figure 5-1: Front panel

Brief Description of LEDs and Push Buttons



LEDs

No.	Description	Function
1	"Wye"	Indication of the wye (star) voltages
2	"Delta"	Indication of the delta voltages
3	"Operating"	Automatic mode
4	"Alarm"	Alarm occurred

Push Buttons

No.	Description	Function
12	Display ↓	Advance to next screen
12	Select	Confirm selection
13	Menu	Select menu
13	Digit ↑	Increase the digit
14	Clear	Acknowledgement of alarm messages
14	Cursor →	Move cursor one position to the right

Miscellaneous

No.	Description	Function
5	LC Display	LC Display
6	Potentiometer	Adjust LCD contrast
7	DPC plug	Configuration plug

LEDs



NOTE

If neither of the "Wye" and "Delta" LEDs is illuminated, the first line of the display indicates the measured currents of the phases.

1	<p>"Wye" Color: Yellow</p>	<p>Indication of the wye voltages</p> <hr/> <p>If this LED is illuminated, the values indicated on the display are the wye (star) voltages (phase-neutral).</p>
2	<p>"Delta" Color: Yellow</p>	<p>Indication of the delta voltages</p> <hr/> <p>If this LED is illuminated, the values indicated on the display are the delta voltages (phase-phase).</p>
3	<p>"Operation " Color: Green</p>	<p>Operation</p> <hr/> <p>This LED is illuminated constantly when the control unit is in the Automatic mode. If this LED is flashing, the control is in the configuration mode.</p>
4	<p>"Alarm" Color: Red</p>	<p>Alarm</p> <hr/> <p>This LED flashes as long as a set point limit is exceeded. When all measuring values are below the configured set point limit again and "Auto clearing display" is configured "OFF", this LED will change to steady illumination.</p>

Push Buttons



In order to facilitate the setting of the parameters the buttons are equipped with an "AUTOSCROLL" function while the controller is in the configuration mode. It permits the user to rapidly advance to the next setting and configuration screens, the digits, or the cursor position. The "AUTOSCROLL" function will only be enabled when the user presses and holds the corresponding buttons.

- 12 **Display↓ / Select** **Display↓ / Select**
Color: none

Automatic mode: Display↓ - By pressing this button, the user advances through the display of operating (wye voltages, delta voltages, wire currents) and alarm messages. The "Wye" and "Delta" LEDs are illuminated accordingly.

Configuration: Select - By pressing this button, the user advances to the next configuration screen. If the value originally displayed has been changed via the "Digit↑" or "Cursor→" push buttons, the newly set value is saved by pressing the "Select" push button once. By pressing the button again, the user causes the system to advance to the next configuration screen.

- 13 **Menu / Digit↑** **Menu / Digit↑**
Color: none

Automatic mode: Menu - By pressing this button, the user advances through the messages displayed on the second line of the display. (Various measured values and any alarm messages that have not been cleared are indicated.)

Configuration: Digit↑ - By pressing this button, the position at which the cursor is presently located is increased by one digit. The increase is restricted by the permissible limits (see list of parameters included in Appendix E). If the highest permissible number has been reached, the number automatically returns to the lowest permissible number.

- 14 **Clear / Cursor →** **Clear / Cursor →**
Color: none

Automatic mode: Clear - Individual alarm messages are deleted by pressing this button provided the fault is no longer present.

Configuration: Cursor→ - This button moves the cursor one position to the right. When the cursor reaches the extreme right position it may be returned to the extreme left position by pressing the Cursor→ button again.

LC Display



5 LC Display LC display

Performance values can be monitored from the two-line display, provided that the control is in automatic mode. In configuration mode, the individual parameters are displayed.


Display in Automatic Mode (First Line of the Display: Measured Values)




NOTE

The user can scroll through the first display line with the button "Display ↓".


"Wye" = on, "Delta" = off
Wye voltages



"Wye" = off, "Delta" = on
Delta voltages



"Wye" = off, "Delta" = off
Phase currents



Display in automatic mode, first line: measured values

The following measured values are displayed (depending on the "Wye" and "Delta" LEDs):


- The "Wye" LED is illuminated, and the "Delta" LED is off.
The wye (star) voltages (V_{L1-N} , V_{L2-N} and V_{L3-N}) of the four-wire system are indicated. If the application is a three-wire system, the configuration screen "volt.-Measuring" must be configured to "phase to phase". The "Wye" LED will not illuminate in this application.
- The "Wye" LED is off and the "Delta" LED is illuminated.
The delta voltages (V_{L1-L2} , V_{L2-L3} and V_{L3-L1}) of the phase-to-phase system/phase - neutral system are indicated.
- The "Wye" LED is off and the "Delta" LED is off.
The phase currents (I_{L1} , I_{L2} and I_{L3}) are displayed

Display in Automatic Mode (Second Line of the Display: Measured Values)



NOTE

The "Menu" button may be used to scroll through the messages shown on the second line of the display.



Display in automatic mode, second line: measured values

The frequency is always indicated in [Hz]. Instead of "xxxxxxxxxx" the following measuring values are indicated:

- | | |
|---------------------------|-----------------------------------------------------------------|
| • Power P | Unit dynamic in [kW / MW] |
| • Power factor (cos φ) | Unit dimensionless |
| • Reactive power Q | Unit dynamic in [kvar / Mvar] |
| • Apparent power S | Unit dynamic in [kVA / MVA] |
| • Active energy W | Unit dynamic in [kWh / MWh] |
| • Ground current Ie | Unit static in [A] |
| • Synchronizing voltage | Unit dyn. in [V/kV] GPX/GPX-I/GPY-I/GPY-I-N/K08 |
| • Synchronizing frequency | Unit static in [Hz] GPX/GPX-I/GPY-I/GPY-I-N/K08 |
| • Synchronizing angle | Unit static in [°] GPX/GPX-I/GPY-I/GPY-I-N/K08 |

Display in Automatic Mode (Second Line of the Display: Alarm Indication)



NOTE

The user may scroll through the alarm messages that have occurred with the "Menu" button.



Display in automatic mode, second line: alarm indication

Alarm messages are shown on the bottom line of the unit display. Table 5-1 contains a list of all alarm messages that the control may monitor for depending on how the unit is configured.

Alarm type		Alarm text
Overvoltage, level 1	Standard	Overvolt.1
Overvoltage, level 2	Standard	Overvolt.2
Undervoltage, level 1	Standard	Und.volt.1
Undervoltage, level 2	Standard	Und.volt.2
Asymmetry	Standard	Asymmetry
Overfrequency, level 1	Standard	Overfreq.1
Overfrequency, level 2	Standard	Overfreq.2
Underfrequency, level 1	Standard	Und.freq.1
Underfrequency, level 2	Standard	Und.freq.2
Independent time-overcurrent, level 1	Standard	Ov.curr. 1
Independent time-overcurrent, level 2	Standard	Ov.curr. 2
Independent time-overcurrent, level 3	Standard	Ov.curr. 3
Inverse time-overcurrent	Standard	I>(invers)
Inverse time-overcurrent with voltage restraint	Standard	I>(invers)
Ground fault, calculated, level 1	Standard	Earthcur.1
Ground fault, calculated, level 2	Standard	Earthcur.2
Overload	Standard	Overload
Reverse-/reduced power	Standard	Rev. power
Unbalanced load	Standard	Unbalance
Reactive power, capacitive	Standard	React.pow-
Reactive power, inductive	Standard	React.pow+

Table 5-1: Alarm messages

Chapter 6. Configuration

Configuration can be performed via the front panel push buttons and the front panel LC display or using a PC and the PC program LeoPC1 via the serial interface. If direct configuration via a PC is selected, the following baud rate is to be used:

- Configuration via direct configuration plug = 9,600 Baud (8 Bit, no parity, 1 stop bit)



CAUTION

Please note that configuration only should be done while the system is not in operation.



NOTE

A list of all parameters may be found in Appendix E of this manual.

You can advance through the individual parameter screens if you are in configuration mode (simultaneously pressing of "Digit↑" and "Cursor→" push buttons permits access to the configuration mode) by using the "Select" button. If you press and hold the "Select" push button, the scroll function will be activated, allowing for the parameter screens to be advanced through more rapidly. The control unit will permit the operator to reverse up to four previous screens (exception: it is not possible to reverse from the first parameter to the last parameter). To perform the reverse function through the parameter screens, the "Select" and "Cursor→" push buttons must be pressed and released simultaneously. The control unit will revert to automatic mode if an entry isn't performed, a change made, or any other action performed for 120 seconds.



NOTE

There are two different hardware versions described in this operating manual: A 100 V-version [1] and a 400 V-version [4]. The versions vary as far as the configuration screens and the parameter input ranges are concerned. The two types are differentiated by indicating the voltage: ([1] ... or [4] ...).

Adjust Settings: SELECT (ANWAHL)

Configuration mode

Button "Select"

After the configuration mode is enabled, the subsequent screens can be viewed and modified within the preset limits. Please note, that by depressing the "Select" button, the following screens are advanced by one screen each. If a parameter is configured "OFF", the related screens are not displayed or monitored by the control. Pressing the "Select" button will advance the displayed screen to the next parameter.

Basic Data



Software version
x.xxxx

Software version

This screen displays the software version loaded into the control (the last two xx are for software revisions which do not affect the function of the unit).

SPRACHE/LANGUAGE

Language selection

Deutsch/English

The desired language for the controller to operate in is set by this parameter. The screens (configuration and display screens) can be displayed either in German or English.

Configuration Access



Password

The unit is equipped with a three-level code and configuration hierarchy, which allows different user access to the control. A distinction is made between:

Code level CS0 (User Level)

Factory password = none

This code level allows for monitoring of the system and does not permit access to the parameters. Configuration is blocked.

Code level CS1 (Basic Service Level)

Factory password = "0 0 0 1"

This code level entitles the user to change selected controller set points, enable auto-clearing display, and to reset the kWh counter. Changing a password is not permitted at this level. This password expires two hours after entering the password and the user is returned to the CS0 level.

Code level CS2 (Commissioning Level)

Factory password = "0 0 0 2"

Allows direct access to all parameters (displaying and changing). In addition, the user may also set the password for levels CS1 and CS2. This password expires two hours after entering the password and the user is returned to the CS0 level.



NOTE

Once the code level is set, it will not be changed even after entering the configuration repeatedly an incorrect code number has been entered, the code level is set to CS0, thus locking the device for external persons.

If for 2 hours uninterruptedly supply voltage is applied, the device automatically switches to code level 0.



NOTE

The following configuration screen "Enter code number" only appears if the parameter "Password Protection" is configured ON (see below).

Enter code number	0000
----------------------	------

Enter code number **0000 to 9999**

Upon enabling the configuration mode, the user is required to enter an access code number, which identifies the various users. The displayed number XXXX is a randomly generated number. If the random number is confirmed by pressing the "Select" button without being changed, the current level of access maintained. Upon entering either a level 1 or level 2 access code, the corresponding level of access is granted. If an incorrect access code is entered the control unit changes to code level 0 and all access is blocked until a code level 1 or 2 access code is entered.

Password Protection	ON
------------------------	----

Password protection **ON/OFF**

- ON**..... Password protection is enabled. Configuration access is granted by entering the appropriate password (Code level 1/2). If an incorrect code number has been entered, configuration is blocked.
- OFF**..... Password protection is disabled. Access to configuration screens is permanently set to code level 2 and the code number is not queried. This parameter can only be changed if the code number of code level 2 has been entered.

Change Passwords

Define level 1 code	0000
------------------------	------

Define level 1 password **0000 to 9999**

This screen appears only when the level 2 password has been entered. After entering the digits into this screen, the code level for level 1 (basic service level) is enabled. After entering this code, the user only has the access rights assigned to this code level.

This code level (CS) is preset to **CS1 = 0 0 0 1**

Define level 2 code	0000
------------------------	------

Define level 2 password **0000 to 9999**

This screen appears only when the level 2 password has been entered. After entering the digits into this screen, the code level for level 2 (commissioning level) is enabled. After entering the code, the user has the access rights assigned to this code level.

This code level (CS) is preset to **CS2 = 0 0 0 2**

Direct Configuration



NOTE

A direct configuration cable DPC (P/N 5417-557), the LeoPC1 program (supplied with the cable) and the corresponding configuration files are required to perform direct configuration. After the program has been installed, consult the online help for a description of the PC program and its setup.

For configuration of the unit via PC program please proceed as follows:

- Install the PC program on your laptop/PC according to the installation manual.
- Before the end of the installation you are requested to select the language with which you want to start the PC program. You can change the language at any time. The selection of the language refers only to language with which the menus and subprograms of the PC program works. This setting will not change the language of the control unit being configured.
- After the installation of the PC program reboot your laptop/PC.
- Establish the connection between your laptop/PC and the unit via the DPC. Plug one side to the configuration plug of the unit and the other side to the COM1 port of your laptop/PC (other possibilities are described in the installation manual).
- You may start the PC program as follows:
 - by "Start/Program/Woodward/LeoPC" (starting at version 3.1.xxx), or
 - by a double click on a file ending ".cfg" in the subdirectory "LeoPC".
- After the PC program has been started, establish the communication by pressing the "F2" button. This will establish a data link between the unit and the laptop/PC.
- Start the sub program "Device Parameterization" and adjust the parameter of the unit to your application using this manual.



WARNING

If the following parameter "Direct parametr." is configured to "YES", communication via the interface terminals X1 to X5 is disabled (Packages GPX-I / GPY-I / GPY-I-N / K08). If communication is to be re-established via the interface terminals X1 to X5 after the unit is configured, the following parameter must be set to "NO"!

Direct parametr.	Direct configuration	YES/NO
YES	YES	Configuration via the configuration port is enabled. The following conditions must be met in order to carry out configuration via the direct configuration cable: <ul style="list-style-type: none"> - A connection must be established via the direct configuration cable between the unit and the PC - the Baud rate of the PC program must be set to 9,600 Baud - the corresponding configuration file must be used (file name: "xxxx-xxxx-yyy-zz.asm", initiated by xxxx-xxxx-yyy-zz.cfg)
	NO	Configuration via the direct configuration port is disabled.

Measurement



WARNING

The following values must be entered correctly for the generator to be monitored. Failure to do so may lead to incorrect measuring of parameters resulting in damage to or destruction of the generator and/or personal injury or death.

Voltage Measurement

```
Volt.-Measuring
-----
```

This screen only affects the displayed values. The protective functions are defined below.

Voltage measuring

Phase to phase/phase neutral

This parameter determines how the voltage is to be measured. If this parameter is set to "Phase to phase", the configuration screen "Volt.-Monitoring" in section Type of Monitoring on page 40 does not appear.

Potential Transformer Configuration

Units with Package GP

```
Volt.transformer
secondary 000V
```

Potential transformer secondary

[1] 50 to 125 V; [4] 50 to 480 V

The potential transformer secondary voltage is set here in V. This parameter is utilized to calculate the system voltage in the display. For voltages measured without a potential transformer, secondary and primary voltage must be configured the same.

```
Volt.transformer
primary 00.000kV
```

Potential transformer primary

00.100 to 65.000 kV

The potential transformer primary voltage is set here in kV. This entry is used to show the system voltage in the display.

Example: If a voltage of 400 V is measured without a potential transformer, the secondary transformer voltage must be configured to **400V** and the primary transformer voltage must be configured to **00.400V**.

Units with Packages GPX / GPX-I / GPY-I / GPY-I-N / K08

Volt.transformer sec.(GN) 000V

Generator potential transformer secondary [1] 50 to 125 V; [4] 50 to 480 V

The potential transformer secondary voltage is set here in V. This parameter is utilized to calculate the system voltage in the display. For voltages measured without a potential transformer, secondary and primary voltage must be configured the same.

Volt.transformer prim(GN)00.000kV

Generator potential transformer primary 00.100 to 65.000 kV

The potential transformer primary voltage is set here in kV. This entry is used to show the system voltage in the display.

Volt.transformer sec.(MN) 000V

Mains potential transformer secondary [1] 50 to 125 V; [4] 50 to 480 V

The potential transformer secondary voltage is set here in V. This parameter is utilized to calculate the system voltage in the display. For voltages measured without a potential transformer, secondary and primary voltage must be configured the same.

Volt.transformer prim(MN)00.000kV

Mains potential transformer primary 00.100 to 65.000 kV

The potential transformer primary voltage is set here in kV. This entry is used to show the system voltage in the display.

Example: If a voltage of 400 V is measured without a potential transformer, the secondary transformer voltage must be configured to 400V and the primary transformer voltage must be configured to 00.400V.

Current Measurement

Current transf. 0000/0

Current transformer 1 to 9,999/{x} A

The input of the current transformer ratio is necessary for the indication and control of the actual monitored value. The current transformers ratio should be selected so at least 60% of the secondary current rating can be measured when the monitored system is at 100% of operating capacity (i.e. at 100% of system capacity a 5A CT should output 3A). If the current transformers are sized so that the percentage of the output is lower, the loss of resolution may cause inaccuracies in the monitoring and control functions and may affect the functionality of the control. The control may be ordered with either ../1 A or ../5 A current transformer inputs. The CT inputs will dictate how this parameter is displayed on the control. Information about the current transformers inputs may be found on the unit data plate.

{x} = 1.....MFR13x1B/xxx = Current transformer with ../1 A rated current
 {x} = 5.....MFR13x5B/xxx = Current transformer with ../5 A rated current

Rated Values (Packages GPX / GPX-I / GPY-I / GPY-I-N / K08)

Rated voltage 000V	Rated voltage [1] 5 to 125 V; [4] 10 to 480 V
	This parameter defines the system rated voltage. This will affect the permissible limits for synchronization (refer to Synchronization (Packages GPX / GPX-I / GPY-I / GPY-I-N / K08)" on page 38).
Rated frequency 00.0Hz	Rated frequency 40.0 to 70.0 Hz
	Enter the rated frequency of the generator (or the utility mains), which in most cases is 50 Hz or 60 Hz. This will affect the permissible limits for synchronization (refer to Synchronization (Packages GPX / GPX-I / GPY-I / GPY-I-N / K08)" on page 38).
Rated current 0000A	Rated current 10 to 9,999 A
	The system current rating is defined in this parameter. Percentage values in the protective functions refer to this parameter.

Power Measurement



NOTE

With a positive real power, a positive real current flows in the "k-I" direction in the CT. Positive reactive power means that with a positive effective direction, inductive reactive (lagging) current flows in the effective direction. If the control is connected to the terminals of a generator and if the outgoing circuits of the CT facing the generator are connected to "k", the unit shows a positive real power when the generator supplies real power. Refer to the explanation in the chapter "Direction of Power" on page 22.

Rated power 00000kW	Rated power 5 to 32,000 kW
	The rated power is configured here. The exact value of the rated power is absolutely vital. Many measurement, control, and monitoring functions refer to this value (e.g. the percentage input for the power protection).
Power measuring -----	Power measurement one-phase / three-phase
	<p>Power measurement may be configured as one-phase or three-phase. If "one-phase power measurement" is set, the current and the voltage in phase L1 are used for power measurement. If "three-phase power measurement" is set, all three-phase currents and the relevant voltages are used for power measurement.</p> <ul style="list-style-type: none"> • one-phase power measurement: $P = \sqrt{3} \times V_{L12} \times I_{L1} \times P.F (\cos\phi)$ • threephase power measurement: $P = V_{L1N} \times I_{L1} \times P.F (\cos\phi) + V_{L2N} \times I_{L2} \times P.F (\cos\phi) + V_{L3N} \times I_{L3} \times P.F (\cos\phi)$

Control Functions



Synchronization (Packages GPX / GPX-I / GPY-I / GPY-I-N / K08)

Output of the Signal "Systems are Synchronous"

After the control unit monitors voltages and frequencies are within permissible limits, it will issue a circuit breaker closure command to connect two systems. The closure command has a predefined minimum on time that is output to a relay. Relay 8 is dedicated to this function.

The maximum permissible limits are:

- Generator System (GN): 75% to 112.5% of the rated voltage
- Mains System (MN): 87% to 112.5% of the rated voltage

Function "Synchronization of systems"

The control unit calculates internally the electrical angle of advance to issue the circuit breaker closure command. The corresponding lead-time remains constant due to the inherent delay of the breaker regardless of the frequency differential of the two systems. If the voltage and frequency differential of the two systems are within permissible limits, the breaker closure command may be issued under the following conditions:

- The respective monitored voltages of the two systems must be greater than 75 % and less than 112.5 % of the configured rated voltage.
- The monitored voltage differential of the two systems must fall below the configured maximum permissible voltage differential.
- The monitored frequency differential of the two systems must fall below the configured maximum permissible frequency differential
- The electrical angle between two coincident phases must be smaller than the respective permissible error angle (slip-dependent, max. 8 °elec.).

Synchronous Networks

A network is considered as synchronous if the frequency difference between the systems is less than 0.02134 Hz. The unit also issues a breaker closure order for synchronous networks, as long as the electrical angle between the two systems does not exceed the maximum permissible phase angle and the monitored voltage differential is less than the configured maximum permissible voltage differential.

Configuration Screens

<p>Synchronizing functions ON</p>	<p>Synchronizing functions ON/OFF</p>
	<p>ON.....Synchronizing functions have been enabled. The subsequent screens of this function are displayed.</p> <p>OFF.....Synchronizing functions have been disabled. The subsequent screens of this function are not displayed.</p>
<p>Synchronization df max 0.00Hz</p>	<p>Maximum permissible positive slip frequency differential for synchr. 0.02 to 0.49 Hz</p>
	<p>This parameter defines the upper permissible frequency differential limit for synchronization. Prior to the control issuing a breaker closure command, the monitored frequency differential of the two systems must be less than the value configured here.</p> <p>Positive slip refers to the System (GN) frequency being greater than the System (MN) frequency.</p>
<p>Synchronization df min -0.00Hz</p>	<p>Maximum permissible negative slip frequency differential for synchr. 0.00 to -0.49 Hz</p>
	<p>This parameter defines the lower permissible frequency differential limit for synchronization. Prior to the control issuing a breaker closure command, the monitored frequency differential of the two systems must be greater than the value configured here.</p> <p>Negative slip refers to the System (GN) frequency being less than the System (MN) frequency.</p>
<p>Synchronization dV max = 00.0%</p>	<p>Maximum permissible voltage differential 0.1 to 15.0 %</p>
	<p>A close command will not be issued until the measured differential voltage of the two systems is less than the value configured here. An internal hysteresis of 12.5% of the value configured will be applied to eliminate relay chatter. The percentage configured here is a + or – value.</p>
<p>Synchronization Max phase < 00</p>	<p>Maximum permissible phase angle 1 to 60°</p>
	<p>The phase angle in synchronous networks must not exceed the value configured here to be able to energize the closing relay. If the value configured here is between 55° and 60°, the closing relay will not energize until the phase angle falls below 55°, but it will remain energized until the phase angle exceeds the configured value even if it is between 55° and 60°.</p>
<p>Synchronization Time pulse>000ms</p>	<p>Minimum pulse time of the breaker close relay 50 to 250 ms</p>
	<p>The duration of the breaker closure command is defined by this parameter. The length of the pulse can be adjusted to the requirements of the individual breaker. The configured value defines the minimum on time of the pulse.</p>
<p>Gen.circ.breaker Pick-up t. 000ms</p>	<p>Breaker inherent delay 40 to 300 ms</p>
	<p>All breakers have an inherent delay. This is the time from when the closure command is issued until the breaker contacts are closed. This parameter defines that time. The control unit uses the time value configured here to determine when the breaker closure command is issued independent of the frequency differential. This permits the breaker contacts to close as close as possible to the synchronous point.</p>

Type of Monitoring



NOTE

The following screen will not be displayed, if the parameter "Volt.-Measuring" is configured to "Phase to phase" power measurement. (refer to Voltage Measurement on page 35).



Monitoring for

Phase-neutral/Phase to phase

The unit can either monitor the phase-neutral voltages (four-wire system) or the phase-phase voltages (three-wire system). Usually, for low-voltage system (400V-version) the phase-neutral voltages are monitored, while for the medium and high-voltage systems (100 V-version), the phase-phase voltages are monitored. The monitoring of the phase-phase voltages is recommended to avoid a phase-earth fault in a compensated or isolated mains resulting in the voltage protection tripping. The only effect on the screen "Voltage measuring" is the one described in the above note. The settings in the screen "**Volt.-Monitoring**" do have the following effects on the configuration screens:

Phase-neutral: The voltage at the terminals 1/2/3/4 is measured as a four-wire installation. All subsequent screens concerning voltage measuring refer to phase-neutral voltage (V_{Ph-N}). This is indicated in the configuration screens by the supplement [**Phase-N**].

Phase to phase: If the voltage system connected to the terminals 1/2/3/4 is a three-wire system, this setting must be selected. All subsequent screens concerning voltage measuring refer to phase-phase voltage (V_{Ph-Ph}). In the configuration screens, this is indicated by the supplement [**V(ph-ph)**].

Protection



Overvoltage Monitoring

Function: "Voltage not within permissible limits"

The monitored voltage in at least one phase is not within the configured permissible limits for overvoltage. The alarm message "Overvolt.1" or "Overvolt.2" will be displayed. This message **cannot** be suppressed with the discrete input "Blocking of protective functions / remote acknowledgement".

Overvoltage Monitoring ON

Overvoltage monitoring **ON/OFF**

ON..... Overvoltage monitoring is enabled. The subsequent screens of this function are displayed.
OFF..... Overvoltage monitoring is disabled. The subsequent screens of this function are not displayed.

Screen for Phase-neutral:
Overvoltage 1 (Phase-N) >000V

Threshold overvoltage level 1 **(Phase-phase) [1] 20 to 150 V; [4] 20 to 520 V (Phase-neutral) [1] 10 to 87 V; [4] 10 to 300 V**

Screen for Phase to phase:
Overvoltage 1 V(ph-ph) >000V

Overvoltage (level 1) is defined by this parameter. If this limit is reached or exceeded, the unit outputs the message "Overvolt.1". If a relay was assigned to this function in the relay manager, that relay will be energized.

Overvoltage 1 Delay 00.00s

Pickup delay, level 1 **0.02 to 99.98 s**

In order to initiate an overvoltage (level 1) alarm, the measured voltage must exceed and remain above the configured threshold without interruption for at least the period of time specified in this screen.

Screen for Phase-neutral:
Overvoltage 2 (Phase-N) >000V

Threshold overvoltage level 2 **(Phase-phase) [1] 20 to 150 V; [4] 20 to 520 V (Phase-neutral) [1] 10 to 87 V; [4] 10 to 300 V**

Screen for Phase to phase:
Overvoltage 2 V(ph-ph) >000V

Overvoltage (level 2) is defined by this parameter. If this limit is reached or exceeded, the unit outputs the message "Overvolt.2". If a relay was assigned to this function in the relay manager, that relay will be energized.

Overvoltage 2 Delay 00.00s

Pickup delay, level 2 **0.02 to 99.98 s**

In order to initiate an overvoltage (level 2) alarm, the measured voltage must exceed and remain above the configured threshold without interruption for at least the period of time specified in this screen.

Overvoltage Hysteresis 00V

Hysteresis for the overvoltage monitoring, levels 1 + 2 **0 to 99 V**

In order to prevent system fluctuations from continually initiating overvoltage alarms (both levels), a lower release point is defined here. If the control monitors the voltage above the permissible limit, the voltage must drop below that threshold and the voltage level defined here for the fault condition to be recognized as no longer existing.

Example: If a 480 V system has an overvoltage limit of 510 V and a hysteresis of 10 V, the monitored voltage for an overvoltage alarm must drop below 500 V to reset the alarm.

Undervoltage Monitoring

Function: "Voltage not within permissible limits"

The monitored voltage in at least one phase is not within the configured permissible limits for undervoltage. The alarm message "Und.volt.1" or "Und.volt.2" will be displayed. This message **cannot** be suppressed with the discrete input "Blocking of protective functions / remote acknowledgement".

Undervoltage Monitoring ON

Undervoltage monitoring **ON/OFF**

ONUndervoltage monitoring is enabled. The subsequent screens of this function are displayed.

OFFUndervoltage monitoring is disabled. The subsequent screens of this function are not displayed.

Screen for Phase-neutral:

Undervoltage 1 (Phase-N) <000V

Screen for Phase to phase:

Undervoltage 1 V(ph-ph) <000V

Threshold undervoltage level 1 **(Phase-phase) [1] 20 to 150 V; [4] 20 to 520 V (Phase-neutral) [1] 10 to 87 V; [4] 10 to 300 V**

Undervoltage (level 1) is defined by this parameter. If this limit is reached or fallen below, the unit outputs the message " **Und.volt.1**". If a relay was assigned to this function in the relay manager, that relay will be energized.

Undervoltage 1 Delay 00.00s

Pickup delay, level 1 **0.02 to 99.98 s**

In order to initiate an undervoltage (level 1) alarm, the measured voltage must fall below and remain below the configured threshold without interruption for at least the period of time specified in this screen.

Screen for Phase-neutral:

Undervoltage 2 (Phase-N) <000V

Screen for Phase to phase:

Undervoltage 2 V(ph-ph) <000V

Threshold undervoltage level 2 **(Phase-phase) [1] 20 to 150 V; [4] 20 to 520 V (Phase-neutral) [1] 10 to 87 V; [4] 10 to 300 V**

Undervoltage (level 2) is defined by this parameter. If this limit is reached or fallen below, the unit outputs the message " **Und.volt.2**". If a relay was assigned to this function in the relay manager, that relay will be energized.

Undervoltage 2 Delay 00.00s

Pickup delay, level 2 **0.02 to 99.98 s**

In order to initiate an undervoltage (level 2) alarm, the measured voltage must fall below and remain below the configured threshold without interruption for at least the period of time specified in this screen.

Undervoltage Hysteresis 00V

Hysteresis for the undervoltage monitoring, levels 1 + 2 **0 to 99 V**

In order to prevent system fluctuations from continually initiating undervoltage alarms (both levels), a higher release point is defined here. If the control monitors the voltage below the permissible limit, the voltage must rise above that threshold and the voltage level defined here for the fault condition to be recognized as no longer existing.

Example: If a 480 V system has an undervoltage limit of 440 V and a hysteresis of 10 V, the monitored voltage for an overvoltage alarm must rise above 450 V to reset the alarm.

Zero Voltage Monitoring

Function: "Voltage within permissible limits"

All three phases of the measured voltages are below the configured limit for a zero voltage condition. This function may be used for dead bus detection and as a release signal to permit dead bus closure of the circuit breaker. This message **cannot** be blocked with the discrete input "Blocking of protective functions / remote acknowledgement". The control unit does not display a message for this condition.

Zero-voltage Monitoring ON	Zero voltage monitoring ON/OFF
	ONZero voltage monitoring is enabled. The subsequent screens of this function are displayed.
	OFFZero voltage monitoring is disabled. The subsequent screens of this function are not displayed.
Zero-voltage -----	Monitoring type of the zero voltage monitoring Busbar 1ph / Generator 3ph
	Busbar 1ph ..Zero voltage monitoring is performed by measuring two phases on the busbar.
	Generator 3ph Zero voltage monitoring is performed by measuring three phases on the generator.
Zero-voltage V(ph-ph) <000V	Zero voltage threshold 8 to 150 V
	The threshold for detecting a zero voltage condition is defined by this parameter. If this limit is reached or fallen below, the unit does not display a message. If a relay was assigned to this function in the relay manager, that relay will be energized.
Zero-voltage Delay 00.00s	Pickup delay 0.02 to 99.98 s
	In order to for the control to recognize a zero voltage condition, the measured voltage must fall below and remain below the configured threshold without interruption for at least the period of time specified in this screen.
Zero-voltage Hysteresis 00V	Hysteresis for the zero voltage monitoring 0 to 99 V
	In order to prevent system fluctuations from continually initiating a zero voltage condition, a higher release point is defined here. If the control monitors the voltage below the permissible limit, the voltage must rise above that threshold plus the voltage level defined here for the fault condition to be recognized as no longer existing.
Release delay Zerovolt. 00.00s	Release delay 0.02 to 99.98 s
	To ensure that the signal relay resets after a zero voltage conditions has occurred, the zero voltage threshold (including the hysteresis) must be exceeded without interruption for the time specified by this parameter. The control will auto-acknowledge a zero voltage condition regardless of how "Autoclearing Relays" is configured.



NOTE

A message is not displayed on the screen for zero voltage conditions.

Voltage Asymmetry Monitoring

The phase-phase voltages are monitored.

Function "Voltage asymmetry not within permissible limits"

The monitored phase-phase voltage differential in the three phases is not within the configured permissible limits for asymmetry (asymmetric voltage vectors; the threshold corresponding to the differential value). The alarm message "**Asymmetry**" will be displayed. This message can be suppressed with the discrete input "Blocking of protective functions / remote acknowledgement".

Asymmetry-
Monitoring ON

Asymmetry monitoring **ON/OFF**

ONVoltage asymmetry monitoring is enabled. The subsequent screens of this function are displayed.

OFFVoltage asymmetry monitoring is disabled. The subsequent screens of this function are not displayed.

Asymmetry
Response v. 00V.

Maximum permissible asymmetry **0 to 99 V**

The maximum voltage asymmetry is defined by this parameter. If this limit is reached or exceeded, the unit outputs the message "**Asymmetry**". If a relay was assigned to this function in the relay manager, that relay will be energized.

Asymmetry
Delay 00.00s

Pickup delay **0.02 to 99.98 s**

In order to initiate a voltage asymmetry alarm, the measured voltage differential must rise above and remain above the configured threshold without interruption for at least the period of time specified in this screen.

Asymmetry
Hysteresis 00V

Hysteresis for the asymmetry monitoring **0 to 99 V**

In order to prevent system fluctuations from continually initiating a voltage asymmetry fault, a lower release point is defined here. If the control monitors the voltage asymmetry beyond the permissible limit, the voltage differential must fall below that threshold plus the voltage level defined here for the fault condition to be recognized as no longer existing.

Overfrequency Monitoring

The frequency monitoring is performed on two levels. The frequency measuring is monitored three-phase if all voltages are greater than 15 % of the rated value (100 V or 400 V). This ensures quick and precise measurement of the frequency. The frequency is still monitored correctly even if voltage is only applied to one phase.

Function "Frequency not within permissible limits"

The monitored frequency is not within the configured permissible limits for overfrequency. The alarm message "Overfreq.1" or "Overfreq.2" will be displayed. This message **cannot** be suppressed with the discrete input "Blocking of protective functions / remote acknowledgement".

Overfrequency-Monitoring ON	Overfrequency Monitoring ON/OFF
	<p>ON..... Overfrequency monitoring is enabled. The subsequent screens of this function are indicated.</p> <p>OFF..... Overfrequency monitoring is disabled. The subsequent screens of this function are not displayed.</p>
Overfrequency 1 f > 00.00Hz	Threshold overfrequency, level 1 40.00 to 80.00 Hz
	<p>Overfrequency (level 1) is defined by this parameter. If this limit is reached or exceeded, the unit outputs the message "Overfreq.1". If a relay was assigned to this function in the relay manager, that relay will be energized.</p>
Overfrequency 1 Delay 00.00s	Pickup delay, level 1 0.02 to 99.98 s
	<p>In order to initiate an overfrequency (level 1) alarm, the measured frequency must exceed and remain above the configured threshold without interruption for at least the period of time specified in this screen.</p>
Overfrequency 2 f > 00.00Hz	Threshold overfrequency, level 2 40.00 to 80.00 Hz
	<p>Overfrequency (level 2) is defined by this parameter. If this limit is reached or exceeded, the unit outputs the message "Overfreq.2". If a relay was assigned to this function in the relay manager, that relay will be energized.</p>
Overfrequency 2 Delay 00.00s	Pickup delay, level 2 0.02 to 99.98 s
	<p>In order to initiate an overfrequency (level 2) alarm, the measured frequency must exceed and remain above the configured threshold without interruption for at least the period of time specified in this screen.</p>
Overfrequency Hysteres. 0.00Hz	Hysteresis for the overfrequency monitoring, levels 1+2 0.01 to 9.99 Hz
	<p>In order to prevent system fluctuations from continually initiating overfrequency alarms (both levels), a lower release point is defined here. If the control monitors the frequency above the permissible limit, the frequency must drop below that threshold and the frequency level defined here for the fault condition to be recognized as no longer existing.</p> <p>Example: If a 60 Hz system has an overfrequency limit of 70 Hz and a hysteresis of 5 Hz, the monitored frequency for an overfrequency alarm must fall below 65 Hz to reset the alarm.</p>

Underfrequency Monitoring

The frequency monitoring is performed on two levels. The frequency measuring is monitored three-phase if all voltages are greater than 15 % of the rated value (100 V or 400 V). This ensures quick and precise measurement of the frequency. The frequency is still monitored correctly even if voltage is only applied to one phase.

Function "Frequency not within permissible limits"

The monitored frequency is not within the configured permissible limits for overfrequency. The alarm message "Und. freq. 1" or "Und. freq. 2" will be displayed. This message can be suppressed with the discrete input "Blocking of protective functions / remote acknowledgement".

Underfrequency-Monitoring ON

Underfrequency Monitoring **ON/OFF**

ONUnderfrequency monitoring is enabled. The subsequent screens of this function are indicated.
OFFUnderfrequency monitoring is disabled. The subsequent screens of this function are not displayed.

Underfrequency 1
f < 00.00Hz

Threshold underfrequency, level 1 **40.00 to 80.00 Hz**

Underfrequency (level 1) is defined by this parameter. If this limit is reached or fallen below, the unit outputs the message "Und. freq. 1". If a relay was assigned to this function in the relay manager, that relay will be energized.

Underfrequency 1
Delay 00.00s

Pickup delay, level 1 **0.02 to 99.98 s**

In order to initiate an underfrequency (level 1) alarm, the measured frequency must fall below and remain below the configured threshold without interruption for at least the period of time specified in this screen.

Underfrequency 2
f < 00.00Hz

Threshold underfrequency, level 2 **40.00 to 80.00 Hz**

Underfrequency (level 2) is defined by this parameter. If this limit is reached or fallen below, the unit outputs the message "Und. freq. 2". If a relay was assigned to this function in the relay manager, that relay will be energized.

Underfrequency 2
Delay 00.00s

Pickup delay, level 2 **0.02 to 99.98 s**

In order to initiate an underfrequency (level 2) alarm, the measured frequency must fall below and remain below the configured threshold without interruption for at least the period of time specified in this screen.

Underfrequency
Hysteres. 0.00Hz

Hysteresis for the underfrequency monitoring, levels 1 + 2 **0.01 to 9.99 Hz**

In order to prevent system fluctuations from continually initiating underfrequency alarms (both levels), a higher release point is defined here. If the control monitors the frequency below the permissible limit, the frequency must rise above that threshold and the frequency level defined here for the fault condition to be recognized as no longer existing.

Example: If a 60 Hz system has an underfrequency limit of 50 Hz and a hysteresis of 5 Hz, the monitored frequency for an overfrequency alarm must rise above 55 Hz to reset the alarm.

Independent Time-Overcurrent Monitoring



NOTE

All percentage values of the current refer to the rated current (page 37).

Function: Current is monitored depending on parameter "Overcurrent Monitoring". The time-overcurrent alarm contains three limits and can be setup as a step definite time overcurrent alarm as illustrated in the figure below. Monitoring of the maximum phase current is performed in three steps. Every step can be provided with a delay time independent of the other steps.




Figure 6-1: Diagram for independent time-overcurrent monitoring

Overcurrent Monitoring	ON
------------------------	----

Independent time-overcurrent monitoring

ON/OFF

ON.....Independent time-overcurrent monitoring is enabled. The subsequent screens of this function are displayed.

OFF.....Independent time-overcurrent monitoring is disabled. The subsequent screens of this function are not displayed.

Overcurrent 1	I > 000%
---------------	----------

Threshold independent time-overcurrent, level 1

0 to 300 %

Overcurrent (level 1) is defined by this parameter. The percentage configured in this parameter refers to the configured rated system current (refer to page 36). If this limit is reached or exceeded, the unit outputs the message "**overcurrent 1**". If a relay was assigned to this function in the relay manager, that relay will be energized.

Overcurrent 1	Delay	00.00s
---------------	-------	--------

Pickup delay, level 1

0.02 to 99.98 s

In order to initiate an overcurrent (level 1) alarm, the measured current must exceed and remain above the configured level 1 threshold without interruption for at least the period of time specified in this screen.

Overcurrent 2
I> 100%

Threshold independent time-overcurrent, level 2 **0 to 300 %**

Overcurrent (level 2) is defined by this parameter. The percentage configured in this parameter refers to the configured rated system current (refer to page 36). If this limit is reached or exceeded, the unit outputs the message "**overcurrent 2**". If a relay was assigned to this function in the relay manager, that relay will be energized.

Overcurrent 2
Delay 00.00s

Pickup delay, level 2 **0.02 to 99.98 s**

In order to initiate an overcurrent (level 2) alarm, the measured current must exceed and remain above the configured level 2 threshold without interruption for at least the period of time specified in this screen.

Overcurrent 3
I> 100%

Threshold independent time-overcurrent, level 3 **0 to 300 %**

Overcurrent (level 3) is defined by this parameter. The percentage configured in this parameter refers to the configured rated system current (refer to page 36). If this limit is reached or exceeded, the unit outputs the message "**overcurrent 3**". If a relay was assigned to this function in the relay manager, that relay will be energized.

Overcurrent 3
Delay 00.00s

Pickup delay, level 3 **0.02 to 99.98 s**

In order to initiate an overcurrent (level 3) alarm, the measured current must exceed and remain above the configured level 3 threshold without interruption for at least the period of time specified in this screen.

Overcurrent
Hysteresis 000%

Hysteresis for the independent time-overcurrent monitoring, levels 1, 2 + 3 **1 to 300 %**

In order to prevent system fluctuations from continually initiating overcurrent alarms (levels 1, 2 + 3), a lower release point is defined here. If the control monitors the current above the permissible limit, the current must drop below that threshold and the current level defined here for the fault condition to be recognized as no longer existing.

Example: If a 1000A system has an overcurrent limit 1 of 110% (1100A) and a hysteresis of 105% (1050A), the monitored current for an overcurrent alarm must drop below 1050A to reset the alarm.

Inverse Time-Overcurrent Monitoring



NOTE

All percentage indications of the current refer to the rated current (see page 37).

Function: Monitoring of overcurrents including inversely proportional time dependent tripping characteristic. The selected trip curve defines the tripping time according to the measured current. The tripping time will be decreased according to a defined curve the higher the measured current is. According to IEC 255 three different characteristics are available.

Normal inverse:
$$t = \frac{0.14}{(I/I_p)^{0.02} - 1} * t_p [s]$$

Very inverse:
$$t = \frac{13.5}{(I/I_p) - 1} * t_p [s]$$

Extremely inverse:
$$t = \frac{80}{(I/I_p)^2 - 1} * t_p [s]$$

Formula definitions:	t:	tripping time
	t_p	time set point value
	I	fault current / monitored current
	I_n	rated (nominal) current
	I_p	current set point value

If t is greater than 162 s the system trips at 162 s. If t is lower than t_{min} the tripping time is t_{min} . The reaction time for t_{min} depends on the time it takes to monitor the fault and the operating time of the relays. t_{min} is at least 20 ms.

Please consider during configuration:

for I_{start} : $I_{start} > I_n$ and $I_{start} > I_p$
 for I_p the smaller I_p is, the steeper is the slope of the tripping curve

Configuration Screens

Inv.time ov.cur.
Monitor. ON

Inverse time-overcurrent monitoring ON/OFF

ONInverse time-overcurrent monitoring is enabled. The subsequent screens of this function are displayed.

OFFInverse time-overcurrent monitoring is disabled. The subsequent screens of this function are not displayed.

Inv.time char.

Inverse time-overcurrent: characteristic Normal / High / Extreme

Normal "Normal inverse" characteristic used

High "Very inverse" characteristic used

Extreme "Extremely inverse" characteristic used

Inv.time ov.cur.
Tp=0.00s

Inverse time-overcurrent: time constant Tp 0.01 to 1.99s

The time constant for t_p is defined by this parameter.

Inv.time ov.cur.
Ip=0.0*In

Inverse time-overcurrent: current constant Ip 0.1 to 3.0*In

The current constant for I_p is defined by this parameter. This set point is dependent upon the rated current (I_n)

Inv.time ov.cur.
I start= 0.00*In

Inverse time-overcurrent: I Start 1 to 3.00*In

The lower tripping value for inverse time-overcurrent protection is defined by this parameter. If the monitored current (I) is below I_{Start} , the inverse time-overcurrent protection does not trip. I_p is used as the lower tripping value if I_{Start} is configured less than I_p .

Characteristics




Figure 6-2: Inverse time-overcurrent - characteristic "normal inverse"




Figure 6-3: Inverse time-overcurrent - characteristic "very inverse"




Figure 6-4: Inverse time-overcurrent - characteristic "extremely inverse"

Inverse Time-Overcurrent Monitoring with Voltage Restraint



NOTE

This monitoring function is an additional functionality for the inverse time overcurrent monitoring function. If the inverse time overcurrent monitoring is disabled, time-overcurrent monitoring with voltage restraint is disabled too.

All percentage indications of the current are in relation to the rated current (see page 37).

Function: This function is recommended for a generator that must be monitored with droop excitation and precautions for short-circuit excitation (e.g. supplementary components) are not available. A short-circuit close to the terminal may be caused due to the low voltage excitation cannot be maintained. As a result, the unit cannot maintain power in order to initiate a voltage independent overcurrent delay. The voltage restraint functionality reduces the overcurrent threshold of the inverse time overcurrent monitoring function proportionally with the monitored voltage if this function is enabled. If the monitored voltage falls below the threshold defined by the knee curve setting, the overcurrent threshold remains at the value of the knee curve setting. The reduction of the inverse time threshold occurs according to Figure 6-5.

Current L1: corresponds to voltage L1-L2

Current L2: corresponds to voltage L2-L3

Current L3: corresponds to voltage L3-L1




Figure 6-5: Characteristic of the inverse time-overcurrent monitoring with voltage restraint (knee curve setting 20 %)

- Legend:
- I_a Adjusted current threshold value
 - I_p Configured value (configured with inverse time overcurrent monitoring)
 - V_n Rated voltage
 - V Monitored voltage

Example:

Initial conditions:

Rated voltage $V_n = 100 \text{ V}$

Configured value $I_p = 2.0 * 5 \text{ A} = 10 \text{ A}$ (rated current $I_n = 5 \text{ A}$)

Case 1 (monitored voltage $V > 90\% V_n$):

As long as the monitored voltage exceeds 90% of the rated voltage, the configured value will not be adjusted.

-> $I_a = I_p$

Case 2 (monitored voltage $V < 90\% V_n$, but actual voltage $V >$ knee curve setting):

If the monitored voltage falls below 90% of the rated voltage, the configured value is adjusted proportionally with the ratio of monitored and rated voltage.

-> $I_a = (V/V_n) * I_p$

Case 3 (monitored voltage $V <$ knee curve setting):

If the monitored voltage falls below the percentage value of the rated voltage configured by the knee curve setting, the configured value is adjusted to the proportional value at the knee curve setting.

-> $I_a = \{(\text{knee point setting in } [\%])/100\} * I_p$

If the knee curve setting is configured to 20% for example and the monitored voltage is lower than 20% of the rated voltage, the adjusted value I_a falls not below 20% of the configured value I_p .

Inv.time ov.cur. V-restr. ON

Inverse time-overcurrent monitoring with voltage restraint **ON/OFF**

ON..... Inverse time-overcurrent monitoring with voltage restraint is enabled. The subsequent screens of this function are displayed.

OFF..... Inverse time-overcurrent monitoring with voltage restraint is disabled. The subsequent screens of this function are not displayed.

Inv.time ov.curr knee curve U>00%

Threshold inverse time-overcurrent with voltage restraint **10 to 90 %**

The threshold limit for the voltage is defined in this parameter. The knee of the curve describes the lower limit of the threshold value lowering, i.e. the trip current belonging to this limit remains valid and will not be lowered further in case of an additional voltage drop.

Ground Fault Monitoring, Calculated (Packages GP / K08)

Ground fault monitoring for low-impedance or solidly grounded systems.

Function: The ground fault monitoring can be configured for two threshold limits. The third harmonics single-phase components may result in false currents being monitored on the grounding circuit. A digital anti-aliasing filter is utilized to separate these harmonics and prevent inaccurate values caused by harmonics from being displayed. If the actual sine wave of the ground current exceeds the configured threshold, an alarm message is displayed. This message can be suppressed with the discrete input "Blocking of protective functions / remote acknowledgement".

Acquiring the measured value:

- The ground current is measured by calculating the vectorial sum of the three monitored phase currents. The current transformer should be sized so that the configured ground current threshold is at least 10% of the transformer's current rating to ensure proper operation.

Earth current monitoring ON

Ground fault monitoring ON/OFF

ONGround fault monitoring is enabled. The subsequent screens of this function are displayed.

OFFGround fault monitoring is disabled. The subsequent screens of this function are not displayed.

Earth current 1 Response = 000%

Threshold ground fault, level 1 10 to 300 %

Ground fault current (level 1) is defined by this parameter. The percentage configured here refers to the configured rated current (refer to page 36). If this limit is reached or exceeded, the unit outputs the message "**Earthcur.1**". If a relay was assigned to this function in the relay manager, that relay will be energized.

Earth current 1 Delay 00.00s

Pickup delay, level 1 0.02 to 99.98 s

In order to initiate a ground fault current (level 1) alarm, the measured ground fault current must exceed and remain above the configured threshold without interruption for at least the period of time specified in this screen.

Earth current 2 Response = 000%

Threshold ground fault, level 2 10 to 300 %

Ground fault current (level 2) is defined by this parameter. The percentage configured here refers to the configured rated current (refer to page 36). If this limit is reached or exceeded, the unit outputs the message "**Earthcur.2**". If a relay was assigned to this function in the relay manager, that relay will be energized.

Earth current 2 Delay 00,00s

Pickup delay, level 2 0.02 to 99.98 s

In order to initiate a ground fault current (level 2) alarm, the measured ground fault current must exceed and remain above the configured threshold without interruption for at least the period of time specified in this screen.

Earth current Hysteresis 000%

Hysteresis for the ground fault monitoring, levels 1+2 1 to 300 %

In order to prevent system fluctuations from continually initiating ground fault current alarms (levels 1 & 2), a lower release point is defined here. If the control monitors the current above the permissible limit, the current must drop below that threshold and the current level defined here for the fault condition to be recognized as no longer existing.

Example: If a 1000A system has a ground fault current limit 1 of 5% (50A) and a hysteresis of 2% (20A), the monitored current for a ground fault current alarm must drop below 20A to reset the alarm.

Overload Monitoring



NOTE

All percentage values refer to a percentage of the configured rated power (page 37).

Function: "Positive active load not within the permissible range"

The single-phase or three-phase active load is above the configured limit for overload. The message "**overload**" is displayed. This message can be suppressed with the discrete input "Blocking of protective device / remote acknowledgement".

Overload Monitoring ON

Overload monitoring **ON/OFF**

ON..... Overload monitoring is enabled. The subsequent screens of this function are displayed.

OFF..... Overload monitoring is disabled. The subsequent screens of this function are not displayed.

Overload Response v.000%

Threshold overload **0 to 150 %**

The overload threshold is defined by this parameter. The percentage configured here refers to the configured rated power (refer to page 37). If this limit is reached or exceeded, the unit outputs the message "**overload**". If a relay was assigned to this function in the relay manager, that relay will be energized.

Overload Delay time 000s

Pickup delay **0 to 300 s**

In order to initiate an overload alarm, the measured active load must exceed and remain above the configured threshold without interruption for at least the period of time specified in this screen.

Overload Hysteresis 00%

Hysteresis for the overload monitoring **0 to 99 %**

In order to prevent system fluctuations from continually initiating overload alarms, a lower release point is defined here. If the control monitors the active load above the permissible limit, the load must drop below the percentage of the rated load defined here for the fault condition to be recognized as no longer existing.

Example: If a 100kW rated system has an overload limit of 120% (120kW) and a hysteresis of 95% (95kW), the monitored load for an overload alarm must drop below 95kW to reset the alarm.

Reverse/Reduced Power Monitoring



NOTE

All percentage values refer to a percentage of the configured rated power (page 37).

Function: "Active power not within the permissible range"

The generator power limits may be configured as reduced power or reverse power depending on the threshold value configured in the control. If the single-phase or three-phase measured real power is below the adjusted limit of the reduced load or below the adjusted value of the reverse power, an alarm will be issued. The message "Rev. Power" appears. This message can be suppressed with the discrete input "Blocking of protective device / remote acknowledgement".

Reverse/min.pow.
Monitoring ON

Reverse/reduced power monitoring ON/OFF

- ONReverse/reduced power monitoring is enabled. The subsequent screens of this function are displayed.
- OFFReverse/reduced power monitoring is disabled. The subsequent screens of this function are not displayed.

Reverse/min.pow.
-00%

Threshold reverse/reduced power -99 to 99 %

- Reverse power monitoring:** If the direction of the active power reverses and the measured power value falls below the configured negative percentage value, the unit issues the message "Rev. Power".
- Reduced power monitoring:** If the measured power falls below the configured positive percentage value, the unit issues the message "Rev. Power".

If a relay was assigned to this function in the relay manager, that relay will be energized.

Reverse/min.pow.
Delay 00.00s

Pickup delay 0.02 to 99.98 s

In order to initiate an reverse/reduced power alarm, the measured active load must exceed and remain above the configured threshold without interruption for at least the period of time specified in this screen.

Reverse/min.pow.
Hysteresis 00%

Hysteresis for the reverse/reduced power monitoring 0 to 99 %

In order to prevent system fluctuations from continually initiating reverse/reduced power alarms, a lower release point is defined here. If the control monitors the active load above the permissible limit, the load must drop below the percentage of the rated load defined here for the fault condition to be recognized as no longer existing.

Unbalanced Load Monitoring



NOTE

All percentage values refer to a percentage of the configured rated power (page 37).

Function: "Unbalanced load not within the permissible range"

The percentage threshold value indicates the permissible variation of phase current from the arithmetic mean value of all three-phase currents. If the measured value is greater than the threshold, the message "**Unbalance**" appears. This message can be suppressed with the discrete input "Blocking of protective device / remote acknowledgement".

Unbalanced load Monitoring ON

Unbalanced load monitoring	ON/OFF
-----------------------------------	---------------

- ON**..... Unbalanced load monitoring is enabled. The subsequent screens of this function are displayed.
- OFF**..... Unbalanced load monitoring is disabled. The subsequent screens of this function are not displayed.

Unbalanced load Response v. 000%

Maximum permissible unbalanced load	0 to 100 %
--------------------------------------------	-------------------

The maximum unbalanced load refers to the measured three-phase currents. If an asymmetrical load causes the phase currents to exceed the configured percentage for the configured time, the unit displays the alarm message "**Unbalance**". If a relay was assigned to this function in the relay manager, that relay will be energized.

Unbalanced load Delay 00.00s

Pickup delay	0.02 to 99.98 s
---------------------	------------------------

In order to initiate an unbalanced load alarm, the measured active load must exceed and remain above the configured differential threshold without interruption for at least the period of time specified in this screen.

Unbalanced load Hysteresis 00%

Hysteresis for the unbalanced load monitoring	1 to 20 %
------------------------------------------------------	------------------

In order to prevent system fluctuations from continually initiating unbalanced load alarms, a lower release point is defined here. If the control monitors the active load above the permissible differential limit, the load must drop below the load differential percentage defined here for the fault condition to be recognized as no longer existing.

Reactive Power Monitoring



NOTE

All percentage values refer to a percentage of the configured rated power (page 37).

Function: "Reactive power not within the permissible range"

The control may monitor the reactive power and provide protection against excessive inductive (over excitation) or capacitive (under excitation) load conditions. The control will display "React.pow+" or "React.pow-" if the inductive or capacitive load has exceeded the permissible limits. This message can be suppressed with the discrete input "Blocking of protective device / remote acknowledgement".

Reactive power
Monitoring ON

Reactive power monitoring ON/OFF

- ON.....Reactive power monitoring is enabled. The subsequent screens of this function are displayed.
- OFF.....Reactive power monitoring is disabled. The subsequent screens of this function are not displayed.

Cap. react. pow.
Response v.000%

Threshold reactive power, capacitive 0 to 100 %

The capacitive reactive power threshold is defined by this parameter. The percentage configured here refers to the configured rated power (refer to page 37). If this limit is reached or exceeded, the unit outputs the message "React.pow-". If a relay was assigned to this function in the relay manager, that relay will be energized.

Cap. react. pow.
Delay 00.00s

Pickup delay 0.02 to 99.98 s

In order to initiate a capacitive reactive power alarm, the measured capacitive reactive load must exceed and remain above the configured differential threshold without interruption for at least the period of time specified in this screen.

Ind. react. pow.
Response v.000%

Threshold reactive power, inductive 0 to 100 %

The inductive reactive power threshold is defined by this parameter. The percentage configured here refers to the configured rated power (refer to page 37). If this limit is reached or exceeded, the unit outputs the message "React.pow+". If a relay was assigned to this function in the relay manager, that relay will be energized.

Ind. react. pow.
Delay 00.00s

Pickup delay 0.02 to 99.98 s

In order to initiate an inductive reactive power alarm, the measured inductive reactive load must exceed and remain above the configured differential threshold without interruption for at least the period of time specified in this screen.

React. pow. mon.
Hysteresis 00%

Hysteresis for the reactive power monitoring 1 to 20 %

In order to prevent system fluctuations from continually initiating reactive power alarms, a lower release point is defined here. If the control monitors the capacitive or reactive load above the permissible limit, the reactive load must drop below the percentage defined here for the fault condition to reset for the fault condition to be recognized as no longer existing.

Relay Configuration



NOTE

Clearing of faults and fault messages from the control unit will depend on the parameters "External clearing", "Auto-clearing Relays", and "Auto-clearing Display". These three parameters will influence the other depending on how each is configured. This is explained in the following text.

External Clearing	ON
-------------------	----

External acknowledgement of the relays via the discrete input "Blocking of protective functions / remote acknowledgement".

Acknowledgement via the discrete input ON/OFF

"Auto-clearing Relays" configured "OFF" (refer to "Auto Acknowledgement of the Relay" on page 59):

- OFF**..... Alarms that cannot be blocked with discrete input "Blocking of protective functions / remote acknowledgement" will not be reset when the fault condition is no longer present. Pressing the "Clear" button resets the relays.
- ON**..... All alarms are reset when the discrete input "Blocking of protective functions / remote acknowledgement" (terminals 5/6) is energized. Alarms which cannot be blocked with the discrete input "Blocking of protective functions / remote acknowledgement" are only reset after the fault condition is no longer present.

"Auto-clearing Relays" configured "ON" (refer to "Auto Acknowledgement of the Relay" on page 59):

- OFF**..... Pressing the "Clear" button resets the displayed fault messages.
- ON**..... All displayed fault messages are reset when the discrete input "Blocking of protective functions / remote acknowledgement" (terminals 5/6) is energized. Alarms which cannot be blocked with the discrete input "Blocking of protective functions / remote acknowledgement" are only reset after the fault condition is no longer present.

Auto Acknowledgement of the Relays

Auto-clearing Relays	ON
----------------------	----

Relay auto acknowledgment ON/OFF

- ON**..... Automatic clearing of the relays is enabled. The relays are automatically reset when the fault condition is no longer detected. The alarm message in the display is cleared according to how the parameter **"Auto-clearing Display"** is configured.
- OFF**..... Automatic clearing of the relays is disabled. Pressing the "Clear" button resets the relays.

The alarm message in the display is cleared according to how the parameter **"Auto-clearing Display"** is configured. The subsequent screens of this function are not indicated.



NOTE

The subsequent screens are only visible if the parameter "Auto-clearing Relays" and the corresponding protective function are enabled and the control unit is equipped with the protective functionality.

Release delay xxxxxxxx 00.00s

Release delay of the relays 0.02 to 99.98 s

The individual relays will reset if "Auto-clearing relays" has been enabled and the monitored values have returned to the permissible limits plus / minus the hysteresis (depending on monitoring) without interruption for the time specified in this parameter. If the monitored value exceeds / falls below the threshold limit, the delay timer re-initiates its countdown. The following protective functions may have reset delays configured.

Release delay for ...		Display indication instead of xxxxxxxx	Remark
Overvoltage	Standard	Overvolt.	Level 1 and level 2
Undervoltage	Standard	Und.volt	Level 1 and level 2
Asymmetry	Standard	Asymmetry	
Overfrequency	Standard	Overfreq.	Level 1 and level 2
Underfrequency	Standard	Underfrq	Level 1 and level 2
Independent time-overcurrent	Standard	Overcurr.	Levels 1, 2, and 3
Inverse time-overcurrent	Standard	Curr. - Inv	
Inverse time-overcurrent with voltage restraint	Standard	Curr. - Inv	
Ground fault, calculated	Standard	Earth f.	Level 1 and level 2
Overload	Standard	Overload	
Reverse-/reduced power	Standard	Rev.power	
Unbalanced load	Standard	Unb. load	
Reactive power inductive	Standard	react.ind.	
Reactive power capacitive	Standard	react.cap.	

Table 6-1: Release delay of the relays

Auto Acknowledgement of Messages

Auto-clearing Display ON

Messages auto acknowledgment ON/OFF

- ON**After the alarm condition is no longer detected, the message in the display is deleted.
- OFF**The alarm message remains in the display after the fault condition is no longer detected until manually cleared. The subsequent screen of this function is not displayed.



NOTE

The subsequent parameter "Clearing display after " is not visible if "Auto-clearing Relays" is configured to "OFF".

Clearing display after 00s

Clear displayed message delay 1 to 99 s

Alarm messages, which have been enabled, will be acknowledged after this configured delay time expires. This delay will initiate once the measure value exceeds/falls below the threshold limit +/- the hysteresis

Changing the Relay Assignment

Change relay-
allocation? YES

Change relay assignment?

YES/NO

This parameter permits the user to change how the relay outputs are configured. Refer to the list of parameters.

YES..... The relay assignments can be configured and the user may define the relay functionality and assignments. The subsequent screens are displayed.

NO..... The relays are configured with the factory default settings. The subsequent screens are not displayed.



NOTE

All relay outputs are configured the same. The following is an example showing relays 1 through 3. Depending on the model purchased, the unit may have up to 7 configurable relays. The Packages GPX / GPX-I / GPY-I / GPY-I-N / K08 enable to use 4 additional relays.

Example: Relay 1 to 3

Funct. relay 123
(R=releases) RRR

Function of the relays 1, 2, and 3

E/R

The individual relays may be configured as either E=Energizes (Normally Open contacts) or R=Releases (Normally Closed contacts).

E..... The relay is configured as normally open (N.O.) contacts. The relay will energize only if the assigned monitoring function has tripped.

R..... The relay is configured as normally closed (N.C.) contacts. The relay is always energized and will only de-energize (release) if the assigned monitoring function has tripped.

NOTE Relay 1 is configured as R (release/N.C.) and cannot be modified.



NOTE

The following screen(s) will only be displayed if the unit is equipped with the corresponding protective function(s), the protective function is enabled, and the parameter "Change relay allocation" is enabled.

```
xxxxxxxxxxxxxxx
to relay      0000
```

Assign protective function output to relays

0 to 4/8

Each digit in this parameter is used to assign one relay to a protective function. Up to four relay outputs may be assigned to a protective function. The control may be configured as follows:

- 0**If the protective function is not assigned to a relay, a "0" must be configured in the display. None of the relay outputs will energize/de-energize when the corresponding protective function trips if all four relay assignments are configured with a "0". A message for the protective function will still be visible in the unit display.
- 1/2/3**Relay 1 (terminals 9/10), relay 2 (terminals 11/12/13), and/or relay 3 (terminals 14/15/16) are available for assignment to protective function on all units.
- 4/5/6/7**Relay 4 (terminals 19/20/21), relay 5 (terminals 22/23/24), relay 6 (terminals 25/26/27), and/or relay 7 (terminals 28/29/30) are available for assignment to protective function if the unit is equipped with either the [GPX / GPX-I / GPY-I / GPY-I-N / K08 Packages](#).

ExampleAn MFR 13/[GPX](#) has a protective function that is required to output a signal to relays 2,4, and 7. That protective function relay assignment should be configured as 2470. The sequence of the numbers has no significance in the functionality or operations.

A relay output may be assigned to more than one protective function. This will cause the relay to issue a signal when any of the configured protective functions trip. If a relay should only issue a signal when a specific protective function trips, then the relay must not be assigned to any other protective function.

Monitoring of ... output to relay		Indication on display instead of XXXXXXXXXX
Overvoltage, level 1 / 2	Standard	Overvoltage 1 / Overvoltage 2
Undervoltage, level 1 / 2	Standard	Undervoltage 1 / Undervoltage 2
Zero voltage	Standard	Zero-voltage.
Asymmetry	Standard	Asymmetry
Overfrequency, level 1 / 2	Standard	Overfrequency 1 / Overfrequency 2
Underfrequency, Level 1 / 2	Standard	Underfrequency 1 / Underfrequency 2
Independent time-overcurrent, level 1 / 2 / 3	Standard	Overcurrent 1 / 2 / 3
Inverse time-overcurrent	Standard	Inv.time ov.curr
Inverse time-overcurrent with voltage restraint	Standard	Inv.time ov.curr
Ground fault, calculated, level 1 / 2	Standard	Earth Fault 1 / Earth Fault 2
Overload	Standard	Overload
Reverse-/reduced power	Standard	Reverse/min.pow.
Unbalanced load	Standard	Unbalanced load
Reactive power, capacitive	Standard	Cap.react pow.
Reactive power, inductive	Standard	Ind.react pow.
Interface Fault	Packages GPX-I / GPY-I / GPY-I-N / K08	Interface Fault
Centralized alarm		Collect Response

Table 6-2: Protective function output to relay



NOTE

The "ready for operation" function is always assigned to relay 1. However, other protective functions may also be assigned to relay 1 additionally. Relay 1 is always configured as Normally Closed (break contact) and will de-energize if the unit is not ready for operation.

Pulse Output of the Positive Active Energy (Packages GPY-I / GPY-I-N)



NOTE

If the negative active power or the positive and negative reactive power must be logged, use a measuring transducer such as the Woodward UMT 1.

Pulse output p.duration 0.00s

Pulse duration **0.04 to 1.00 s**

The duty cycle of one output pulse is defined here.
Note: The pulse duration must be configured for compatibility to the kWh impulse. It may be possible to configure overlapping impulses that may be recognized as a continuous signal.

Pulse/kWh Logic -----

Output of the kWh-pulse **positive/negative**

The output logic of the kWh-pulse can be either negative (the collector-output [terminal 60/61] is de-energized for each positive kWh-pulse), or positive (the collector-output [terminal 60/61] is energized for each positive kWh-pulse).

Active energy Pulse/kWh 000.0

Pulses per positive kWh **0.1 to 150.0**

The quantity of pulses per measured kWh is defined here. The pulses issued by this controller must be analyzed by an external control.
Example: If this parameter is configured as "**Pulse/kWh 020.00**" and 20 kWh are measured the number of pulses that will be output will be 400 or 20 kWh × 20 pulses/kWh = 400 pulses

RESET kWh ON

RESET kWh measuring **ON/OFF**

Enabling this parameter permits the kWh meter to be reset to zero by pressing the "Select" and "Digit↑" buttons while in the automatic operating mode.



NOTE

The kWh-counter is reset by:

1. Verify the control is in automatic mode.
2. Verify that the kWh-counter is displayed in the lower line of the display.
3. Press and hold the "Select" and "Digit↑" buttons for at least 5 seconds.

After the counter has been successfully reset, the screens will display "0000.0 kWh".

Analog Outputs (Packages GPY-I / GPY-I-N)



It is possible to configure a linear measuring range for each analog output and assign it to a specific measured value (refer to table 6-3). The -20/0/4 to 20 mA analog outputs may be configured as a -20 to 20 mA, 0 to 20 mA, or 4 to 20 mA output. The user may define the upper and lower limits of the analog input measuring range. Text may be assigned to the input as well.

Value	Lower and upper setting value	
	0 mA, 4 mA, -20 mA	20 mA
Vol 1	0 to 65,000 V	
Vol 2	0 to 65,000 V	
Vol 3	0 to 65,000 V	
Vol ph-N AV	0 to 65,000 V	
Vol ph-N max	0 to 65,000 V	
Vol ph-N min	0 to 65,000 V	
Vol 1-2	0 to 65,000 V	
Vol 2-3	0 to 65,000 V	
Vol 3-1	0 to 65,000 V	
Vol ph-ph AV	0 to 65,000 V	
Vol ph-ph max	0 to 65,000 V	
Vol ph-ph min	0 to 65,000 V	
Frequency	40.00 to 80.00 Hz	
Current L1	0 to 9,999 A	
Current L2	0 to 9,999 A	
Current L3	0 to 9,999 A	
Current AV	0 to 9,999 A	
Current max	0 to 9,999 A	
Current min	0 to 9,999 A	
Direct. Cur 1	-9,999 to 9,999 A	
Direct. Cur 2	-9,999 to 9,999 A	
Direct. Cur 3	-9,999 to 9,999 A	
Dir. Current AV	-9,999 to 9,999 A	
Dir. Current max	-9,999 to 9,999 A	
Dir. Current min	-9,999 to 9,999 A	
Active power	-32,000 to 32,000 kW	
Reactive power	-32,000 to 32,000 kvar	
Apparent power	0 to 32,000 kVA	
cosphi	i0.01 to 1.00 to c0.01	

¹.... The sign of the current values is defined by the polarity of the active component.

Table 6-3: Analog outputs, table of values

Example: analog output 2 (-20/0/4 to 20 mA: terminals 52/53)
 Output of the wire-to-wire voltage L12:

20 mA-output

Analog output 2 0 .. 20 mA

Output range of the analog output 2 (20mA) -20..+20mA / 0..20mA / 4..20mA / OFF

The only variable that may be changed for this parameter is the lower value for this analog output. The upper limit is always +20 mA.
-20..20mA -20 mA is the configured low limit for the analog output.
0..20mA 0 mA is the configured low limit for the analog output.
4..20mA 4 mA is the configured low limit for the analog output.
OFF..... The analog output is not enabled. The subsequent screens of this function are not displayed.

Analog output 2 -----

Output value of the analog output 2 see Table 6-3

The parameter that is to be assigned to the output is selected here (refer to Table 6-3).

Analog output 0mA = 00000V

Scaling of the lower output value see Table 6-3

Defines the lower limit of the output.

Analog output 20mA = 00000V

Scaling of the upper output value see Table 6-3

Defines the upper limit of the output.

Interface (Packages GPX-I / GPY-I / GPY-I-N / K08)



CAUTION

The communications bus interface functionality is disabled when the direct configuration port is enabled. The parameter "Direct parametr." must be set to "NO" to re-enable the communication bus interface (refer to "Direct Configuration" on page 34).



NOTE

These screens and all related screens are only displayed if the particular communication option is included on the control unit. If the individual communication protocol is not included, the related screens will not be displayed.



NOTE

A description of the communication protocols may be found in Appendix D.

Screens for Modbus RTU Slave Protocol

Device number	
MOD-Bus	000

Device number Modbus RTU Slave 1 to 255

Device number for the Modbus RTU Slave.

Baudrate	
	0000

Baud rate Modbus RTU Slave 1,200 / 2,400 / 4,800 / 9,600 / 19,200 Baud

The baud rate of the Modbus RTU Slave is defined here.

Parity	
	none

Parity Modbus RTU Slave none / even / odd

The parity of the Modbus RTU Slave is defined here.

Stopbits	
	one

Stop bits Modbus RTU Slave one / two

The number of stop bits of the Modbus RTU Slave is defined here.

Delay to send	
MOD-Bus	00.0ms

Waiting time transmission after read request 0.2 to 50.0 ms

After the read request by the master, the minimum waiting time before transmitting the answer is configured here. This allows the controller to adjust the response time to the master so that it can process the answer.

General Interface Screens

Serial control <div style="text-align: right;">ON</div>	Control via interface ON/OFF <hr/> ON Control via the serial interface is enabled and control orders received via the interface are processed. OFF Control via the serial interface is disabled and control orders received via the interface are ignored.
Serial interface Monitoring ON	Interface monitoring ON/OFF <hr/> ON The interface monitoring is enabled. The control expects to receive bits 2 and 3 to be written to "00" in the control word by the master control within 15 seconds after receiving the last message. If these bits are not read within the prescribed time, and unsuccessful data exchange is detected, and the alarm message " Interface " is issued. OFF The interface monitoring is disabled.
Interface fault to relay 0000	Relay assignment for interface error 0 to 3 / 0 to 8 <hr/> Relays may be configured to energize when an interface fault is detected. The desired relays that to energize are configured here. The relays will only energize if the parameter " Serial interface monitoring " is configured as "ON".
Inhibit via Interface ON	Blocking via the interface ON/OFF <hr/> ON The protective functions messages (i.e. underfrequency) may be suppress via the interface. This operates in the same manner as terminals 5/6 "Blocking of protective functions / remote acknowledgement". OFF The protective functions messages (i.e. underfrequency) cannot be suppress via the interface.

Chapter 7.

Commissioning



DANGER - HIGH VOLTAGE

When commissioning the control, please observe all safety rules that apply to the handling of live equipment. Ensure that you know how to provide first aid in the event of an uncontrolled release of energy and that you know where the first aid kit and the nearest telephone are. Never touch any live components of the system or on the back of the system:

LIFE THREATENING



CAUTION

Only a qualified technician may commission unit. The "EMERGENCY-STOP" function must be operational prior to commissioning of the system, and must not depend on the unit for its operation.



CAUTION

Prior to commissioning ensure that all measuring devices are connected in correct phase sequence. The connect command for the unit circuit breaker must be disconnected at the unit circuit breaker. The field rotation must be monitored for proper rotation. Any absence of or incorrect connection of voltage measuring devices or other signals may lead to malfunctions and damage the unit, the engine, and/or components connected to the unit!

Procedure


1. After wiring the unit and ensuring all voltage-measuring devices are phased correctly, apply the control system voltage (i.e. 24 Vdc). The "Operation" LED will illuminate.
2. By simultaneously pressing the two push buttons "Digit↑" and "Cursor→", the configuration mode is accessed. After entering the access code number, the unit may be configured according to the application requirements (see the chapter regarding the parameters).

The MFR 1 will not issue a "Connect" signal while it is in configuration mode.

3. After applying the measured variables, the unit will display the measured values. These values should be confirmed with a calibrated measuring instrument.
4. After the unit has been configured for the application, the configuration mode is exited by simultaneously pressing the "Digit↑" and "Cursor→" buttons.
5. Check all protection functions and the relay outputs.
Check all control outputs as well as the setting and behavior of the controller outputs (frequency & voltage)

6. Check the synchronization (Packages GPX / GPX-I / GPY-I / GPY-I-N / K08):
 - a.) Interrupt the "Connect" signal for the power circuit breaker.
 - b.) The mains voltage (synchronization voltage) must be within the permissible limits.
 - c.) In the moment a connection command is output, the differential voltage between the corresponding conductors must be equal to zero. This check must be carried out for all three phases, in order to check the correctness of the rotating field.
 - d.) After a successful check, the "Connect" signal can be connected again.
7. Check the dead bus start function
Prior to checking the dead bus start function, the output of the "Connect" signal must be interrupted.
8. If steps 1 through 7 have been carried out successfully, parallel operations may be commenced. It is recommended to start with a constant power/baseload operation (approx. 25 % of the generator rated power) initially. While this operation is being carried out, the displayed measured values must be verified. Test the GCB shutdown. Check the real power controller and if necessary the power factor controller for proper operation. Enter various set point values and verify proper operation.

Appendix A. Dimensions



2005-07-11 | MFR 1 Dimensions r1ww-2805-ab.skf

Figure 7-1: Dimensions

Discrete inputs -----	isolated
- Input range ($V_{Cont, discrete input}$)	Rated voltage 18 to 250 Vac/dc
- Input resistance	approx. 68 k Ω
Relay outputs -----	potential free
- Contact material	AgCdO
- General purpose (GP) ($V_{Cont, relay output}$)	
	AC.....2.00 Aac@250 Vac
	DC..... 2.00 Adc@24 Vdc
	0.36 Adc@125 Vdc
	0.18 Adc@250 Vdc
- Pilot duty (PD) ($V_{Cont, relay output}$)	
	AC.....
	DC..... 1.00 Adc@24 Vdc
	0.22 Adc@125 Vdc
	0.10 Adc@250 Vdc
Analog outputs -----	isolated
- At rated value	freely scaleable
- Insulation voltage	1,500 Vdc
- Resolution PWM.....	12 Bit
- -20/0/4 to 20 mA output.....	Maximum load 500 Ω
Pulse output -----	
- Type	transistor output
- Rated gate voltage.....	24 Vdc
- Maximum gate voltage.....	32 Vdc
- Minimum gate current.....	10 mA dc
- Maximum gate current	30 mA dc (0.5 Vdc)
Interface -----	isolated
- Insulation voltage	dependent on model: 500 to 3,000 Vdc
- Version.....	variable
Housing -----	
- Type	APRANORM DIN 43 700
- Dimensions (W × H × D).....	96 × 72 × 130 mm
- Front cutout (W × H)	91 [+1.0] × 67 [+0.7] mm
- Wiring	Screw-type terminals depending on connector 1.5 mm ² , 2.5 mm ² , or 4 mm ²
- Recommended tightening torque	[1.5 mm ² / 2.5 mm ²] 0.5 Nm, [4 mm ²] 0.6 Nm
	use 60/75 °C copper wire only
	use class 1 wire only or equivalent
- Weight.....	approx. 800 g
Protection -----	
- Protection system	IP42 from front with correct mounting
	IP54 from front with gasket (gasket: P/N 8923-1036)
	IP21 from back
- Front foil	insulating surface
- EMC test (CE).....	tested according to applicable EN guidelines
- Listings.....	CE marking; UL listing for ordinary locations
	UL/cUL listed, Ordinary Locations, File No.: E231544
	(Package GPY-I-N not UL/cUL listed)
- Marine-Approval.....	GL

Appendix C. Measured Quantities and Accuracy

Measuring value	Display/range	Accuracy	Note
Frequency			
f_{L1}, f_{L2}, f_{L3}	40.0 to 80.0 Hz	0.05 Hz	
Voltage			
$V_{L1}, V_{L2}, V_{L3}, V_{L12}, V_{L23}, V_{L31}$	0 to 520 V/0 to 65 kV	1 %	Accuracy depending on the configured transformer ratio
Current			
I_{L1}, I_{L2}, I_{L3}	0 to 9,999 A	1 %	Accuracy depending on the configured transformer ratio
Real power			
Total real actual power	-32.0 to 32.0 MW	2 %	Accuracy depending on the configured transformer ratio
Re-active power			
Actual value in L1, L2, L3	-32.0 to 32.0 Mvar	2 %	Accuracy depending on the configured transformer ratio
Apparent power			
Actual value in L1, L2, L3	0 to 45.0 MVA	2 %	Accuracy depending on the configured transformer ratio
Power factor (cos ϕ)			
Actual value (cos ϕ_{L1})	c0.00 to 1.00 to i0.00	1.5 °	-

Reference conditions: The data apply to the following reference conditions:

- Input voltage = sinusoidal rated voltage
- Input current = sinusoidal rated current
- Frequency = rated frequency ± 2 %
- Power supply = rated voltage ± 2 %
- Power factor cos $\phi = 1$
- Ambient temperature 23 °C ± 2 K
- Warm-up period = 20 minutes.

Appendix D. Interface Telegram

Communication Interface Addresses



Transmission Message

Number				Content (words)	Unit	Remark
3964	Modbus	CAN bus	Profibus			

00	01	1 (02, 03)	MUX=1, 1	0	Telegram header	"302"	Telegram type
02	03	2 (04, 05)	MUX=1, 2	1	Voltage L12	V	
04	05	3 (06, 07)	MUX=1, 3	2	Voltage L23	V	
06	07	4 (08, 09)	MUX=2, 1	3	Voltage L31	V	
08	09	5 (10, 11)	MUX=2, 2	4	Voltage L1N	V	
10	11	6 (12, 13)	MUX=2, 3	5	Voltage L2N	V	
12	13	7 (14, 15)	MUX=3, 1	6	Voltage L3N	V	
14	15	8 (16, 17)	MUX=3, 2	7	Frequency L12	Hz × 100	
16	17	9 (18, 19)	MUX=3, 3	8	Current L1	A	
18	19	10 (20, 21)	MUX=4, 1	9	Current L2	A	
20	21	11 (22, 23)	MUX=4, 2	10	Current L3	A	
22	23	12 (24, 25)	MUX=4, 3	11	Power factor (cosphi)	dim.less × 100	
24	25	13 (26, 27)	MUX=5, 1	12	Real power	kW	
26	27	14 (28, 29)	MUX=5, 2	13	Reactive power	kvar	
28	29	15 (30, 31)	MUX=5, 3	14	Busbar voltage L12	V	
30	31	16 (32, 33)	MUX=6, 1	15	Busbar voltage L12	Hz × 100	
32	17	17 (34)	MUX=6, 2	16	Exponent	dim.less	VGN
33	17	17 (35)	MUX=6, 2	16		dim.less	IGN
34	18	18 (36)	MUX=6, 3	17	Exponent	dim.less	PGN/QGN
35	18	18 (37)	MUX=6, 3	17		dim.less	VSS
36	37	19 (38, 39)	MUX=7, 1	18	Generator real energy	kWh	High Word
38	39	20 (40, 41)	MUX=7, 2	19			Low Word
40	41	21 (42, 43)	MUX=7, 3	20	Internal alarms 1 Note (example bit 15/14): 0/1 = alarm not triggered 1/0 = alarm triggered	Bit 15 = 1 \	Overfrequency level 2
						Bit 14 = 0 /	
						Bit 13 = 1 \	Underfrequency level 2
						Bit 12 = 0 /	
						Bit 11 = 1 \	Overvoltage level 2
						Bit 10 = 0 /	
						Bit 9 = 1 \	Overvoltage level 2
						Bit 8 = 0 /	
						Bit 7 = 1 \	Unbalanced load
					Bit 6 = 0 /		
					Bit 5 = 1 \	Overcurrent level 1	
					Bit 4 = 0 /		
					Bit 3 = 1 \	Overload	
					Bit 2 = 0 /		
					Bit 1 = 1 \	Reverse/reduced power	
					Bit 0 = 0 /		

Number				Content (words)	Unit	Remark		
3964	Modbus	CAN bus	Profibus					
42	43	22 (44, 45)	MUX=8, 1	21	Internal alarms 2	Bit 15 = 1 \	Overfrequency level 1	
						Bit 14 = 0 /		
						Bit 13 = 1 \		Underfrequency level 1
						Bit 12 = 0 /		
						Bit 11 = 1 \		Overvoltage level 1
						Bit 10 = 0 /		
						Bit 9 = 1 \		Undervoltage level 1
						Bit 8 = 0 /		
						Bit 7 = 1 \		Overcurrent level 3
Bit 6 = 0 /								
Bit 5 = 1 \	df/dt alarm							
Bit 4 = 0 /								
Bit 3 = 1 \	Asymmetry (voltage)							
Bit 2 = 0 /								
Bit 1 = 1 \	Vector/phase jump							
Bit 0 = 0 /								
44	45	23 (46, 47)	MUX=8, 2	22	Internal alarms 3	Bit 15 = 1 \	Power factor level 1	
						Bit 14 = 0 /		
						Bit 13 = 1 \		Power factor level 2
						Bit 12 = 0 /		
						Bit 11 = 1 \		Inductive reactive power
						Bit 10 = 0 /		
						Bit 9 = 1 \		Capacitive reactive power
						Bit 8 = 0 /		
						Bit 7 = 1 \		Positive real power surge
Bit 6 = 0 /								
Bit 5 = 1 \	Negative real power surge							
Bit 4 = 0 /								
Bit 3 = 1 \	Overcurrent level 2							
Bit 2 = 0 /								
Bit 1 = 1 \	Interface fault							
Bit 0 = 0 /								
46	47	24 (48, 49)	MUX=8, 3	23	Internal alarms 4	Bit 15 = 1 \	Busbar : Overfrequency	
						Bit 14 = 0 /		
						Bit 13 = 1 \	Busbar : Underfrequency	
						Bit 12 = 0 /		
						Bit 11 = 1 \	Busbar : Overvoltage	
						Bit 10 = 0 /		
						Bit 9 = 1 \	Busbar : Undervoltage	
						Bit 8 = 0 /		
						Bit 7 = 1 \	Internal	
Bit 6 = 0 /								
Bit 5 = 1 \	Internal							
Bit 4 = 0 /								
Bit 3 = 1 \	Internal							
Bit 2 = 0 /								
Bit 1 = 1 \	Internal							
Bit 0 = 0 /								

Number				Content (words)	Unit	Remark
3964	Modbus	CAN bus	Profibus			
48 49	25 (50, 51)	MUX=9, 1	24	Internal alarms 5 Note (example bit 15/14): 0/1 = alarm not triggered 1/0 = alarm triggered	Bit 15 = 1 \	Internal
					Bit 14 = 0 /	
					Bit 13 = 1 \	Internal
					Bit 12 = 0 /	
					Bit 11 = 1 \	Internal
					Bit 10 = 0 /	
					Bit 9 = 1 \	Internal
					Bit 8 = 0 /	
					Bit 7 = 1 \	Internal
					Bit 6 = 0 /	
Bit 5 = 1 \	Internal					
Bit 4 = 0 /						
Bit 3 = 1 \	Zero voltage					
Bit 2 = 0 /						
Bit 1 = 1 \	Power level reached					
Bit 0 = 0 /						
50 51	26 (52, 53)	MUX=9, 2	25	Internal alarms 6 Note (example bit 15/14): 0/1 = alarm not triggered 1/0 = alarm triggered	Bit 15 = 1 \	Ground fault Ve, level 1
					Bit 14 = 0 /	
					Bit 13 = 1 \	Internal
					Bit 12 = 0 /	
					Bit 11 = 1 \	Internal
					Bit 10 = 0 /	
					Bit 9 = 1 \	Internal
					Bit 8 = 0 /	
					Bit 7 = 1 \	Internal
					Bit 6 = 0 /	
Bit 5 = 1 \	Ground fault Ve, level 2					
Bit 4 = 0 /						
Bit 3 = 1 \	Internal					
Bit 2 = 0 /						
Bit 1 = 1 \	Internal					
Bit 0 = 0 /						
52 53	27 (54, 55)	MUX=9, 3	26	Internal alarms 7 Note (example bit 15/14): 0/1 = alarm not triggered 1/0 = alarm triggered	Bit 15 = 1 \	Internal
					Bit 14 = 0 /	
					Bit 13 = 1 \	Internal
					Bit 12 = 0 /	
					Bit 11 = 1 \	Inverse time-overcurrent
					Bit 10 = 0 /	
					Bit 9 = 1 \	Internal
					Bit 8 = 0 /	
					Bit 7 = 1 \	Internal
					Bit 6 = 0 /	
Bit 5 = 1 \	Internal					
Bit 4 = 0 /						
Bit 3 = 1 \	Internal					
Bit 2 = 0 /						
Bit 1 = 1 \	Internal					
Bit 0 = 0 /						

Receive Message

Number		Content (words)	Unit	Remark
3964	Modbus			
00 01	1 (02, 03)	Set point value active power P_{Setpoint}	kW	0 to 32000
02 03	2 (04, 05)	Set point value Power factor (ϕ_{Setpoint})	Power factor \times 100	-99 to 100 ¹
04 05	3 (06, 07)	Control word	Bit 15 = 1	Blocking of watchdog active ²
			Bit 14 = 1	free
			Bit 13 = 1	free
			Bit 12 = 1	free
			Bit 11 = 1	free
			Bit 10 = 1	Release isolated operation ³
			Bit 9 = 1	free
			Bit 8 = 1	Packages GPX-I / GPY-I / GPY-I-N / K08: Release power circuit breaker ⁴
			Bit 7 = 1	free
			Bit 6 = 1	free
			Bit 5 = 1	free
			Bit 4 = 1	Acknowledge ⁵
Bit 3 = 1	Transmission watchdog bit 1 ⁶			
Bit 2 = 1	Transmission watchdog bits 0 ⁶			
Bit 1 = 1	free			
Bit 0 = 1	free			
06 07	4 (08, 09)	Set point frequency f_{Setpoint}	Hz \times 100	3200 to 6800 ⁷
08 09	5 (10, 11)	Set point voltage V_{Setpoint}	V	0 to 480 ⁸
10 11	6 (12, 13)	free		

¹ The transmitted number has a sign (When connected correctly - = capacitive, + = inductive; 100 means power factor = 1)

² This control bit is ignored, if the screen "Blocking via interface" is configured as "OFF".

³ Corresponds to the discrete input "Release isolated operation" (terminal 73/74).

⁴ Packages GPX-I / GPY-I / GPY-I-N / K08: Corresponds to the discrete input "Release CB" (terminal 30/31).

⁵ Corresponds to the "Acknowledge" button.

⁶ Here, a "00" must always be sent. If these bits are not configured as "00", the alarm "Interface" is sent after 15 seconds (only if the screen "Interface monitoring" is set to "ON").

⁷ Example: 4856 = 48.56 Hz

⁸ The voltage set point relates to the set secondary voltage.

For voltage transformers 10.0 kV/100 V a voltage set point value of 100 V must be set (corresponds to $V_{\text{Setpoint}} = 10.0$ kV)

Description of the Data Format



NOTE

Certain addresses have two parts, the measured value and the exponent multiplier!

Voltage and current	0 to 9999 without sign	measured in [V, A], no exponent
Real power	0 to 9999 with sign	measured in [W]; data format: two's complement positive = positive power negative = negative power (reverse power)
Reactive power	0 to 9999 with sign	measured in [var]; data format: two's complement positive = inductive negative = capacitive
Frequency		measured in [Hz × 100]
Real energy	32 Bit	measured in [kWh]; data format: two's complement positive = exported real energy negative = imported real energy
Power factor (cos phi)	-99 to +100	measured in [cos phi × 100] positive = inductive/leading, generator over-excited negative = capacitive/lagging, generator under-excited




Figure 7-2: Interface, power factor scaling

Examples

$V_{G12} = 103, \text{exponent} = 2$
 $103 \times 10^2 \text{ [V]} = 1,030 \text{ [V]} = 10.3 \text{ kV}$

$I_{G1} = 80, \text{exponent} = -1$
 $80 \times 10^{-1} \text{ [A]} = 8.0 \text{ [A]} = 8.0 \text{ A}$

$P_{GN} = 123, \text{exponent} = 4$
 $123 \times 10^4 \text{ [W]} = 1,230,000 \text{ [W]} = 1.23 \text{ MW}$

$P_{GN} = 803, \text{exponent} = 2$
 $803 \times 10^2 \text{ [W]} = 80,300 \text{ [W]} = 80.3 \text{ kW}$

$f_{GN} = 5230$
 $5230 \text{ [Hz} \times 100] = 52.30 \text{ [Hz]} = 52.3 \text{ Hz}$

Power factor = 87
 $87 \text{ [Cos phi} \times 100] = 0.87 \text{ [Cos phi]} = 0.87$

Bit Change at Tripping of a Watchdog Function

If one of the watchdog functions (protective alarms) trips, the corresponding bits (for example bit 15/14 = over-frequency limit 2) will change from not tripped (= 0/1) to tripped (= 1/0).


Framework Data for the Interfaces



Framework Data for Modbus RTU Slave

Transmitting protocol.....Modbus RTU Slave
 Hardware.....Interface RS-485
 Transmission rateadjustable
 Slave address.....adjustable
 Parityadjustable

A maximum of 10 words can be read or 4 words written with one command. Modbus function codes 03, 04, 06 and 16 are supported.



2005-08-31 | Data coupling 2005-08-31.skf

Figure 7-3: Interface - Modbus connection

Appendix E. List of Parameters

Product number P/N _____ Rev _____

Version MFR 13 _____

Project _____

Serial number S/N _____ Date _____

Pkg.	Parameter	Setting range 100/400 V version	Default setting	Customer setting
BASIC DATA				
	Software version	-	-	
	SPRACHE/LANGUAGE	German/English	English	<input type="checkbox"/> G <input type="checkbox"/> E <input type="checkbox"/> G <input type="checkbox"/> E
	Enter code	0000 to 9999	-	
	Password Protection	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 0
	Define level 1 code	0000 to 9999	0001	
	Define level 2 code	0000 to 9999	0002	
	Direct parametr.	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> Y <input type="checkbox"/> N
MEASUREMENT				
	Volt.-Measuring	Phase to phase / Phase-neutral	Phase-neutral	<input type="checkbox"/> pn <input type="checkbox"/> pp <input type="checkbox"/> pn <input type="checkbox"/> pp
GP / K08	Volt.transformer secondary	50 to 125/50 to 480 V	100/400 V	
GP / K08	Volt.transformer primary	00.100 to 65.000 kV	00.400 kV	
GPX GPX-I GPY-I GPY-I-N	Volt.transformer sec.(GN)	50 to 125/50 to 480 V	100/400 V	
..	Volt.transformer prim(GN)	00.100 to 65.000 kV	00.400 kV	
..	Volt.transformer sec.(MN)	50 to 125/50 to 480 V	100/400 V	
GPX GPX-I GPY-I GPY-I-N	Volt.transformer prim(MN)	00.100 to 65.000 kV	00.400 kV	
	Current transf.	1 to 9,999/{x} A	1,000/{x} A	
GPX GPX-I GPY-I GPY-I-N	Rated voltage	5 to 125/10 to 480 V	100/400 V	
K08 GPX GPX-I GPY-I GPY-I-N K08	Rated frequency	40.0 to 70.0 Hz	50.0 Hz	
	Rated current	1 to 9,999 A	1,000 A	
	Rated power	5 to 32,000 kW	500 kW	
	Power measuring	one-phase/three-phase	three-phase	<input type="checkbox"/> s <input type="checkbox"/> t <input type="checkbox"/> s <input type="checkbox"/> t
CONTROL FUNCTIONS				
GPX GPX-I GPY-I GPY-I-N K08	Synchronizing	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 0
..	Synchronization df max	0.02 to 0.49 Hz	0.18 Hz	
..	Synchronization df min	0.00 to -0.49 Hz	-0.10 Hz	
..	Synchronization dV max	0.1 to 15.0 %	6.0 %	
..	Synchronization Max phase <	1 to 60°	2°	
..	Synchronization Time pulse>	50 to 250 ms	200 ms	
GPX GPX-I GPY-I GPY-I-N K08	Gen.circ.breaker Pick-up t.	40 to 300 ms	80 ms	

Pkg.	Parameter	Setting range 100/400 V version	Default setting	Customer setting
PROTECTION				
	Volt. Monitoring	Phase-neutral / Phase to phase	Phase to phase	<input type="checkbox"/> pn <input type="checkbox"/> pp <input type="checkbox"/> pn <input type="checkbox"/> pp
	Overvoltage Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 0
	Overvoltage 1 V(ph-ph)> (Phase-N)>	20 to 130 / 520 / 900 V 10 to 75 / 300 V / 20 to 900 V	110/440/769 V 64/254/444 V	
	Overvoltage 1 Delay	0.02 to 99.98 s	0.10 s	
	Overvoltage 2 V(ph-ph)> (Phase-N)>	20 to 130 / 520 / 900 V 10 to 75 / 300 V / 20 to 900 V	120/480/839 V 64/254/485 V	
	Overvoltage 2 Delay	0.02 to 99.98 s	0.04	
	Overvoltage Hysteresis	0 to 99 V	1/4 V	
	Undervoltage Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 0
	Undervoltage 1 V(ph-ph)< (Phase-N)<	20 to 130 / 520 / 900 V 10 to 75 / 300 V / 20 to 900 V	90/360/629 V 51/207/363 V	
	Undervoltage 1 Delay	0.02 to 99.98 s	0.10 s	
	Undervoltage 2 V(ph-ph)< (Phase-N)<	20 to 130 / 520 / 900 V 10 to 75 / 300 V / 20 to 900 V	80/320/559 V 46/184/323 V	
	Undervoltage 2 Delay	0.02 to 99.98 s	0.04 s	
	Undervoltage Hysteresis	0 to 99 V	1/4/8 V	
	Zero-voltage Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 0
	Zero-voltage V(ph-ph)<	Busbar 1ph / Generator 3ph 8 to 150 V	Generator 3ph 8 V	<input type="checkbox"/> B1 <input type="checkbox"/> G3 <input type="checkbox"/> B1 <input type="checkbox"/> G3
	Zero-voltage Delay	0.02 to 99.98 s	0.25 s	
	Zero-voltage Hysteresis	0 to 99 V	1/4/8 V	
	Release delay Zerovolt.	0.02 to 99.98 s	0.04 s	
	Asymmetry- Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 0
	Asymmetry Response v.	0 to 99 V	10/40/69 V	
	Asymmetry Delay	0.02 to 99.98 s	2.00 s	
	Asymmetry Hysteresis	0 to 99 V	1/4/6 V	
	Overfrequency- Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 0
	Overfrequency 1 f>	40.00 to 80.00 Hz	50.2 Hz	
	Overfrequency 1 Delay	0.02 to 99.98 s	0.10 s	
	Overfrequency 2 f>	40.00 to 80.00 Hz	51.0 Hz	
	Overfrequency 2 Delay	0.02 to 99.98 s	0.04 s	
	Overfrequency Hysteresis	0.01 to 9.99 Hz	0.05 Hz	
	Underfrequency- Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 0
	Underfrequency 1 f<	40.00 to 80.00 Hz	49.8 Hz	
	Underfrequency 1 Delay	0.02 to 99.98 s	0.10 s	
	Underfrequency 2 f<	40.00 to 80.00 Hz	49.0 Hz	
	Underfrequency 2 Delay	0.02 to 99.98 s	0.04 s	
	Underfrequency Hysteresis	0.01 to 9.99 Hz	0.05 Hz	
	Overcurrent Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 0
	Overcurrent 1 I>	0 to 300 %	120 %	
	Overcurrent 1 Delay	0.02 to 99.98 s	0.1 s	
	Overcurrent 2 I>	0 to 300 %	160 %	
	Overcurrent 2 Delay	0.02 to 99.98 s	0.04 s	
	Overcurrent 3 I>	0 to 300 %		
	Overcurrent 3 Delay	0.02 to 99.98 s		
	Overcurrent Hysteresis	1 to 300 %	5 %	

Pkg.	Parameter	Setting range 100/400 V version	Default setting	Customer setting
PROTECTION				
	Inv.time ov.curr monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0
	Inv.time char.	Normal / High / Extreme	Extreme	
	Inv.time ov.curr Tp=	0.01 to 1.99 s	0.10 s	
	Inv.time ov.curr Ip=	0.1 to 3.0*In	1.0 * In	
	Inv.time ov.curr I start=	1 to 3.00*In	1.00 * In	
	Inv.time ov.cur. V-restr.	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0
	Inv.time ov.curr Knee curve	10 to 99 %	20 %	
GP / K08	Earth current monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0
..	Earth current 1 Response	10 to 300 %	120 %	
..	Earth current 1 Delay.	0.02 to 99.98 s	0.1 s	
..	Earth current 2 Response	10 to 300 %	160 %	
..	Earth current 2 Delay	0.02 to 99.98 s	0.04 s	
GP / K08	Earth current Hysteresis	0 to 300 %	5 %	
	Overload Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0
	Overload Response v.	0 to 150 %	120 %	
	Overload Delay	0 to 300 s	20 s	
	Overload Hysteresis	1 to 99 %	2 %	
	Reverse/min.pow. Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0
	Reverse/min.pow.	-99 to 99 %	-10 %	
	Reverse/min.pow. Delay	0.02 to 99.98 s	3.0 s	
	Reverse/min.pow. Hysteresis	1 to 99 %	2 %	
	Unbalanced load Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0
	Unbalanced load Response v.	0 to 100 %	20 %	
	Unbalanced load Delay	0.02 to 99.98 s	0.25 s	
	Unbalanced load Hysteresis	1 to 20 %	5 %	
	Reactive power Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0
	Cap. react. pow. Response v.	0 to 100 %	30 %	
	Cap. react. pow. Delay	0.02 to 99.98 s	0.10 s	
	Ind. react. pow. Response v.	0 to 100 %	30 %	
	Ind. react. pow. Delay	0.02 to 99.98 s	0.10 s	
	React. pow. mon. Hysteresis	1 to 20 %	2 %	

Pkg.	Parameter	Setting range 100/400 V version	Default setting	Customer setting
RELAYS				
GP / K08	External Clearing relays	ON/OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0
	Auto-clearing relays	ON/OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0
	Release delay Overvoltage	0.02 to 99.98 s	0.10 s	
	Release delay Undervoltage	0.02 to 99.98 s	0.10 s	
	Release delay Asymmetry	0.02 to 99.98 s	0.10 s	
	Release delay Overfreq.	0.02 to 99.98 s	0.10 s	
	Release delay Underfrq.	0.02 to 99.98 s	0.10 s	
	Release delay Overcurr.	0.02 to 99.98 s	0.20 s	
	Release delay Earth F.	0.02 to 99.98 s	0.20 s	
	Release delay Overload	0.02 to 99.98 s	0.10 s	
	Release delay Rev.Power	0.02 to 99.98 s	0.10 s	
	Release delay Unb. Load	0.02 to 99.98 s	0.10 s	
	Release delay react.cap.	0.02 to 99.98 s	0.10 s	
	Release delay react.ind.	0.02 to 99.98 s	0.10 s	
GPX GPX-I GPY-I GPY-I-N K08 GPX GPX-I GPY-I GPY-I-N K08	Auto-clearing Display	ON/OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0
	Clearing display after	1 to 99 s	1 s	
	Change relay-allocation	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N
	Funct. relay 12	E/R	RE	
	Funct. relay 123	E/R	REE	
	Funct. relay 45	E/R	EE	
	Funct. relay 678	E/R	EEE	
	Collect response to relay	0 to 3/7	0002	
	Overvoltage 1 to relay	0 to 3/7	0002	
	Overvoltage 2 to relay	0 to 3/7	0002	
	Undervoltage 1 to relay	0 to 3/7	0002	
	Undervoltage 2 to relay	0 to 3/7	0002	
	Zero-voltage to relay	0 to 3/7	0002	
	Asymmetry to relay	0 to 3/7	0002	
Overfrequency 1 to relay	0 to 3/7	0003		
Overfrequency 2 to relay	0 to 3/7	0003		
Underfrequency 1 to relay	0 to 3/7	0003		
Underfrequency 2 to relay	0 to 3/7	0003		
Overcurrent1 to relay	0 to 3/7	0002		
Overcurrent2 to relay	0 to 3/7	0002		
Overcurrent3 to relay	0 to 3/7	0002		
Current-Inv. to relay	0 to 3/7	0002		
GP / K08 Earth Fault 1 to relay	0 to 3/7	0003		
GP / K08 Earth Fault 2 to relay	0 to 3/7	0003		
Overload to relay	0 to 3/7	0003		
Reverse/min.pow. to relay	0 to 3/7	0003		
Unbalanced Load to relay	0 to 3/7	0002		
Ind. react.pow. to relay	0 to 3/7	0002		
Neg. react.pow. to relay	0 to 3/7	0002		
GPX-I GPY-I GPY-I-N K08 Interface Fault to relay	0 to 3/7	0002		

Pkg.	Parameter	Setting range 100/400 V version	Default setting	Customer setting	
PULSE OUTPUT					
GPY-I GPY-I-N	Pulse output p.duration	0.04 to 1.00 s	0.10 s		
	Pulse output Logic	positive/negative	negative		
	Active energy Pulse/kWh	0.10 to 150.00	1.00		
GPY-I GPY-I-N	RESET kWh	ON/OFF	OFF	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
ANALOG OUTPUTS					
GPY-I GPY-I-N	Analog output 1	OFF -20 to 20mA 0 to 20 mA 4 to 20 mA	-20 to 20mA	<input type="checkbox"/> OFF <input type="checkbox"/> -/+20mA <input type="checkbox"/> 0-20mA <input type="checkbox"/> 4-20mA	<input type="checkbox"/> OFF <input type="checkbox"/> -/+20mA <input type="checkbox"/> 0-20mA <input type="checkbox"/> 4-20mA
	.. Analog output 1	see table at the end of the list of parameters	Active power		
	.. Analog output		0 kW		
.. Analog output	500 kW				
..	Analog output 2	OFF -20 to 20mA 0 to 20 mA 4 to 20 mA	-20 to 20mA	<input type="checkbox"/> OFF <input type="checkbox"/> -/+20mA <input type="checkbox"/> 0-20mA <input type="checkbox"/> 4-20mA	<input type="checkbox"/> OFF <input type="checkbox"/> -/+20mA <input type="checkbox"/> 0-20mA <input type="checkbox"/> 4-20mA
	.. Analog output 2	see table at the end of the list of parameters	cosphi		
	.. Analog output		c0.50		
.. Analog output	i0.50				
..	Analog output 3	OFF -20 to 20mA 0 to 20 mA 4 to 20 mA	-20 to 20mA	<input type="checkbox"/> OFF <input type="checkbox"/> -/+20mA <input type="checkbox"/> 0-20mA <input type="checkbox"/> 4-20mA	<input type="checkbox"/> OFF <input type="checkbox"/> -/+20mA <input type="checkbox"/> 0-20mA <input type="checkbox"/> 4-20mA
	.. Analog output 3	see table at the end of the list of parameters	1 L1		
	.. Analog output		0 A		
.. Analog output	1,000 A				
GPY-I GPY-I-N					
INTERFACE					
GPX-I GPY-I GPY-I-N K08	Device number MOD-Bus	1 to 255	1		
	.. Baudrate	1,200 / 2,400 / 4,800 / 9,600 / 19,200 Baud	9,600 Baud		
	.. Parity	none/even/odd	none		
.. Stopbits	one/two	one			
.. Delay to send MOD-Bus	0.2 to 50.0 ms	0.0 ms			
..	Serial control	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
..	Serial interface Monitoring	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0
GPX-I GPY-I GPY-I-N K08	Inhibit via Interface	ON/OFF	ON	<input type="checkbox"/> 1 <input type="checkbox"/> 0	<input type="checkbox"/> 1 <input type="checkbox"/> 0

Value	Lower and upper setting value	
	0 mA, 4 mA, -20 mA	20 mA
Vol 1	0 to 65,000 V	
Vol 2	0 to 65,000 V	
Vol 3	0 to 65,000 V	
Vol ph-N AV	0 to 65,000 V	
Vol ph-N max	0 to 65,000 V	
Vol ph-N min	0 to 65,000 V	
Vol 1-2	0 to 65,000 V	
Vol 2-3	0 to 65,000 V	
Vol 3-1	0 to 65,000 V	
Vol ph-ph AV	0 to 65,000 V	
Vol ph-ph max	0 to 65,000 V	
Vol ph-ph min	0 to 65,000 V	
Frequency	40.00 to 80.00 Hz	
Current L1	0 to 9,999 A	
Current L2	0 to 9,999 A	
Current L3	0 to 9,999 A	
Current AV	0 to 9,999 A	
Current max	0 to 9,999 A	
Current min	0 to 9,999 A	
Direct. Cur 1	-9,999 to 9,999 A	
Direct. Cur 2	-9,999 to 9,999 A	
Direct. Cur 3	-9,999 to 9,999 A	
Dir. Current AV	-9,999 to 9,999 A	
Dir. Current max	-9,999 to 9,999 A	
Dir. Current min	-9,999 to 9,999 A	
Active power	-32,000 to 32,000 kW	
Reactive power	-32,000 to 32,000 kvar	
Apparent power	0 to 32,000 kVA	
cosphi	i0.01 to 1.00 to c0.01	

..... The sign of the current values is defined by the polarity of the active component.

Table 7-1: Analog outputs, table of values

Appendix F. Service Options



Product Service Options



The following factory options are available for servicing Woodward equipment, based on the standard Woodward Product and Service Warranty (5-01-1205) that is in effect at the time the product is purchased from Woodward or the service is performed. If you are experiencing problems with installation or unsatisfactory performance of an installed system, the following options are available:

- Consult the troubleshooting guide in the manual.
- Contact Woodward technical assistance (refer to "How to Contact Woodward" later in this chapter) and discuss your problem. In most cases, your problem can be resolved over the phone. If not, you can select which course of action you wish to pursue based on the available services listed in this section.

Returning Equipment for Repair



If a control (or any part of an electronic control) is to be returned to Woodward for repair, please contact Woodward in advance to obtain a Return Authorization Number. When shipping the unit(s), attach a tag with the following information:

- name and location where the control is installed;
- name and phone number of contact person;
- complete Woodward part numbers (P/N) and serial number (S/N);
- description of the problem;
- instructions describing the desired repair.



CAUTION

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Packing a Control

Use the following materials when returning a complete control:

- protective caps on any connectors;
- antistatic protective bags on all electronic modules;
- packing materials that will not damage the surface of the unit;
- at least 100 mm (4 inches) of tightly packed, industry-approved packing material;
- a packing carton with double walls;
- a strong tape around the outside of the carton for increased strength.

Return Authorization Number RAN

When returning equipment to Woodward, please telephone and ask for the Customer Service Department in Stuttgart [+49 (711) 789 54-0]. They will help expedite the processing of your order through our distributors or local service facility. To expedite the repair process, contact Woodward in advance to obtain a Return Authorization Number, and arrange for issue of a purchase order for the unit(s) to be repaired. No work can be started until a purchase order is received.



NOTE

We highly recommend that you make arrangement in advance for return shipments. Contact a Woodward customer service representative at +49 (711) 789 54-0 for instructions and for a Return Authorization Number.

Replacement Parts



When ordering replacement parts for controls, include the following information:

- the part numbers P/N (XXXX-XXX) that is on the enclosure nameplate;
- the unit serial number S/N, which is also on the nameplate.

How to Contact Woodward



Please contact following address if you have questions or if you want to send a product for repair:

Woodward GmbH
Handwerkstrasse 29
70565 Stuttgart - Germany

Phone: +49 (711) 789 54-0 (8.00 - 16.30 German time)
Fax: +49 (711) 789 54-100
e-mail: stgt-info@woodward.com

For assistance outside Germany, call one of the following international Woodward facilities to obtain the address and phone number of the facility nearest your location where you will be able to get information and service.

Facility	Phone number
USA	+1 (970) 482 5881
India	+91 (129) 409 7100
Brazil	+55 (19) 3708 4800
Japan	+81 (476) 93 4661
The Netherlands	+31 (23) 566 1111

You can also contact the Woodward Customer Service Department or consult our worldwide directory on Woodward's website (www.woodward.com) for the name of your nearest Woodward distributor or service facility. [For worldwide directory information, go to www.woodward.com/ic/locations.]

Engineering Services



Woodward Industrial Controls Engineering Services offers the following after-sales support for Woodward products. For these services, you can contact us by telephone, by e-mail, or through the Woodward website.

- Technical support
- Product training
- Field service during commissioning

Technical Support is available through our many worldwide locations, through our authorized distributors, or through GE Global Controls Services, depending on the product. This service can assist you with technical questions or problem solving during normal business hours. Emergency assistance is also available during non-business hours by phoning our toll-free number and stating the urgency of your problem. For technical engineering support, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference technical support.

Product Training is available on-site from several of our worldwide facilities, at your location, or from GE Global Controls Services, depending on the product. This training, conducted by experienced personnel, will assure that you will be able to maintain system reliability and availability. For information concerning training, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference *customer training*.

Field Service engineering on-site support is available, depending on the product and location, from our facility in Colorado, or from one of many worldwide Woodward offices or authorized distributors. Field engineers are experienced on both Woodward products as well as on much of the non-Woodward equipment with which our products interface. For field service engineering assistance, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference *field service*.

Technical Assistance



If you need to telephone for technical assistance, you will need to provide the following information. Please write it down here before phoning:

Contact

Your company _____

Your name _____

Phone number _____

Fax number _____

Control (see name plate)

Unit no. and Revision: P/N: _____ REV: _____

Unit type MFR 13 _____

Serial number S/N _____

Description of your problem

Please be sure you have a list of all parameters available.

We appreciate your comments about the content of our publications.
Please send comments to: stgt-documentation@woodward.com
Please include the manual number from the front cover of this publication.



Woodward GmbH
Handwerkstrasse 29 - 70565 Stuttgart - Germany
Phone +49 (711) 789 54-0 • Fax +49 (711) 789 54-100
stgt-info@woodward.com

Homepage

<http://www.woodward.com/power>

Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.

Complete address/phone/fax/e-mail information for all locations is available on our website (www.woodward.com).

2007/7/Stuttgart