

**Changing Output Direction on
TM-25 and TM-200 Proportional Actuators**



General Precautions

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment.

Practice all plant and safety instructions and precautions.

Failure to follow instructions can cause personal injury and/or property damage.



Revisions

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, check manual **26311**, *Revision Status & Distribution Restrictions of Woodward Technical Publications*, on the *publications page* of the Woodward website:

www.woodward.com/publications

The latest version of most publications is available on the *publications page*. If your publication is not there, please contact your customer service representative to get the latest copy.



Proper Use

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.



Translated Publications

If the cover of this publication states "Translation of the Original Instructions" please note:

The original source of this publication may have been updated since this translation was made. Be sure to check manual **26311**, *Revision Status & Distribution Restrictions of Woodward Technical Publications*, to verify whether this translation is up to date. Out-of-date translations are marked with . Always compare with the original for technical specifications and for proper and safe installation and operation procedures.

Warnings and Notices

Important Definitions



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

- **DANGER**—Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
- **WARNING**—Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
- **CAUTION**—Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
- **NOTICE**—Indicates a hazard that could result in property damage only (including damage to the control).
- **IMPORTANT**—Designates an operating tip or maintenance suggestion.

WARNING

**Overspeed /
Overtemperature /
Overpressure**

The engine, turbine, or other type of prime mover should be equipped with an overspeed shutdown device to protect against runaway or damage to the prime mover with possible personal injury, loss of life, or property damage.

The overspeed shutdown device must be totally independent of the prime mover control system. An overtemperature or overpressure shutdown device may also be needed for safety, as appropriate.

WARNING

**Personal Protective
Equipment**

The products described in this publication may present risks that could lead to personal injury, loss of life, or property damage. Always wear the appropriate personal protective equipment (PPE) for the job at hand. Equipment that should be considered includes but is not limited to:

- Eye Protection
- Hearing Protection
- Hard Hat
- Gloves
- Safety Boots
- Respirator

Always read the proper Material Safety Data Sheet (MSDS) for any working fluid(s) and comply with recommended safety equipment.

WARNING

Start-up

Be prepared to make an emergency shutdown when starting the engine, turbine, or other type of prime mover, to protect against runaway or overspeed with possible personal injury, loss of life, or property damage.

WARNING

**Automotive
Applications**

On- and off-highway Mobile Applications: Unless Woodward's control functions as the supervisory control, customer should install a system totally independent of the prime mover control system that monitors for supervisory control of engine (and takes appropriate action if supervisory control is lost) to protect against loss of engine control with possible personal injury, loss of life, or property damage.

NOTICE**Battery Charging
Device**

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

Electrostatic Discharge Awareness

NOTICE**Electrostatic
Precautions**

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts:

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual **82715**, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Follow these precautions when working with or near the control.

1. Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as much as synthetics.
2. Do not remove the printed circuit board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
 - Do not touch any part of the PCB except the edges.
 - Do not touch the electrical conductors, the connectors, or the components with conductive devices or with your hands.
 - When replacing a PCB, keep the new PCB in the plastic antistatic protective bag it comes in until you are ready to install it. Immediately after removing the old PCB from the control cabinet, place it in the antistatic protective bag.

Changing Output Direction on TM-25 and TM-200 Proportional Actuators

Introduction

The output direction of TM-25 and TM-200 actuators may be changed in the field by competent repair personnel. Test equipment which will allow operation of the actuator from minimum to maximum stroke without controlling the fuel valve will be required after making the change.

Extend and retract TM actuators are identical except for the feedback and trim springs which control the position of the torque-motor flapper. Although the springs used in the different actuators vary in scale, they do not vary extensively in appearance. It is important to keep the springs separate and well labeled.

Models

Actuator models 9904-064 and 9904-060 that extend on increased control signal are fitted with feedback-spring assembly 3018-287 and trim spring 1524-325 to convert them into a 9904-077 or 9904-061 actuator which retracts on increased electrical control signal.

Actuator models 9904-077 and 9904-061 that retract on increased control signal are fitted with feedback spring assembly 3018-283 and trim spring 1524-539 to convert them into a 9905-064 or 9904-060 actuators which extend on increased electrical control signal.

Actuator Part Number	Direction of Output on Increased Fuel Signal	Feedback Spring	Trim Spring
9905-064 (TiM-200)	Extend	3018-283	1524-539
9904-060 (TM-25)	Extend	3018-283	1524-539
9904-077 (TM-200)	Retract	3018-287	1524-325
9904-061 (TM-25)	Retract	3018-287	1524-325

The feedback spring assembly includes a spring and a spring seat which is epoxied to the feedback spring.

Procedure

The following step-by-step procedure is provided to accomplish the change in output direction in the field. After the change is accomplished it will be necessary to install the actuator on a test device so that the amount of servo movement can be adjusted.




Figure 1. Actuator Body with Servo Piston Removed

1. Place the actuator on a clean workbench.
2. Remove the four 0.375-24 x 1.125 servo clamping screws from the output shaft end of the actuator. (The rod end may be left on the output shaft, if desired.)
3. Remove the servo and the servo-cover assembly from the actuator body by pulling in a straight line. Take care not to damage the O-ring on the cover assembly.
4. Remove the feedback spring assembly (spring with attached spring seat).
5. **Retract**—Replace the spring/spring-seat assembly with Woodward part number 3018-287 if the actuator is being changed to retract on increased fuel signal.

Extend—Replace the spring/spring-seat assembly with Woodward part number 3018-283 if the actuator is being changed to extend on increased fuel signal.

The spring seat goes against the end of the servo. The open end of the spring goes into the feedback bore first.

6. Install the servo piston and cover assembly. Take special care not to damage the blue seal on the servo piston. The seal cannot be replaced without special tooling. Use Vaseline on the O-ring to prevent damage as the cover is replaced in the actuator body.
7. Bolt the cover down. Use Led Plate or equivalent on the four stainless steel screws. Torque in an alternating pattern to 16 lb-ft (22 N·m).
8. Remove the cover from the adjustment end of the actuator by removing the three lockwired 0.250-28 cap screws and flat washers.

9. Use a sharp tool to destroy and remove the pressed-in seal in the trim-spring bore.
10. Use a 3/16 Allen wrench to remove the adjustment plug from the trim-spring bore.
11. **Retract**—Replace the trim spring with Woodward part number 1524-225 if the actuator is being changed to retract on increased signal.
Extend—Replace the trim spring with Woodward part number 1524-539 if the actuator is being changed to extend on increased signal.
12. Replace the adjustment plug. Take care not to damage the O-ring. Use Vaseline on the O-ring to make installation easier. Turn the adjustment plug in (clockwise) four complete turns.
13. Install the TM actuator on the test facility. Remove the torque motor cover (see Figure 2) and reverse the connections at soldered terminals A and B. Use new shrink tubing at the terminals. Replace the cover and mark the actuator to indicate the change in type.




Figure 2. Actuator Body with Adjustment Plug and Trim Spring Removed

14. Calibrate the actuator:

Extend—

- a. Turn on the pressure oil supply to the TM actuator. The output shaft should remain at its maximum retraction. If necessary, adjust the plug replaced in step 12 so that there is no movement of the shaft when the pressure oil is turned on.
- b. Set a travel indicator on the output shaft.
- c. Set the input current to 40 mA.
- d. Adjust the plug replaced in step 12 to extend the servo 0.125" (3.18 mm). Turn counterclockwise to increase the amount of travel, or clockwise to decrease the amount of travel.
- e. Set the test current to 200 mA. The output shaft should extend an additional 0.875" (22.22 mm) for a total movement of 1.000 to 1.025 inches (25.40 to 26.04 mm).

Retract—

- a. Turn on the pressure oil supply to the TM actuator. Adjust the plug replaced in step 12 so that the output shaft extends 1.000 to 1.025 inches (25.40 to 26.04 mm) from the body.
- b. Set a travel indicator on the output shaft.
- c. Set the input current to 40 mA.
- d. Adjust the plug replaced in step 12 to retract the shaft 0.125" (3.18 mm) with the application of 40 mA. (Turn clockwise to cause the shaft to retract more, or counterclockwise to cause the shaft to retract less.)
- e. Set the test current to 200 mA. The output shaft should retract an additional 0.875" (22.22 mm).

15. Install the new adjustment plug press-in seal.

16. Install the cover with the three screws and flat washers. Use Led Plate on the screws. Lockwire the screws to prevent removal of the cover in the future.

17. Change the part number of the actuator to conform to the new output direction.

When installing the reworked actuator be sure that:

- Linkage is correct to provide complete control of the fuel valve.
- Wiring is correct to provide the desired output movement on increased fuel signal.
- The engine or turbine is equipped with emergency shutdown equipment.

We appreciate your comments about the content of our publications.

Send comments to: icinfo@woodward.com

Please reference publication **50525B**.



PO Box 1519, Fort Collins CO 80522-1519, USA
1000 East Drake Road, Fort Collins CO 80525, USA
Phone +1 (970) 482-5811 • Fax +1 (970) 498-3058

Email and Website—www.woodward.com

**Woodward has company-owned plants, subsidiaries, and branches,
as well as authorized distributors and other authorized service and sales facilities throughout the world.**

Complete address / phone / fax / email information for all locations is available on our website.