



Product Manual 35131
(Revision A, 4/2020)
Original Instructions



ProAct™ Digital Speed Control System
for Models I and II
RoHS Compliant

Installation and Operation Manual



General Precautions

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment.

Practice all plant and safety instructions and precautions.

Failure to follow instructions can cause personal injury and/or property damage.



Revisions

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, check manual **26455**, *Customer Publication Cross Reference and Revision Status & Distribution Restrictions*, on the *publications page* of the Woodward website:

www.woodward.com

The latest version of most publications is available on the *publications page*. If your publication is not there, please contact your customer service representative to get the latest copy.



Proper Use

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.



Translated Publications

If the cover of this publication states "Translation of the Original Instructions" please note:

The original source of this publication may have been updated since this translation was made. Be sure to check manual **26455**, *Customer Publication Cross Reference and Revision Status & Distribution Restrictions*, to verify whether this translation is up to date. Out-of-date translations are marked with . Always compare with the original for technical specifications and for proper and safe installation and operation procedures.

Revisions— A bold, black line alongside the text identifies changes in this publication since the last revision.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, no responsibility is assumed by Woodward unless otherwise expressly undertaken.

Contents

WARNINGS AND NOTICES	7
ELECTROSTATIC DISCHARGE AWARENESS	8
REGULATORY COMPLIANCE	9
CHAPTER 1. GENERAL INFORMATION	10
Application.....	11
Control Applications	11
Speed Control Accessories.....	12
Actuator Accessories	12
CHAPTER 2. DESCRIPTION OF OPERATION	21
Overview	21
Control Dynamics.....	22
Fuel Limiters.....	23
Fuel Rack Limiter Map	27
Boost (External) Fuel Limiting.....	28
Lower Speed Threshold.....	28
Speed Reference and Ramps.....	29
Droop/Isochronous.....	31
ProAct Actuator	31
Return Spring.....	32
The Feedback Device	32
ProAct 75 Actuator Selection	32
CHAPTER 3. INSTALLATION	34
Control Box Location and Installation Considerations	35
Actuator Installation Considerations	35
Fuel Position Stops	36
Electrical Connections.....	37
Power Supply	38
Actuator and Position Feedback Wiring.....	39
Discrete Inputs	39
Speed Signal Input.....	41
Remote Speed Setting / Fuel Rack Limiter Input.....	41
Aux Voltage Input.....	41
Control Outputs	41
CHAPTER 4. OPERATION AND ADJUSTMENT	44
Installation Checkout Procedure	44
Establish Connection	44
Gather Required Tools & Hardware.....	45
Establishing Connection from a PC to the Application	46
Troubleshooting	48
Actuator Range Calibration	49
Actuator Travel Visual Inspection	50
Inertia Calibration	51
Friction Calibration	51
Configuration.....	52
Dynamics Settings	55
Conclusion of Test and Calibration Procedures.....	61
CHAPTER 5. SERVICE TOOL PAGES	62
Introduction.....	62
Status Bar & Navigation	62
Saving Settings	62
Home Page	63
Woodward	3

Main Page	64
Dynamics Tuning	65
Menu 1, 2 - Dynamics Settings	66
Menu 3—Speed Reference Settings	68
Menu 4—Limiter Settings.....	72
Menu 5—Monitor Menu.....	75
Menu 6a—Configuration Set Points.....	77
Menu 6b: Configuration / Actuator Test	81
Manual Calibration	82
Automatic Calibration	83
Inertia Test	84
Friction Test.....	85
Verify Position	86
Actuator Position Mapping	87
Menu 0: Diagnostics.....	88
Hour and Event Counter	89
System Page.....	90
XCP & Security	90
CHAPTER 6. SYSTEM TROUBLESHOOTING.....	91
CHAPTER 7. PRODUCT SUPPORT AND SERVICE OPTIONS	95
Product Support Options.....	95
Product Service Options	95
Returning Equipment for Repair	96
Replacement Parts.....	96
Engineering Services	97
Contacting Woodward's Support Organization	97
Technical Assistance	98
APPENDIX A. MENU SUMMARY	99
APPENDIX B. ACTUATOR CALIBRATION	103
Actuator Calibration Procedure.....	103
APPENDIX C. MIGRATE FROM OLD TO NEW (ROHS) PROACT DIGITAL SPEED CONTROL.....	104
APPENDIX D. TOOLKIT SETTINGS MANAGEMENT	105
Downloading Settings from Device	105
(ProAct Digital Speed Control → PC)	105
Uploading Settings to Device (PC → ProAct Digital Speed Control).....	110
TECHNICAL SPECIFICATIONS.....	116
REVISION HISTORY	117
DECLARATIONS	118

The following are trademarks of Woodward, Inc.:

- ProAct
- Woodward
- ToolKit

The following are trademarks of their respective companies:

- LeafLight (Kvaser AB)
- PCAN (PEAK-System)
- .NET Framework (Microsoft Corporation)
- Windows7 (Microsoft Corporation)
- Intel i5 (Intel Corporation)

Illustrations and Tables

Figure 1-1. Kvaser Leaf Light V2 Woodward Part Number 5404-1189	12
Figure 1-2. Flexible Coupling	13
Figure 1-3. Example of ProAct II Actuator	14
Figure 1-4a. Outline Drawing of ProAct I or II Actuator	15
Figure 1-4b. Outline Drawing of ProAct I or II Actuator	16
Figure 1-5a. ProAct Wiring Diagram	17
Figure 1-5b ProAct Wiring Diagram Details A, B, C	18
Figure 1-6. Outline Drawing of ProAct Control Box	19
Figure 1-7. Terminal Drawing of ProAct Control Box.....	20
Figure 2-1. Window Width for Gain Ratio	22
Figure 2-2. Triple Start Fuel Limiting.....	23
Figure 2-3. Complete Torque Map	25
Figure 2-4. Start Fuel Limit.....	25
Figure 2-5. Transient Overfuel	26
Figure 2-6. 4–20 mA Fuel Rack Limiter Map	27
Figure 2-7. A Fuel Demand (Actuator Position) Limit	28
Figure 2-8. Remote Speed Reference	30
Figure 2-9. Droop Speed Setting	31
Figure 2-10. ProAct Output Travel	32
Figure 3-1. Diesel Engine Travel Stops	36
Figure 3-2. Carburetor Travel Stops	36
Figure 3-3. Examples of Actuator Brackets	36
Figure 3-4. Preparing Shielded Wiring.....	37
Figure 3-5. Correct Wiring to Power Supply	38
Figure 3-6. Incorrect Power Supply Wiring	38
Figure 3-7. Maximum Length of Power Wiring.....	41
Figure 3-8a. Speed Switch Operation.....	42
Figure 3-8b. Speed Switch Wiring	42
Figure 3-9. Fault Lamp Output Wiring.....	43
Figure 4-1. Kvaser Leaf Light V2 (Woodward # 5404-1189)	45
Figure 4-2. CAN Termination Adapter	45
Figure 4-3. CAN Splitter Adapter	46
Figure 4-4. Can Communication USB Adapter	46
Figure 4-5. Typical Transient Response Curves.....	56
Figure 4-6. Non-Linear Valve Power Curve	57
Figure 4-7. Sample Engine Plot	57
Figure 4-8. Linearized Engine Plot.....	58
Figure 4-9. Example of Plot Created from GAIN Column	60
Figure 4-10. Example of Plot Created from ACTUATOR OUTPUT Column	60
Figure 5-1. Dynamics Map Curves	67
Figure 5-2. Accel/Decel Example.....	69
Figure 5-3. Droop Curve	70
Figure 5-4. Idle Droop	70
Figure 5-5. Speed Switch Settings.....	71
Figure 5-6. Complete Fuel Limit Map.....	74
Figure D-1. Read Settings from Device Wizard	105
Figure D-2. Save Settings File Selection Dialog	106
Figure D-3. Save Settings Network Selection Dialog	107
Figure D-4. Save Settings Device Selection Dialog.....	107
Figure D-5. Save Settings Progress Dialog	108
Figure D-6. Save Settings Attached Notes Dialog	109
Figure D-7. Save Settings Completion Dialog (Success)	109
Figure D-8. Load Settings File to Device Wizard	110
Figure D-9. Load Settings File Selection Dialog	111
Figure D-10. Load Settings Network Selection Dialog.....	111
Figure D-11. Load Settings Device Selection Dialog.....	112

Figure D-12. Load Settings Difference Warning Dialog	113
Figure D-13. Load Settings Difference Resolution Dialog	113
Figure D-14. Load Settings Acknowledgement Dialog	114
Figure D-15. Load Settings Progress Dialog	114
Figure D-16. Load Settings Completion Dialog (Success)	115
Table 1-1. Comparison of Old ProAct Control to New Control	10
Table 1-2. Actuator Output Butterfly Valve Shaft Flexible Couplings	12
Table 2-1. Actuator Selection	33
Table 3-1. Discrete Input Specification	39
Table 4-1. XCP CAN Connections	46
Table 4-2. Gain Plot Data Collection	59
Table 4-3. Load Step Gain and Actuator Output Settings	61
Table 5-1. Menu 1—Alternate Dynamics Settings*	67
Table 5-2. Menu 2—Alternate Dynamics Settings*	68
Table 5-3. Menu 3—Speed Reference Settings*	72
Table 5-4. Menu 4—Limiter Settings*	75
Table 5-5. Menu 6a - Settings*	80
Table 5-5. Menu 6b Settings	87
Table 5-6. Diagnostic Event Descriptions	88
Table 5-7. XCP & Security Menu Items, Values, and Units	90
Table 6-1. System Troubleshooting Chart	91
Table A-1. Menu 1—Dynamics Settings	99
Table A-2. Menu 2 —Alternate Dynamics Settings	99
Table A-3. Menu 3—Speed Reference Settings	100
Table A-4. Menu 4—Limiter Settings	101
Table A-5. Menu 6a—Configuration Set Points	102
Table A-6. Menu 6b—Configuration Set Points	102

Warnings and Notices

Important Definitions



This is the safety alert symbol used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

- **DANGER** - Indicates a hazardous situation, which if not avoided, will result in death or serious injury.
- **WARNING** - Indicates a hazardous situation, which if not avoided, could result in death or serious injury.
- **CAUTION** - Indicates a hazardous situation, which if not avoided, could result in minor or moderate injury.
- **NOTICE** - Indicates a hazard that could result in property damage only (including damage to the control).
- **IMPORTANT** - Designates an operating tip or maintenance suggestion.

WARNING

Overspeed / Overtemperature / Overpressure

The engine, turbine, or other type of prime mover should be equipped with an overspeed shutdown device to protect against runaway or damage to the prime mover with possible personal injury, loss of life, or property damage.

The overspeed shutdown device must be totally independent of the prime mover control system. An overtemperature or overpressure shutdown device may also be needed for safety, as appropriate.

WARNING

Personal Protective Equipment

The products described in this publication may present risks that could lead to personal injury, loss of life, or property damage. Always wear the appropriate personal protective equipment (PPE) for the job at hand. Equipment that should be considered includes but is not limited to:

- Eye Protection
- Hearing Protection
- Hard Hat
- Gloves
- Safety Boots
- Respirator

Always read the proper Material Safety Data Sheet (MSDS) for any working fluid(s) and comply with recommended safety equipment.

WARNING

Friction and Inertia

The inertia settings and friction settings must be properly adjusted using the service tool prior to engine operation. Improper inertia or friction settings can result in unpredictable actuator movement and possible personal injury or damage to the equipment.

WARNING

Start-up

Be prepared to make an emergency shutdown when starting the engine, turbine, or other type of prime mover, to protect against runaway or overspeed with possible personal injury, loss of life, or property damage.

WARNING**On- and Off-Highway
Mobile Applications:**

Unless Woodward's control functions as the supervisory control, customer should install a system totally independent of the prime mover control system that monitors for supervisory control of engine (and takes appropriate action if supervisory control is lost) to protect against loss of engine control with possible personal injury, loss of life, or property damage.

NOTICE**Battery Charging
Device**

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system. The ProAct control system has protection against damage due to disconnection of battery while charging. Deviations in operation will occur that may cause a momentary actuator movement of up to 10%.

Electrostatic Discharge Awareness

NOTICE**Electrostatic
Precautions**

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts:

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual **82715**, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Follow these precautions when working with or near the control.

1. Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as much as synthetics.
2. Do not remove the printed circuit board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
 - Do not touch any part of the PCB except the edges.
 - Do not touch the electrical conductors, the connectors, or the components with conductive devices or with your hands.
 - When replacing a PCB, keep the new PCB in the plastic antistatic protective bag it comes in until you are ready to install it. Immediately after removing the old PCB from the control cabinet, place it in the antistatic protective bag.

IMPORTANT

External wiring connections for reverse-acting controls are identical to those for direct-acting controls.

Regulatory Compliance

European Compliance for CE Marking:

These listings are limited only to those units bearing the CE Marking:

- EMC Directive:** Declared to Directive 2014/30/EU of the European Parliament and of the Council of 26 February 2014 on the harmonization of the laws of the Member States relating to electromagnetic compatibility (EMC).
- Restriction of Hazardous Substances (RoHS):** Declared to 2011/65/EC COUNCIL DIRECTIVE of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

North American Compliance:

- EMC:** This product is exempted from declaring or marking for EMC requirements in North America.

Other International Compliance:

Australia & New Zealand

- RCM:** Compliance is limited to application for those units bearing the Regulatory Compliance Mark (RCM). Only EMC is applicable in virtually all Woodward intended applications.

RCM on Woodward products is very limited due to allowed exemptions from applying the RCM or having a DoC.

- EMC:** Electromagnetic Compatibility (EMC) Declaration of Conformity (DoC) RCM requirements for the Australian and New Zealand Radiocommunications Act is a separate document only created for products applying the RCM to the label.

Products with an RCM on the label have an EMC Declaration of Conformity available:

Woodward products typically comply with at least CISPR11 Group1, Class A emissions limits, Electromagnetic Interference (EMI) testing, even if not marked with the RCM as long as the “CE mark” is on the label.

General EMC Compliance – Special Conditions for Safe Use

The unit is intended to operate with both outer and inner covers in place.

The control features exceptional spike, ripple, and EMI (electromagnetic interference) rejection. This protects the control from spurious interference and noise which can cause speed and load shifts. The chassis should be bolted to a good ground to ensure effective EMI/RFI protection.

The unit wiring is intended to be no longer than 10 m.

Discrete inputs and discrete outputs may get their wetting voltage from the EUT power and were tested as power inputs due to this setup configuration. They may also get their wetting voltage from a separate dedicated supply and were tested in this setup as well.


Chapter 1.

General Information

.This manual describes the Woodward ProAct Digital Speed Control and ProAct 75° electric powered actuators, Models I and II.

This product is meant to be a drop-in replacement for ProAct digital speed controls. The new model adds RoHS compliance. The old control has a brushed aluminum housing and the new one is black as shown in Table 1-1.

Table 1-1. Comparison of Old ProAct Control to New Control

Old ProAct (Non RoHS)	New ProAct (RoHS Compliant)
	
One control for ProAct Model I One control for ProAct Model II	Single control part number, supporting ProAct Models I and II
Part numbers for counter-clockwise actuator rotation Part number for clockwise actuator rotation	Support for software configuration of clockwise or counter-clockwise in all controls
Compatible with only non-ROHs actuators	Compatible with non-ROHs (older) and ROHs actuators (July 2019 and later)
Serial service port for handheld programmer No PC service tool	CAN XCP for service port (no handheld) Toolkit PC service tool
One control for Remote Reference One control for Fuel Limiter One control for Boost Pressure	Single control part number with configurable analog input configurable as Remote Reference, Fuel Limiter, Boost Pressure Actuator bump available to create disturbance for speed control tuning Trending of control parameters Settings files

Application

The ProAct control system is designed to control the speed of engines in mechanical drive or generator set service. The electric powered ProAct actuator has 75° of rotation and is designed for direct drive of the butterfly valve on gas engines, and through linkage with fuel racks on diesel engines.

Actuators are available in different sizes to fit specific control demands. In most cases, the ProAct II actuator will be used. The ProAct II provides 6.8 J (5.0 ft-lb) of work (transient) and 2.7 N·m (2.0 lb-ft) of torque and a slew rate of 80ms for a 10-→90% position change.

The ProAct I provides 3.4 J (2.5 ft-lb) of work (transient) and 1.4 N·m (1.0 lb-ft) of torque at steady state. ProAct I controls may be operated on nominal 12 Vdc systems. ProAct II controls require nominal 24 Vdc supply.

The ProAct Digital Speed Control includes a configurable input compatible with 4 to 20 mA or 0 to 5 Vdc electrical signals. The user may configure the system for:

- [Remote Speed Reference](#): An internal speed reference for local control of speed, and an auxiliary voltage input for load-sensor connection in load-sharing applications.
- [Fuel Rack Limiting](#) : The rack is limited to whichever is lower between the Torque Limit and 4–20 mA rack limit.
- [Boost Pressure](#) : The purpose of the manifold air pressure fuel limiter is to prevent over fueling during loading to significantly reduce black smoke in diesel engine exhaust and unburned hydrocarbons in spark gas engine exhaust.

The ProAct control system includes:

- ProAct Digital Speed Control
- External 18–32 Vdc (24 Vdc nominal) power source for Model II or a 10–32 Vdc power source for Model I
- Speed-sensing device (MPU)
- ProAct I or ProAct II actuator to position the fuel rack
- Optional load sensing device

The ProAct Digital Speed Control consists of a single printed circuit board in a sheet metal chassis. Connections are via two terminal strips and a DB9 connector.

The control chassis has an outer aluminum shield to protect the circuits from electromagnetic interference (EMI) and electrostatic discharge (ESD)

Control Applications

A ProAct control connected to a model II actuator requires 18–32 Vdc (24 Vdc nominal) uninterrupted power supply, with 125W as the maximum power consumption at nominal voltage.

A ProAct control connected to a model I actuator requires 10–32 Vdc (12 or 24 Vdc nominal) uninterrupted power supply with 50W as the maximum power consumption at nominal voltage.

ProAct actuators are designed to directly link to the butterfly in the gas engine carburetor. The control can be programmed to have variable gain to compensate for the variable gain characteristics of carbureted gas engines.

Diesel engine applications can program the control program to accommodate non-linear fuel controls or non-linear linkage arrangements.

Speed Control Accessories

- **CAN to USB Converter:** Kvaser PC CAN Interface Device (Kvaser)



Figure 1-1. Kvaser Leaf Light V2 Woodward Part Number 5404-1189

Actuator Accessories

Electrical plug to match plug on the actuator:

- 1631-187 straight plug (Non-RoHS)
- 1631-633 90° plug (Non-RoHS)


Actuator Lever for linkage connection:

- 3699-027 5-inch, 5 holes
- 3952-043 2-inch, 2 holes

Flexible couplings for direct connection of the actuator output to a carburetor's butterfly-valve shaft (dimension "X" in Figure 1-2):

Table 1-2. Actuator Output Butterfly Valve Shaft Flexible Couplings

Diameter of Butterfly Valve Shaft	Part Number
0.250	1431-431
0.312	1431-433
0.375 (9.5 mm)	1431-435
0.394 (10 mm)	1431-437
0.472 (12 mm)	1431-439
0.500	1431-443
0.625	1431-445
0.750	1431-447
0.875	1431-449



041-087
93-4-8 RAM

Figure 1-2. Flexible Coupling




Figure 1-3. Example of ProAct II Actuator

Outline Drawings




Figure 1-4a. Outline Drawing of ProAct I or II Actuator

CLOCKWISE AND COUNTERCLOCKWISE ROTATION
DEFINED BY LOOKING AT THE ACTUATOR OUTPUT
SHAFT AS SHOWN IN THIS VIEW








Figure 1-4b. Outline Drawing of ProAct I or II Actuator


NOTES:

- ⚠ MODEL I CONTROL: 10-32 VDC
MODEL II CONTROL: 18-32 VDC
- ⚠ CLOSE TO RUN
WARNING! DO NOT USE FOR EMERGENCY SHUTDOWN. THE PRIME MOVER SHOULD BE EQUIPPED WITH A SEPARATE OVERSPEED, OVERTEMPERATURE, OR OVERPRESSURE SHUTDOWN DEVICES TO PROTECT AGAINST RUNAWAY OR DAMAGE TO THE PRIME MOVER WITH POSSIBLE PERSONAL INJURY OR LOSS OF LIFE.
- ⚠ NOT USED. DO NOT CONNECT.
- ⚠ CLOSE TO USE REMOTE SPEED REFERENCE INPUT.
- ⚠ CLOSE TO USE ALTERNATE DYNAMICS.
- ⚠ USE THESE CONTACTS TO RAISE OR LOWER THE SPEED REFERENCE.
- ⚠ CLOSE FOR RATED SPEED.
- ⚠ CLOSE FOR ISOSYNCHRONOUS MODE.
- ⚠ SHIELDED WIRES TO BE TWISTED, WITH SHIELD GROUND AT ONE END ONLY. WHEN MOUNTING CONTROL TO BULKHEAD, USE EXTERNAL TOOTH LOCK WASHER UNDER ONE SCREWHEAD TO ENSURE PROPER GROUNDING.
- ⚠ DISCRETE OUTPUTS CAN BE SUPPLIED WITH UP TO 0.5 AMP AT POWER SUPPLY VOLTAGE. THE OUTPUT IS A LOW-SIDE SWITCH (RELAY CONTACT) TO POWER SUPPLY GROUND.
- ⚠ SEE PRODUCT MANUAL FOR CAN USAGE. FORCE BOOT AND RS-232 FUNCTIONALITY ARE FOR WOODWARD USE ONLY.




CUSTOMER WIRING

Figure 1-5a. ProAct Wiring Diagram






DETAIL A

WIRING TO ACTUATOR USING CIRCULAR CONNECTOR



DETAIL C

WIRING TO ACTUATOR USING CONDUIT CONNECTION WITH 'FLYING LEADS'



DETAIL B

CONTROLS TERMINAL BLOCK CONFIGURATION

35131 F1-4b
9936-505r50
11/4/19

Figure 1-5b ProAct Wiring Diagram Details A, B, C




Figure 1-6. Outline Drawing of ProAct Control Box




Figure 1-7. Terminal Drawing of ProAct Control Box

Chapter 2.

Description of Operation

General

This chapter provides an overview of the features and operation of the ProAct digital speed control and actuator system.

The ProAct Digital Speed Control uses a microprocessor for all control functions, such as computing engine speed, performing the control algorithm calculations, speed ramps, etc. All control adjustments are made with a PC connected to the control via a Control Area Network (CAN) port.

The operating program is adjusted through pages in the service built to look like the seven menus accessed through the hand held terminal display on the now unavailable previous generation control.

The speed signal itself is usually provided by a magnetic pickup supplying an AC signal from 1 to 60 Vrms to the control. The frequency (in Hz) is proportional to engine rpm.

The speed sensor logic contains a special tracking filter, designed for reciprocating engines, which minimizes the effects of engine torsionals or irregularities in the gear used for sensing speed. This provides exceptionally smooth steady-state control and allows the control dynamics to be matched to the engine.

The control features exceptional spike, ripple, and EMI (electromagnetic interference) rejection. Discrete inputs are optically isolated and capable of rejecting EMI and variable resistances in switch or relay contacts. Analog inputs are differential-type with extra filtering for common-mode noise rejection. This protects the control from spurious interference and noise which can cause speed and load shifts. The chassis should be bolted to a good ground to ensure effective EMI/RFI protection.

An auxiliary ± 2.5 volt input is provided to interface with generator controls to provide isochronous load-sharing operation, or allow speed biasing from external sources.

Overview

Once the Start Speed is reached, the fuel position limit will be set to the Min Torque Limit, but the actuator position will be controlled using the governor and the governor ramp rates. Specifically, the speed will be ramped to the Idle Speed using a rate determined by the Accel Time. Idle Speed will be maintained until the Rated Speed is selected. When Rated Speed is selected by closing the Idle/Rated switch contact, the fuel limit is set to the Maximum Fuel Limit set point value or the Torque Limit, whichever is less, for the current engine operating speed. The speed reference selected at this time is determined by the status of the Enable Remote switch. If Remote reference is not selected (Remote reference switch contacts open), the speed reference will ramp from idle to rated speed, based on the Accel Time set point. Closing either the Raise or Lower contacts (or the Remote contact) while ramping from idle to rated results in immediate cancellation of the idle-to-rated ramp. The Raise/Lower ramp rates will take over depending on whether Raise or Lower is selected.

This feature expects Idle Speed to be set higher than Start Speed. If Idle Speed is configured to a value lower than Start Speed, the control will DECREASE the engine speed to the Idle Speed at the Lower Rate. When Rated Speed is selected, the same procedure as above will be followed.

If Idle is not used, the control will ramp to Rated Speed using a rate determined by the Accel Time directly from Start Speed.

Control Dynamics

The algorithms used in the ProAct control are designed specifically for reciprocating engine applications. Control dynamics vary automatically as functions of both speed and actuator position to provide better performance over the entire engine operating range.

Variable Dynamics

The control is designed to compensate for non-linear fuel systems and changes in engine dynamics with load. The control gain is mapped as a function of actuator position.

Four break points work with four gain settings to map the actuator against expected non-linear conditions. This provides optimal dynamics and smooth steady-state operation for all conditions from no load to full engine load. The four different response rates are achieved by the creation of four different gain settings. Gas engine installations will usually require all four gain settings for different fuel flows, especially if the actuator is direct-coupled to the butterfly. Most diesel applications will need only one or two of the gain settings with the break points of the other settings moved up out of the way (set to 100%).

Alternate Dynamics

The ProAct control provides two complete sets of dynamic adjustments, which are externally switch selectable. The two sets of dynamics are provided for use where engine operating conditions change, such as in systems which use two different fuels, clutched-in loads, and electrical power generation where the unit may be operated stand-alone and paralleled with an infinite bus.

Each set of dynamics provides different gain mapping, stability, compensation, gain ratio, and gain window settings. This allows instantaneous changes in control for engines which operate with different fuels or have load-type changes which require different dynamics.

Gain Ratio is the ratio of Gain setting during transient off-speed conditions to the gain setting at steady state. Speed Gain Ratio operates by multiplying the Gain set point by the Gain Ratio when the speed error is anticipated to be greater than the Window Width. This allows a lower gain at steady state for better stability and reduced steady-state actuator movement.




Figure 2-1. Window Width for Gain Ratio

During steady-state operation with a constant load, the control uses the base gain setting. This gain is adjusted by the user to a value to prevent the control from responding to minor fluctuations in engine speed, a common problem with gas-fuel, spark-ignited engines.

This feature eliminates the potentially damaging jiggle of the actuator and fuel system. The control automatically increases gain by an adjustable gain ratio when speed error exceeding an adjustable window occurs, or is anticipated to occur, based on measurements of the instantaneous rate of change of the entire engine. Operation with base gain is restored once the control senses the return to steady-state speed. The Window Width speed is a \pm value, centered around zero speed error.

Fuel Limiters

The Start Fuel limit is combined with a user-tunable ramp that will increase the Start Fuel limit at a programmable rate while the engine speed is below the Start Speed set point. This ramp is designed to allow for easier starting of the engine during various temperature conditions, such as a cold start, which may require an increase in fuel.

Triple Start Fuel Limits

Triple Start Fuel works like three sequential Start Fuel Actuator output commands with a ramp between each. The speed control governor is not active during the start fuel limiting stages. Once Start Speed is reached, the governor is then activated for the ramp to idle (or rated) and remains in control until Zero speed is detected.

Two stages are needed to limit smoke during start-up while still achieving fast start times. The third stage is provided to allow for performance due to cold engine starts in the winter. The Start Fuel Limiting feature is cancelled after Start Speed is reached, and will not be activated again until after zero speed is detected.




Figure 2-2. Triple Start Fuel Limiting

When Start Speed BreakPoint 1 threshold is reached, the Start Fuel Limit 1 position setting is ramped to the Start Fuel Limit 2 position setting at the configured Start 1-2 Ramp Rate. Setting this rate to its maximum value effectively eliminates the ramp. When Start Speed BreakPoint 2 threshold is reached, the Start Fuel Limit 2 position setting is ramped to the Start Fuel Limit 3 position setting at the configured Start 2-3 Ramp Rate. Setting this rate to its maximum value effectively eliminates the ramp.

The Start Fuel Limits (1, 2, and 3) can be set at any level with respect to each other. The Start Speed BreakPoint thresholds should be set incrementally so that Start Speed BP 1 is lower than Start Speed BP 2, which is also lower than Start Speed.

When just a single start fuel limit is required, set the Start Fueling parameter to 1. Only start Fuel Limit 1 will be used in this case.

Ramps

While start fuel limiting is engaged, the ProAct control is operating in actuator position control mode. It is not possible to control rpm, but rpm is used for position limit threshold switching.

Start Fuel Ramping is only enabled with a single start fuel limit, Start Fueling = 1.

The fuel position will increase at the Start Ramp Rate until the Start Speed is reached (or the Max Fuel Limit is reached).

Torque Limit

The Torque Limit is an actuator position limit function. During start fuel limiting, the actuator operates in position control only. However, during run conditions (after Start Speed is first reached), the actuator operates in speed control with a position limit function imposed on the actuator position resulting from the speed control function. This implementation is called a Torque Limit. Figure 2-3 shows the torque limits imposed from start-up through running as a complete map. However, once Start Speed is reached, the torque (position) limits imposed by the start fuel-limiting feature are no longer applied even if the speed drops below the Start Speed (in this case, the Min Torque is used).




Figure 2-3. Complete Torque Map

Maximum Fuel Limit

This programmable actuator position limit is in place when rated speed is selected. This is the maximum actuator position setting allowed for steady-state full load.




Figure 2-4. Start Fuel Limit

Transient Overfuel

This feature allows the user to set the Maximum Fuel Limit near the rated engine horsepower. The Transient Overfuel will allow exceeding this Maximum Fuel Limit for a tunable percentage for a tunable time (Transient Time). This ensures good transient load acceptance while maintaining safe steady-state-horsepower limiting.




Figure 2-5. Transient Overfuel

Fuel Rack Limiter Map

Depending on the ProAct driver part number or configuration settings, a 4–20 mA or 0-5 Vdc Fuel Rack Limiter Map feature can be available. This feature is intended to activate only when Start Speed or the Lower Limit speed is reached (whichever is higher). This map works in conjunction with the Torque Limit. The fuel rack is limited to whichever is lower between the Torque Limit and the Rack limit.

When the input signal (mA / V) fails low, the limiter output will stay at Rack Limit 1.

When the input signal (mA / V) fails high, the limiter output will stay at Rack Limit 5.




Figure 2-6. 4–20 mA Fuel Rack Limiter Map

Boost (External) Fuel Limiting

Depending on the ProAct driver part number or configuration settings, a 4–20 mA or 0-5 Vdc Boost Limiter feature can be available. The Boost Fuel Limit is a software adjustable five-breakpoint curve based on an external analog input signal. Boost or Manifold Air pressure (MAP) is typically used for the external fuel limiter signal. The purpose of the manifold air pressure fuel limiter is to prevent over-fueling during loading to significantly reduce black smoke in diesel engine exhaust or unburned hydrocarbons in spark ignited gas engine exhaust. A fuel demand (actuator position) limit is set for each specific air manifold pressure breakpoint.




Figure 2-7. A Fuel Demand (Actuator Position) Limit

The limiting value is linear between breakpoints as shown. The engineering units for each breakpoint are in percent. The limiter must be carefully set since excessive fuel limiting can degrade the loading response. Occasionally exhaust temperature or other engine parameter is used for the external fuel limiting function. The external fuel limiter is not active below the run speed setting. The Maximum Fuel Limit is always active and can override a higher Boost (External) Fuel Limit setting.

When the input signal (mA / V) fails low, the limiter output will stay at Boost Limit 1.

When the input signal (mA / V) fails high, the limiter output will stay at Boost Limit 3.

Lower Speed Threshold

There is a hard-coded value for minimum speed below which the ProAct will not attempt to operate. This value is currently at 3% or 5% (depending on ProAct driver part number) of Rated Speed to facilitate easier engine starting under extreme cold conditions.

Speed Reference and Ramps

The ProAct control provides discrete local control of the speed reference with switch inputs to issue raise and lower speed commands. For remote speed setting, the control permits a 4 to 20 mA or 0 to 5 Vdc input (depending on ProAct driver part number or configuration settings) which is used to vary the speed reference. This section describes the operation of each of the speed reference and ramp functions and their relation to each other. Read this section carefully to be sure your switch gear sequencing provides the proper operating modes.

The control provides an Idle/Rated discrete input with tunable Idle and Rated Speed settings. Raise and Lower inputs will raise and lower the speed reference at tunable rates.

The Idle Speed set point is provided for engine start-up or cool-down speed. Idle speed may be set equal to or less than the Rated Speed set point. Idle Speed is independent of the Lower Limit set point and may be set to a lower speed. When Idle is selected (Idle/Rated switch in Idle position with contacts open), Remote Speed Reference and Raise and Lower inputs are disabled. Idle speed cannot be changed except through programming the Idle Speed set point.

When Rated Speed is selected by closing the Idle/Rated switch contact, the fuel limit is set to the Maximum Fuel Limit set point value or the Torque Limit, whichever is less, for the current engine operating speed. The speed reference selected at this time is determined by the status of the Enable Remote switch. If Remote reference is not selected (the Remote reference switch contacts are open), the speed reference will ramp from low idle to rated speed, based on the Accel Time set point. Closing either the Raise or Lower contacts (or the Remote contacts) while ramping from idle to rated results in immediate cancellation of the idle-to-rated ramp. The Raise/Lower ramp rates will take over, depending on whether Raise or Lower is selected.

The Raise and Lower commands ramp engine speed based on the Raise and Lower Rate set points. The Raise and Lower Limits determine the limits of these commands. If Enable Remote is selected (and Rated Speed is selected), the control will ramp speed to the reference value set by the remote speed-setting milliamp input (at the Raise or Lower Rate). The remote speed setting operates from 4 to 20 mA or 0 to 5 Vdc. The values of the 4 ma / 0 Vdc and 20 ma / 5 Vdc Remote Reference set points must be set between the Raise and Lower Limit set points. The 4 mA Remote Reference set point may be set to a lower or higher speed than the 20 mA set point, providing for either direct or reverse-acting remote speed setting.

If Remote is selected when the Idle/Rated switch contacts are closed, or during the idle-to-rated ramp, the speed reference will ramp to the speed reference value determined by the milliamps on the remote speed-setting input, based on the Raise Rate/Lower Rate set points.

Remote speed-setting inputs between 2 and 4 mA are treated as the minimum of 4 mA. Below 2 mA, the remote input is considered failed. Between 4 and 20 mA, the control determines the required speed reference based on a straight line interpolated between the 4 mA Remote Reference and 20 mA Remote Reference set points. If a difference is detected between the current speed reference and the remote reference computed from the mA input, the current speed reference is raised or lowered at the rate determined by the Raise or Lower Rate to bring the speed reference into agreement with the remote speed reference. The remote reference will not increase speed over the Raise Limit or lower it below the Lower Limit, nor change speed faster or slower than the Raise Rate/Lower Rate respectively.

When Remote Reference is selected and the remote input is failed (less than 2 mA), the speed reference remains at the current value. The speed reference can be changed in this situation only by increasing the remote reference above 2 mA or by opening the Remote Enable switch and toggling the Run/Stop switch or cycling the power to the control (cycling the power is *not* recommended).

When the current operating mode is Rated, switching to Idle results in ramping engine speed to idle based on the Decel Time set point.

If the control is in Remote Speed Reference and you wish to return to Rated Speed, the Remote switch must be in the open position and the Run/Stop switch toggled (or cycle the power to the control, which is *not* recommended), or the Idle/Rated switch shall be toggled.

A Fast Start feature is available for engine installations requiring fast start-up to rated speed. When the Fast Start feature is enabled and the Rated contact is closed when the engine is started, the speed reference will be instantly set to Rated speed setpoint, allowing quick engine startup. Only in this special case it's allowed to have the triple start fuel limiter speed setpoints set higher than Idle speed setpoint for fast open loop starting of the engine. When Fast Start is enabled, but Idle is selected when the engine is started, the engine will start to Idle.




Figure 2-8. Remote Speed Reference

Droop/Isochronous

The Droop/Isochronous switch allows selection of either type of governor operation. If Droop is selected, the ProAct control will hold engine speed according to a droop schedule entered in the program.




Figure 2-9. Droop Speed Setting

The droop schedule is based on a full 75 degrees of actuator rotation between minimum and maximum fuel. If less than 75 degrees of rotation is used, the amount of droop is reduced proportionally. Thus a control programmed for 5% droop will actually only have 2.5% droop if only 37.5° of actuator rotation is used, from no load to full load. Using only 37.5° of actuator travel will require programming 10% droop for an actual 5% droop curve (a minimum of 66° of travel is recommended).

ProAct Actuator

The ProAct actuator is a limited-angle rotational torque motor designed specifically for the control of engine fuel. The torque motor is a “run-hold” device. It responds to a fuel-position error at full speed until the position feedback causes the electronic control to change the current signal to hold position. This characteristic makes the actuator extremely fast and at the same time extremely accurate and “stiff” in engine-fuel control.

The ProAct II uses a four-pole torque motor design to provide 2.7 N·m (2.0 lb-ft) of torque (3.4 J/2.5 ft-lb work) with 6 A, 24 V input at steady state, and 5.4 N·m (4.0 lb-ft) of torque (6.8 J/5.0 ft-lb work) with 12 A, 24 V input during transient.

The actuator is equipped with internal stop springs which allow rotational overshoot of 3° in each direction. The internal spring stops are necessary to halt the rotation of rotor and load inertia without damage to the actuator. This possible over-rotation of 3° in both directions must be considered when designing linkage or connecting to the butterfly shaft.




Figure 2-10. ProAct Output Travel

The terminal shaft on the actuator provides 0.500-36 (inch) serrations. The output shaft is connected to the butterfly valve or fuel control shaft either directly through a zero-backlash flexible coupling* or through an attached lever and linkage. Installations should attempt to use as much of the actuator rotation as possible to use as much of the actuator's work capability as possible.

(*) When a flexible coupling is used, take care to assure that the maximum coupling misalignment is not exceeded and that the coupling is sized properly for the loads.

Return Spring

The ProAct actuator has an internal return spring designed to move the actuator toward minimum fuel in case the electrical control should fail, or power is removed. Spring scale may not be enough to move the engine to shutdown.

! WARNING

The fuel system should be equipped with a spring return to minimum fuel capable of moving the fuel control in case of failure in the ProAct system, the connections between the ProAct actuator and the fuel control, or loss of electrical power. The return spring should be of sufficient force to return the fuel system to minimum fuel on loss of actuator control, but should not limit the actuator's ability to properly control the engine under all operating conditions.

The Feedback Device

The feedback device is located on the closed shaft of the actuator. The older actuators use a rotary transducer which changes resistance proportional to the actuator shaft angle. The new replacement actuators use a rotary Hall Effect position sensor which changes output voltage proportional to the actuator shaft angle. The device is a non-contacting unit, thereby eliminating most wear problems.

ProAct 75 Actuator Selection

The actuator installed must match the system requirements. Select the actuator with either an MS connector or a conduit fitting with clockwise or counterclockwise rotation*.

(*) Directions are determined by looking at the actuator shaft and the rotation to increase fuel.

Table 2-1. Actuator Selection

Actuator	Woodward P/N
ProAct I, CW, MS Connector	8405-065
ProAct I, CW, Conduit Connector	8405-067
ProAct I, CCW, MS Connector	8405-089
ProAct II, CW, MS Connector	8405-069
ProAct II, CW, Conduit Connector	8405-071
ProAct II, CCW, MS Connector	8405-073
ProAct II, CW, Smooth Shaft, MS Connector	8405-075
ProAct II, CW, D-Shaft, MS Connector	8405-077
ProAct II, CCW, MS Connector for Flo-Tech Throttle Only	8405-081
ProAct II, CCW, MS Connector No Return Spring	8405-091
ProAct II, CW, Conduit Connector Threaded Shaft Hole	8405-094

NOTICE

Table 2-1 represents actuators that **WILL EVENTUALLY** be RoHS compliant. However, at this time they may not be available for sale as a RoHS compliant unit. Please contact Woodward for confirmation of status prior to ordering if RoHS is required.

Chapter 3. Installation

Unpacking

Before handling the control, read page iii, Electrostatic Discharge Awareness. Be careful when unpacking the electronic control. Check the control for signs of damage such as bent panels, scratches, and loose or broken parts. If any damage is found, immediately notify the shipper.

The ProAct actuator will come in a separate carton from the control. Inspect the carton for damage. The actuator is a rugged, heavy device and shipping damage is unlikely. Particularly inspect the receptacle and terminal shaft for possible damage.

Power Requirements

The ProAct II control system requires a voltage source of 18 to 32 Vdc (24 Vdc nominal) uninterrupted power supply. Maximum power consumption is 125 W at rated voltage. The ProAct I control system requires a voltage source of 10 to 32 Vdc (12 or 24 Vdc nominal). Maximum power consumption is 50 W at nominal voltage.

The control must be fused on the power input to prevent damage to wiring and/or circuitry during operation. The fuse should be dedicated to the ProAct and not shared with any other devices on the same power source.

Fuse Recommendations:

Model I: 5 A fast blow

Model II: 15 A fast blow

NOTICE

To prevent damage to the control, do not exceed the input voltage range.

IMPORTANT

If a battery is used for operating power, an alternator or other battery charging device is necessary to maintain a stable supply voltage.

NOTICE

To prevent damage to the control, make sure that the alternator or other battery-charging device is turned off or disconnected before disconnecting the battery from the control. This System has protection against damage due to disconnection of battery while charging. Deviations in operation will occur that may cause a momentary actuator movement, up to a 10%.

Control Box Location and Installation Considerations

Please consider the following requirements when selecting the mounting location for the ProAct Digital Speed Control :

- Adequate ventilation for cooling
- Space for servicing and repair
- Protection from direct exposure to water or condensation-prone environment
- Protection from high-voltage or high-current devices, or devices which produce electromagnetic interference
- Avoidance of vibration
- Location that provides an operating temperature range of -40 to $+70$ °C (-40 to $+158$ °F).

The ProAct Digital Speed Control is designed to be mounted using the four slots at the perimeter of the base of the unit, as shown in [Figure 1-6](#). These slots are designed for #8 (M4) hardware.

The ProAct control must NOT be mounted on the engine.

Actuator Installation Considerations

Thermal

The actuator is designed for installation on the engine. The actuator will generate heat, especially when stalled.

The feedback sensor located on the actuator has a maximum temperature limitation of 125 °C (257 °F). Should the actuator be shielded from air circulation, the installer must consider the heat conductivity of the installation bracket, and the operating temperature of the ultimate heat sink to which the bracket will be attached. Generally the heat transfer abilities of aluminum and low-carbon steel are better than high-carbon steel or stainless steel. Contact Woodward if operating temperature is a concern.

Output Coupling or Linkage

The actuator will provide up to 75° rotation from minimum to maximum positions. This will allow direct installation to most butterfly shafts. Special connectors that permit the installation of the actuator directly to a butterfly valve shaft are available. The coupling selected (or any linkage used) must be of zero backlash design. If a coupling is used it should be drilled and pinned, or serrated.

The bracket that mounts the actuator must be of adequate precision to assure that misalignment limits of the coupling used are not exceeded. Contact your control provider for help in selection of an approved coupling.

Diesel engines will generally use less rotation, often about 30 degrees. Linkage should be designed to use as much actuator rotation as possible to take advantage of the mechanical advantage

If less than 75 degrees of actuator rotation is used in a new system the new software application has an automatic calibration routine to find the stops and rescale the speed control actuator to use 0-100%.

Fuel Position Stops

Diesel installations will generally use the fuel system minimum and maximum position stops. The actuator travel should be centered within the total rotation needed from minimum to maximum fuel.

Diesel engine racks are normally designed to provide the minimum and maximum stops without binding.

Butterfly valves in carburetors will often bind if rotated too far toward minimum or maximum. For this reason, the stops in the actuator should be used at both minimum and maximum positions. Note that the stops will allow up to 3° of additional rotation in both directions during impact.

Make sure that the engine will always shut down when the actuator is at the minimum stop.




Figure 3-1. Diesel Engine Travel Stops




Figure 3-2. Carburetor Travel Stops

Actuator Bracket

The actuator may be installed on a bracket holding to the 2.248–2.251 inch diameter male pilot concentric to the terminal shaft or to a bracket which attaches to the base with four .312-18 screws with a minimum engagement of 16 mm (0.625 inch). The actuator may be mounted in any attitude. The actuator is weather proof and resistant to the corrosive effects of water and salt water, however pressure washing of the feedback device side of the actuator should be minimized.




Figure 3-3. Examples of Actuator Brackets

Replace the four outside through bolts with longer .250-20 bolts when mounting on a fixture locating on the pilot diameter. Torque the bolts to 7.3 to 8.5 N·m (65 to 75 lb-in).

When mounting on the bottom of the actuator, first apply moly disulfide or similar thread lubricant to attaching bolts and then torque to 17 to 18 N·m (150 to 160 lb-in).

NOTICE

The actuator will fall apart if the inner bolts are removed.



WARNING

NOT A STEP – The ProAct™ actuator is not designed to be used as a convenient step for climbing up on the prime mover, engine or turbine. The actuator shall be installed in a location where it won't be misused as a step.

Electrical Connections

External wiring connections and shielding requirements for a typical control installation are shown in the wiring diagram. The wiring connections are explained in the rest of this chapter.

Shielded Wiring

All shielded cable must be twisted conductor pairs. Do not attempt to tin the braided shield. All signal lines should be shielded to prevent picking up stray signals from adjacent equipment. Connect the shields to the nearest chassis ground. Discrete IO & Power may be shielded to improve robustness to EMI, but is not required to meet listed specifications. Wire exposed beyond the shield should be as short as possible, not exceeding 50 mm (2 inches). The other end of the shields must be left open and insulated from any other conductor. DO NOT run shielded signal wires along with other wires carrying large currents. See Woodward manual 50532, *EMI Control for Electronic Governing Systems*, for more information.

Where shielded cable is required, cut the cable to the desired length and prepare the cable as instructed below.

1. Strip outer insulation from BOTH ENDS, exposing the braided or spiral wrapped shield. DO NOT CUT THE SHIELD.
2. Using a sharp, pointed tool, carefully spread the strands of the shield.
3. Pull the inner conductor(s) out of the shield. If the shield is the braided type, twist it to prevent fraying.
4. Remove 6 mm (1/4 inch) of insulation from the inner conductors.

The shield must be considered as a separate circuit when wiring the system. The shield must be carried through connectors without interruption.

Installations with severe electromagnetic interference (EMI) may require additional shielding precautions. Contact Woodward for more information.

Failure to provide shielding can produce future conditions which are difficult to diagnose. Proper shielding at the time of installation is required to assure satisfactory operation of the speed control system.





Figure 3-4. Preparing Shielded Wiring

Power Supply


The power supply output must be low impedance (for example, directly from batteries).



NOTE:

 A NEGATIVE GROUND SYSTEM IS SHOWN. IF A POSITIVE GROUND SYSTEM IS USED, THE SWITCH AND FUSE MUST BE LOCATED IN SERIES WITH BATTERY (-) AND TERMINAL (TB1-2) ON THE WOODWARD CONTROL. THE POSITIVE TERMINAL BECOMES CHASSIS GROUND.

Figure 3-5. Correct Wiring to Power Supply



824-143
97-08-22 skw

Figure 3-6. Incorrect Power Supply Wiring

Run the power leads directly from the power source to the control. DO NOT POWER OTHER DEVICES WITH LEADS COMMON TO THE CONTROL. Avoid long wire lengths. Connect the positive (line) to terminal 24 and the negative (common) to terminal 25. If the power source is a battery, be sure the system includes an alternator or other battery-charging device.

DO NOT turn off control power as part of a normal shutdown procedure. Use the Run/Stop discrete input (terminal 23) for normal shutdown.

NOTICE

Do NOT apply power to the control at this time. Applying power may damage the control.

NOTICE

To prevent damage to the engine, apply power to the ProAct control for at least ten seconds before starting the engine. The control must have time to perform its power-up diagnostics and become operational. Do not attempt to start the engine if the diagnostic tests fail, because test failure turns off the output of the control.

NOTICE

To prevent possible damage to the control or poor control performance resulting from ground loop problems, follow the electrical connection instructions. The control common is electrically isolated from the power supply input.

Actuator and Position Feedback Wiring

The ProAct actuator will rotate in either direction. In models I and II, the actuator direction of rotation is selected by wiring in the actuator and the drift spring.

Connect the actuator wiring from the actuator to the ProAct control to terminals 1 (+) and 2 (–). Connect the actuator position feedback wires to terminals 7 (+), 8 (0), and 9 (–). Position feedback nominal voltages, as measured at the terminals, are approximately 3 V at minimum actuator position and 2 V at maximum actuator position.

Discrete Inputs

Discrete inputs are input commands to the ProAct Digital Speed Control that switch between two options. The discrete inputs are usually powered by the positive power supply.

Table 3-1. Discrete Input Specification

Isolation voltage	None
Input thresholds	> 4.5 Vdc = "ON" < 3.7 Vdc = "OFF"
Input impedance	25 kΩ
Max input voltage	±32 Vdc

Isoch/Droop Contact

The Isoch/Droop contact (open for droop, closed for isochronous) connects to terminal 16. When terminal 16 is open, the ProAct control will operate in droop at the percentage entered in Menu 3. When closed, the control will operate in isochronous.

The percent of droop entered in Menu 3 is based on 75° of actuator rotation between minimum and maximum positions. If the installation uses less than 75°, the amount of droop must be increased proportionally.

Idle/Rated Contact

The Idle/Rated contact (open for Idle, closed for Rated) connects to terminal 17. When the Idle/Rated contact is closed, the control immediately switches the fuel limit to the maximum limit or torque limit (whichever is less) and ramps engine speed to the rated speed set point (or the speed specified by the Remote Input when the Remote Speed Setting input at terminal 21 is enabled). When the Idle/Rated contact is opened, the control ramps engine speed to the idle speed setting.

The idle set point cannot be set above the rated set point. The fuel limiters (start, torque, and maximum) remain effective regardless of the Remote Reference input.

Lower and Raise Speed Contacts

The Lower Speed contact connects to terminal 18. Raise and Lower inputs are effective only if the control is in Rated. When the Lower Speed contact is closed, the control lowers speed at a rate determined by the Lower Rate set point. When the contact is open, speed remains at its current value. Closing the Lower Speed contact will cancel the ramps started by the Idle/Rated contact.

The Raise Speed contact connects to terminal 19. When the Raise Speed contact is closed, the control raises speed at a rate determined by the Raise Rate set point. When the contact is open, speed remains at its current value. Closing the Raise Speed contact will cancel the ramps started by the Idle/Rated contact.

Closing both Raise and Lower contacts at the same time will disable Raise and Lower speeds as long as both contacts are closed.

The Raise and Lower Speed contacts are disabled when the Remote Speed Setting mode is selected.

Alternate Dynamics

The Alternate Dynamics contact connects to terminal 20. When this contact is open, Dynamics set 1 is selected. When this contact is closed, Alternate Dynamics is selected.

Remote Reference

When Remote Reference is selected by closing the contact on terminal 21 to +24 Vdc, the Raise and Lower Speed inputs are disabled. The speed reference setting is based on the value of current in the remote speed reference input. When the contact to terminal 21 is open the Raise Speed and Lower Speed inputs are enabled. The remote speed reference is a 4–20 mA or 0-5 Vdc input. The remote speed reference range is adjusted in menu 3.

A remote reference of less than 2 mA or 0.2 Vdc is considered failed, and the control will remain at the last speed setting. To return to rated speed, the remote switch must be open and the Run/Stop switch toggled, or the Idle/Rated contact shall be toggled.

Run/Stop Fuel Contact

The Run/Stop contact (terminal 23) is the preferred means for a normal shutdown of the engine. The control will not operate without a voltage >4.5 Vdc applied to terminal 23. When the contact is closed, the voltage applied to terminal 23 allows the control to move the actuator as required for operating conditions.



WARNING

The Run/Stop contact is not intended for use in any emergency stop sequence. To prevent possible serious injury from an overspeeding engine, do NOT use the Run/Stop contact as part of any emergency stop sequence.

Speed Signal Input

Connect a magnetic pickup (MPU) to terminals 10 and 11 using shielded wire. Connect the shield to the chassis only. Do not connect the shield at the MPU end. Make sure the shield has continuity the entire distance to the speed sensor, and make sure the shield is insulated from all other conducting surfaces.

We recommend that the MPU be dedicated to the control. The MPU output should be in the range of 1 to 60 Vrms, however for best performance of the ProAct Speed Control over the entire temperature range, it is best to adjust the MPU gap to obtain a maximum output less than 30Vrms. To be compatible with the ProAct Digital Speed Control, the frequency output of the MPU should be in the range of 15Hz to 15kHz.

The Number of Gear Teeth is the number of teeth which will be exposed to the speed sensing device during one revolution of the engine. Should the sensed gear not rotate at engine speed, the number of teeth must be adjusted to reflect the proportion of engine speed to the sensed gear speed. The Number of Gear Teeth is tuned (entered) in Configuration Menu (Menu 6).



WARNING

The Number of Gear Teeth is used by the control to convert pulses from the speed-sensing device to engine rpm. To prevent possible serious injury from an overspeeding engine, make sure the control is properly programmed to convert the gear-tooth count into engine rpm. Improper conversion could cause engine overspeed.

Remote Speed Setting / Fuel Rack Limiter Input

The analog input can be used for fuel limiting or remote speed setting functions is software configurable to accept 4-20mA or 0-5V field wiring.

Connect the 4 to 20 mA current transmitter or 0 to 5 Vdc voltage transmitter to terminals 14 (+) and 15 (-). Use a shielded, twisted-pair cable. Connect the shield to the control chassis only.

Aux Voltage Input

Connect the output of a Woodward Load Sensor (if used) to terminals 12 (+) and 13 (-). Use a shielded twisted-pair cable. Wire the remainder of the load sensor in accordance with the wiring diagram for the sensor used.

Control Outputs

Actuator Control

The actuator is connected to terminals 1 (+) and 2 (-). The polarity of this connection must be correct if the actuator is to respond in the desired rotational direction. The actuator cannot be reversed by changing the polarity because of the factory-installed return spring. Use 4 mm² (12 AWG) wire to the actuator. For the best performance, the sum total length of the pairs of wires between the actuator and the control AND between the battery and the control should not exceed 20 m (65.6 ft), nominally an even split of a *maximum* of 10m each.




Figure 3-7. Maximum Length of Power Wiring

The actuator output is protected from accidental common-mode and differential short circuit faults. In the event of a short circuit in the actuator output wiring, the controller will shut down the actuator driver circuitry to protect internal components and it will signal the fault at the Fault LED, the Fault Lamp Output, and will also be annunciated in the service tool. If this fault is present, carefully inspect all actuator connections for incorrect wiring or damaged insulation prior to re-activating the control via input power cycle.

Speed Switches

Terminals 3, 4, and 5 provide the outputs from speed switches A, B, and C. These outputs close an internal relay to ground to enable external speed switch equipment. See Figure 3-8b for diagram. Each speed switch output is rated to 500 mA. The output will operate a signal lamp directly, or may be connected to an intermediate relay to conduct heavier switch operations. The internal relay is pilot duty rated to NEMA B300 and is designed to handle switching into inductive loads such as relay coils and solenoids. The total length of the wire between the speed switches and the signal lamp or relay should not exceed 10 m (32.8 ft).

The switches are configured in Menu 3 and operate as shown in Figure 3-8a.




Figure 3-8a. Speed Switch Operation




Figure 3-8b. Speed Switch Wiring

NOTICE

If the speed switch outputs are tied to delicate equipment or there is reason to believe the current in the output circuit could exceed 500mA, it is advisable to place a fuse in series with the load attached to the speed switch terminal.

Fault Lamp

Terminal 6 provides the output for the fault lamp indicator. This output closes an internal relay to ground to annunciate a fault condition. See Figure 3-9 for wiring diagram. The output will operate a signal lamp directly, or may be connected to an intermediate relay to conduct heavier switch operations, such as a fault trip string. The internal relay is pilot duty rated to NEMA B300 and is designed to handle switching into inductive loads such as relay coils and solenoids. The faults indicated include actuator position feedback supply & voltage out of range, driver diagnostics faults, motor Differential & Common Mode current faults.

The total length of the wire between the fault lamp output and the signal lamp or relay should not exceed 10 m (32.8 ft).




Figure 3-9. Fault Lamp Output Wiring

NOTICE

If the fault output is tied to delicate equipment or there is reason to believe the current in the output circuit could exceed 500mA, it is advisable to place a fuse in series with the load attached to the speed switch terminal.

Actuator Position Feedback

Shielded wire must be connected to the Actuator Position Feedback terminals 7, 8, and 9. The shield must be continuous and grounded at the control end only to prevent interference with the position feedback signal.

Chapter 4.

Operation and Adjustment

Introduction

Because of the variety of installations, plus system and component tolerances, the control must be tuned to each system for optimum performance.

This chapter contains information on control calibration. It includes initial prestart-up and start-up settings and adjustments.



WARNING

An improperly calibrated control could cause an engine overspeed or other damage to the engine. To prevent possible serious injury from an overspeeding engine, read this entire procedure before starting the engine.

Installation Checkout Procedure

With the installation complete as described in this chapter, do the following check out procedure before beginning the start-up adjustments in Chapter 4.

a. Visual Inspection

- i. Check the linkage or coupling between the actuator and fuel metering device for looseness or binding.
- ii. Check for correct wiring in accordance with the wiring diagram ([Figure 1-4](#)).
- iii. Check for broken terminals and loose terminal screws.
- iv. Check the speed sensor for visible damage. If the sensor is a magnetic pickup, check the clearance between the gear and the sensor, and adjust if necessary. Clearance should be between 0.25 and 1.25 mm (0.010 and 0.050 inch) at the closest point. Make sure the gear runout does not exceed the pickup clearance.

b. Check for Grounds

Check for grounds by measuring the resistance from all control terminals to chassis. All terminals except terminals 9, 11, and 25, should measure infinite resistance (the resistance of terminals 9 and 11 depends on whether a floating or grounded power source is used). If a resistance less than infinite is obtained, remove the connections from each terminal one at a time until the resistance is infinite. Check the line that was removed last to locate the fault.

c. Chassis Ground

Check for resistance from chassis to earth ground. The resistance should about be zero Ohms. If earth ground is not available, tie the chassis to system ground.

Establish Connection

Establishing a connection with the control is discussed in two essential steps:

1. Gather Required Tools & Hardware
2. Connect PC CAN Adaptor and ProAct Digital Speed Control CAN Port

Gather Required Tools & Hardware

Install the ProAct Digital Speed Control ToolKit® service tool, which can be downloaded from the Woodward website: www.woodward.com. It may include an embedded ToolKit® software as well, which can alternatively also be downloaded from the Woodward website separately.

Search term “**ProAct Speed Control**” should help you locate the service tool software.

The ProAct service tool requires ToolKit version 5.6.2 or higher

USB Adapter

ToolKit supports IXXAT VCI 3, Kvaser CANlib 5.20, and RP1210B SDK's, which allows ToolKit to work with a variety of IXXAT, Kvaser, and RP1210 CAN devices. Ensure your PC meets the following minimum set of requirements:

- Windows7 or greater
- NET Framework 4.5.1 or greater
- Toolkit will confirm the version if it is unknown
- Intel i5 w/GPU or better for optimal PC performance
- Kvaser drivers
 - Installed automatically with ToolKit

Woodward recommends the following Kvaser PC CAN Interface device:



Figure 4-1. Kvaser Leaf Light V2 (Woodward # 5404-1189)

Other useful CAN accessories (not required with simple CAN interface to ProAct Digital Speed Control connection) include:

- CAN termination adapter: (Woodward # 10-011-107)



Figure 4-2. CAN Termination Adapter

CAN splitter adapter:



Figure 4-3. CAN Splitter Adapter

Some adapters will require the removal of the two D-Sub retainer standoffs at the CAN service port on the ProAct Digital Speed Control. These standoffs can be removed from the control with a 3/16 inch socket wrench or nut driver. Removal of these standoffs will not impact the functionality of the control.

Establishing Connection from a PC to the Application

Plug in your compatible CAN communication USB adapter into your PC if not already connected.







Figure 4-4. Can Communication USB Adapter

Table 4-1. XCP CAN Connections

Name	Interface	Defaults
XCP1	CAN @ 500k	Command ID = 188C12F1 (HEX) Response ID = 188BF112 (HEX)
XCP2	CAN @ 500k	Command ID = 1B8C12F1 (HEX) Response ID = 1B8BF112 (HEX)

There will be this symbol  with a number for each step and the same callout on a print screen for where the step is executed.


<p>1 <input type="checkbox"/> Run the ProAct Digital Speed Control Service Tool</p> <p>Toolkit should start up, open the service tool, and show the Home page</p>	
<p>2 <input type="checkbox"/> Left click “Connect”</p>	
<p>3 <input type="checkbox"/> Select the CAN adapter & channel (Hint: It's never a "Virtual")</p> <p>4 <input type="checkbox"/> Set the Protocol to “XCP”</p> <p>5 <input type="checkbox"/> Set baud rate to “Baud_500Kbits”</p> <p>6 <input type="checkbox"/> Check the two boxes under “Extended”</p> <p>7 <input type="checkbox"/> “Command” ID enter 188C12F1 (0=the number zero)</p> <p>8 <input type="checkbox"/> “Response” ID enter 188BF112 (0=the number zero)</p> <p>9 <input type="checkbox"/> Hit “Add”</p> <p>10 <input type="checkbox"/> Check the box next to the newly created “Alias” 188C12F1. <ul style="list-style-type: none"> The Alias can be renamed to “ProAct Digital Speed Control XCP” to avoid future confusion by right clicking your mouse and selecting Rename. </p> <p>11 <input type="checkbox"/> Finally, left-click the connect button on the bottom of panel.</p>	
<p><input type="checkbox"/> The bottom left of the Toolkit window should say “Connected on Kvaser....” or similar</p>	

If unsuccessful see Troubleshooting section below.

After a connection is made a **“Security Login”** window will pop up where you can select the appropriate login level and enter the control provider's password; see **XCP & Security** for login information.

<p>12 <input type="checkbox"/> Security Level: <input type="checkbox"/> “Operator”</p> <p>13 <input type="checkbox"/> Password “0”</p> <p>14 <input type="checkbox"/> Press “Log In” <input type="checkbox"/></p>	
---	--

Once successfully connected and logged in, the display values on “Navigation” will become live and look similar to this page:



Troubleshooting


First Time Kvaser Installation

Sometimes the PC needs to be restarted to finish the installation of the Kvaser drivers.

Security

If an incorrect password is entered you must press “Close” then “Connect”. XCP Toolkit only allows 1 try at entering the correct password per sequence that starts with “Connect”.

Incorrect CAN Channel Used

<ul style="list-style-type: none"> Do not use a “Kvaser Virtual” channel. The 2 channel Kvaser USBcan R HS/HS converters labels for each DB9 is “1” based counting. The callout in Toolkit matches what Windows uses and is “0” based. <ul style="list-style-type: none"> A So if the DB9 with the label “Ch.1 CAN HS” is connected to the RT-CDC AUX hardware select “Kvaser USBcan R #0 (Channel 0)” B So if the db9 with the label “Ch.2 CAN HS” is connected to the RT-CDC AUX hardware select “Kvaser USBcan R #0 (Channel 1)” 	
--	--

Incorrect Connection Settings

If the incorrect baud rate or ID is specified or if the wiring is incorrect, ToolKit will indicate a status of “Connecting” in the Details dialog. The CAN communications device, such as Kvaser Leaf Light V2, may flash a red error light.

To resolve the issue confirm:

- Protocol is “**XCP**”
- Baud rate is set to “**Baud_500Kbits**”
 - o The “**AutoDetection**” setting does not work with Toolkit XCP connections.
- Check the two boxes under “**Extended**”

Confirm that there is a device under the word “Alias” where

- 188C12F1** (0=the number zero) is the “Command” ID
- 188BF112** (0=the number zero) is the “Response” ID

It is common to configure the address and forget to hit “Add” for example, leading to no boxes to check under “Alias”.

Incorrect CAN Wiring

Control will just saying “Connecting” forever. Connect Kvaser adapter directly to DB9 on control eliminating any extension cables.

Changed XCP ID’s & Baud Rate

At the OEM access level it is possible to change the XCP ID’s and baud rate, but unless the OEM has valid reasons to change the XCP ID’s, we strongly advise changing these XCP settings.


Actuator Range Calibration

The new ProAct™ Digital Speed Control comes with a default calibration that nominal 0-75 degrees stroke for a 0~100% position demand with all suitable actuators. For fine-tuning purposes there is an option to calibrate the actuator to minimum and maximum position. Please refer to this section: **Menu 6b: Configuration / Actuator Test**

If retrofitting an existing system, the calibration step should be skipped.

Actuator Travel Visual Inspection

The actuator travel may be checked using the “Verify Position” test mode on **Menu 6b: Configuration / Actuator Test** of the service tool.



IMPORTANT

Do not crank or attempt to start the engine during this procedure.

WARNING

To prevent possible serious injury from an overspeeding engine, it is important to have the Failsafe switch enabled prior to cranking the engine.

Inertia Calibration

IMPORTANT

Do not crank or attempt to start the engine during this procedure.

The inertia setting calibration value may be checked using the “**Inertia Test**” test mode on **Menu 6b: Configuration / Actuator Test** of the service tool.

The inertia setting calibrates the position controller to the load inertia. A setting of zero represents the actuator shaft with no load attached. The higher the load inertia, the higher the required inertia setting.

The position calibration wizard provides an opportunity to test the settings. When the Test button is pressed, the actuator will go to the 30% position, pause, go to the 60% position, pause, return to the 30% position, pause, and go to the 0% position. The actuator response to these steps helps determine the correct inertia setting.

If the inertia setting is too low, there may be a slow oscillation when the actuator should be steady, or the step response may show excessive overshoot and ringing. If the inertia setting is too high, a high frequency oscillation or limit cycle may be seen. If a range of values is seen to provide adequate response, the lowest value that does not produce overshoot should be chosen.

Friction Calibration

IMPORTANT

Do not crank or attempt to start the engine during this procedure.

The inertia setting calibration value may be checked using the “**Friction Test**” test mode on **Menu 6b: Configuration / Actuator Test** of the service tool.

The friction setting represents the actuator current required to overcome static load friction.

Where no spring return is present, the Input Current value should be increased until the actuator just begins to move. That value of Input Current should then be entered as the Friction Setting. Ideally, this should be done in the middle of the travel range, and not at either end.

Where a return spring is present, the input current should be gradually increased until the actuator begins to move against the spring, then gradually decreased until it moves in the opposite direction. The Friction Setting should be one-half of the difference between these two values. For example, if it takes 0.7 A to begin moving against the spring, and at 0.5 A the actuator moves with the spring in the opposite direction, set the Friction Setting at $(0.7 - 0.5) / 2 = 0.1$ A.


If the friction setting is too low, the actuator may not respond well to small changes in the position demand. If the friction setting is too high, a high frequency oscillation or limit cycle will be seen.

Configuration


Prestart Settings Creation

Some users find using the Offline Settings editor is easier for their first commissioning. The Offline Settings Editor only shows any tunable settings, making it easier to find each parameter that needs configuration.

There will be this symbol  with a number for each step and the same callout on a print screen for where the step is executed.

<p> <input type="checkbox"/> Run the ProAct Digital Speed Control Service Tool</p>	
<p> <input type="checkbox"/> Left click "Settings"</p> <p> <input type="checkbox"/> Left Click "Edit Settings File..."</p>	
<p> <input type="checkbox"/> Select a valid settings file (typically part of the service tool installation) or created one-self or provided by the OEM</p> <p><input type="checkbox"/> Left Click "Open"</p>	 <p style="text-align: center;"></p>

- 5 When the settings file being opened doesn't match the Service Tool revision, this popup window will appear
- 6 Select the "5418-..."
- 7 Left click "OK"



- 8 Configure as needed

Offline settings editor

Menu 3: Speed Reference Settings

Rated Speed: 1800.0 rpm

Idle Speed: 1200.0 rpm

Raise Limit: 1890.0 rpm

Lower Limit: 1200.0 rpm

Accel Time: 8.0 s

Decel Time: 8.0 s

Raise Rate: 2500 rpm/min

Lower Rate: 2500 rpm/min

Droop: 5.00 %

Idle Droop: 0.00 %

Idle Droop BreakPoint: 0.0 %

Fast Start to Rated

Speed Switch A On: 600.0 rpm

Speed Switch A Off: 540.0 rpm

Speed Switch B On: 1200.0 rpm

Speed Switch B Off: 1140.0 rpm

Speed Switch C On: 2000.0 rpm

Speed Switch C Off: 1900.0 rpm

Menu 4: Limiter Settings

Start Fueling: 1

Start Ramp Rate: 1.000 %/s

Start Fuel Limit: 20.0 %

Start Speed: 400.0 rpm

Stop Speed: 300.0 rpm

Max Fuel Limit: 100.0 %

Transient Limit: 0.0 %

Transient Time: 0.0 s

Min Torque Limit: 50.0 %

Torque Limit BP: 1500.0 rpm

Torque Limit at BP: 70.0 %

Max Torque Limit: 90.0 %

Fuel Rack BP (%)

1	10.0
2	20.0
3	30.0
4	40.0
5	50.0

Fuel Rack Limit (%)

1	100.0
2	100.0
3	100.0
4	100.0
5	100.0

Configure Analog Input

Function: 2: Fuel Rack Limiter

Type: 1: 4-20mA

Fuel Rack Limiter (mA) | Fuel Rack Limiter (%)

L: 4.0 | 0.0

H: 20.0 | 100.0

Fuel Rack Limiter (V) | Fuel Rack Limiter (%)

L: 0.5 | 0.0

H: 4.5 | 100.0

Range limits

High: 20.500 mA

High: 4.800 V

Low: 2.000 mA

Low: 0.200 V


Fault delay: 0.0 s

Out of range alarm High ?

Out of range alarm Low ?

Configure Auxiliary Input (+/-2.5V)

AUX Gain (Default 1 equals 3% of RATED / Volt): 1.000

<ul style="list-style-type: none"> <input type="checkbox"/> 9 Left Click on File <input type="checkbox"/> Left Click on “Save As...” <input type="checkbox"/> Create a file name as desired <input type="checkbox"/> Left Click “Save” 	
<ul style="list-style-type: none"> <input type="checkbox"/> Connect to control (if not already) <input type="checkbox"/> Left click “Settings” 10 <input type="checkbox"/> Left Click “Load Settings File to Device...” <input type="checkbox"/> Updates settings as needed to clear faults 	 <div style="border: 2px solid black; padding: 10px; margin-top: 10px;"> <p>IMPORTANT Only settings up to your login security level will be updated and saved to the ProAct™ Digital Speed Control!</p> </div>

Dynamics Settings

Menu 1—Primary Dynamics Settings

The four Gain set points and break points determine the actuator response to a change in speed or load. These settings can vary as a percent of existing load in nonlinear fuel systems.

The adjustments are settings that affect the stability and transient performance of the engine. A large number will provide a faster response to an error between actual speed and reference speed. A small number will provide a slower response to an observed error in speed.

Gain becomes an important portion of the programming that determines the response and stability of an engine.


The control provides two sets of dynamics. Menu 1 sets the primary (normal) dynamics. Menu 2 provides a second set of dynamics for use with an alternate fuel or other conditions which require different control factors.

The set of dynamics being used is selected by the Alternate Dynamics contact input (open for normal dynamics and closed for alternate dynamics).


The following descriptions apply to either set of dynamics. See Figures 4-1 through 4-4

The four Gain and Gain Breakpoint settings in Menus 1 and 2 provide different response scales to changes in load or speed depending on the existing actuator position. This allows the ProAct control to be programmed to provide a response scale that matches the engine response over the no load to full load range.


RESULTS – GAIN AND STABILITY ADJUSTMENTS



IDEAL LOAD STEP RESPONSE



RESULTS – COMPENSATION ADJUSTMENT



Use compensation to achieve most stable engine speed.

851-004

Figure 4-5. Typical Transient Response Curves

Gas Engine Setup

Change in the butterfly valve position is not linear in comparison to engine power output. In naturally-aspirated (non-turbocharged) engines, the position of the valve in comparison to engine output appears on a chart similar to Figure 4-2.




Figure 4-6. Non-Linear Valve Power Curve

Turbocharged engines distort this curve, particularly as turbo pressure builds to the point of operating the waste gate. A turbocharged gas engine will likely have a butterfly position chart similar to Figure 4-3.





Figure 4-7. Sample Engine Plot

Note in both charts that the valve position falls on a curve. The ProAct menu does not permit the construction of a curve. However, with four slope segments available for the Proportional Gain term, a rough approximation of the curve can be created (see Figure 4-4).



041-090B
00-05-16

Figure 4-8. Linearized Engine Plot

Diesel Engine Setup

Most diesel engine fuel controls are nearly linear. The dynamics maps may still be used to accommodate nonlinear conditions caused either by the fuel system or by linkage between the actuator and the rack. For gain settings that are not used, set the associated breakpoint at 100%.

Control Gain Programming Steps

<p>1 <input type="checkbox"/> Navigate to “Dynamics Tuning Page”</p>	
<p>2 <input type="checkbox"/> Press “Start” to start trend</p> <p><input type="checkbox"/> Attempt to Start Engine</p> <p><input type="checkbox"/> If engine does not start Navigate to Menu and adjust “Start Fuel Limit 1” as needed</p>	

1. Gain programming is needed whenever the gain of the engine and fuel system is non-linear. This usually occurs in gas engine applications. A plot of the fuel system must be determined to properly adjust the gain of the control to match the gain of the system at all loads.

The plot reflects the actuator output, as seen in Menu 5, versus the engine load as load is varied from no load to full load.

a. **To construct a gain plot:**

- I. Set the Gain A breakpoint for 100%. This ensures that there won't be any confusion with other settings while plotting the system characteristics. Only Gain A, Stability, and Actuator Compensation will be used.
- II. Start the engine and obtain good control at no load using Gain A, Stability, and Actuator Compensation. Record these settings and the actuator output as displayed in Menu 5.
- III. Step load the engine with as many load steps as are practical. At each load step, Gain A may need to be varied to maintain engine stability. Do not change stability or actuator compensation after the first setting in step b. Should it be necessary to change these settings to obtain good control, repeat all previous steps until only Gain is changed at each load step. At each load step, record the actuator output that is displayed in Menu 5. Also record the engine load and Gain A at each point.

Table 4-2 aids in collecting the data for the Gain Plot.

Gain settings reflect the amount of slope as shown in Figure 4-5. Flat portions of the engine plot will require relatively small amounts of gain, steep portions of the plot will require larger gain numbers.

- IV. Create a plot of the system by plotting actuator output as a function of load. A typical result is shown in Figure 4-5.

Table 4-2 may help in the construction of the plot. Use as many load steps as possible.

Table 4-2. Gain Plot Data Collection

Load Step	Gain (for good control)	Actuator Output
Load Step 1		
Load Step 2		
Load Step 3		
Load Step 4		
Load Step 5		
Load Step 6		
Load Step 7		
Load Step 8		
Load Step 9		
Load Step 10		
Load Step 11		
Load Step 12		
Load Step 13		
Load Step 14		
Load Step 15		
Load Step 16		
Load Step 17		
Load Step 18		
Load Step 19		
Load Step 20		

2. Set Gain A to the value recorded in Step 1b. This should give good control at no load.
3. Use the plot of the engine to determine the linearity of the fuel system. This curve should be linearized between inflection points as shown in Figure 4-9.

4. Set the Gain A Breakpoint for the actuator output at or slightly below the value at the first inflection point. The gain of the electronics is constant for actuator outputs less than the Gain A Breakpoint.
5. Set the Gain B Breakpoint at the point slightly above the first inflection point in the actuator output versus load plot.
6. Gain B should now be adjusted to obtain good control at the inflection point. Note: you may already have obtained the correct value in Step 1c.
7. Set the Gain C Breakpoint slightly below the next inflection point in the curve obtained in 1d.
8. Gain C should now be adjusted to obtain best control at this point. Note: the correct value for Gain C may already have been obtained in Step 1c for this load.
9. Gain D breakpoint is normally higher than the second inflection point. The gain of the control is constant after this point.
10. Gain D is adjusted for the best response at full load. This value may also have been determined in Step 1c.




Figure 4-9. Example of Plot Created from GAIN Column




Figure 4-10. Example of Plot Created from ACTUATOR OUTPUT Column

Stability, Actuator Compensation, Gain Ratio, Window Width

11. Stability (also known as Reset) compensates for the lag time of the engine. It adjusts the time required for the control to return the speed to zero error after a disturbance. Stability is adjusted to prevent slow hunting and to minimize speed overshoot after a load disturbance.
12. Compensation compensates for the actuator and fuel system time constant.
13. Gain Ratio operates in conjunction with the Window Width and Gain adjustments by multiplying the Gain set point by the Gain Ratio when the speed error is greater than the Window Width. This makes the control dynamics fast enough to minimize engine speed overshoot on start-up and to reduce the magnitude of speed error when loads are changing. This allows a lower gain at steady state for better stability and reduced steady-state actuator movement.
14. Window Width is the magnitude (in \pm rpm) of a speed error at which the control automatically switches to fast response. The control does not use the absolute value of speed error, but an “anticipated” speed error, to make this switch. This method provides for quick switching to the high gain value when an off speed occurs, and early switching to the low gain value when recovering from the speed transient. This provides smoother switching than if the absolute speed error were used for the window.

Menu 2—Alternate Dynamics Settings

Menu 2 should be programmed similar to Menu 1, but with the alternate fuel or other operating condition expected. The four Gain settings and breakpoints may be set like those used in Menu 1. The Stability, Compensation, Gain Ratio, and Gain Window will probably be quite different if different fuels are being used.

If the engine will not use the alternate operating condition, the menu will not have to be programmed or it can be programmed identically with the Menu 1 to prevent unintentional changes in the dynamics program.

Table 4-3. Load Step Gain and Actuator Output Settings

Load Step	Gain (for good control)	Actuator Output
Load Step 1		
Load Step 2		
Load Step 3		
Load Step 4		
Load Step 5		
Load Step 6		
Load Step 7		
Load Step 8		
Load Step 9		
Load Step 10		
Load Step 11		
Load Step 12		
Load Step 13		
Load Step 14		
Load Step 15		
Load Step 16		
Load Step 17		
Load Step 18		
Load Step 19		
Load Step 20		

Conclusion of Test and Calibration Procedures

This completes the calibration instructions. Save the set points by pressing the “Save Values” icon at the top of the service tool.



NOTICE

To prevent possible damage to the engine resulting from improper control settings, make sure you save the set points before removing power from the control. Failure to save the set points before removing power from the control causes them to revert to the previously saved settings.

WARNING

Be prepared to make an emergency shutdown when starting the engine, turbine, or other type of prime mover, to protect against runaway or overspeed with possible personal injury, loss of life, or property damage.

Chapter 5.

Service Tool Pages

Introduction

The ProAct Toolkit service tool provides the same menu's as are available on the old Handheld, and also more pages for new features.

Please consult Establish Connection for setting up the CAN connection and basic information about working with Toolkit and settings files.

*~~Strikethrough~~ removed, compared to legacy ProAct driver
 *Underline new, compared to legacy ProAct driver
 ***option** ProAct driver part-number dependent, configuration option

Status Bar & Navigation




The header in the ProAct Toolkit service tool provides status information of the control.

“Config Mode”, “Test Mode”, “Config Fault”, “Alarm” and “Shutdown” status buttons also act as navigation buttons to the configuration and diagnostic pages.

The “ESD” button allows the operator to shut down the engine control from the ProAct Toolkit service tool

Saving Settings

Settings can be saved to the ProAct driver by either pressing the standard Toolkit save button  at the top, or selecting “Save Values...” from menu “Device”.




Some ProAct Toolkit service tool pages have additional buttons for Save, Save & Reboot and Reboot (no Save).

The “Save” button has the same function as the standard Toolkit save method. Configuration parameters like “Number of Gear Teeth”, “Speed Function Type”, “Speed Samples” require the control to reboot prior to start using the changed settings, “Save & Reboot” combines both actions.

To discard any changed settings which have not been saved yet, the “Reboot (no Save)” button can be used to simply reboot the control. Alternatively, removing and re-applying the power to the control can be used to discard any unsaved settings changes.

Home Page



When the service tool is opened and the CAN connection is still offline, the Home page will be shown.


The CAN XCP connection settings are listed, typically XCP1 will be used.

The service Tool part number is shown and shall match the software part number on page System.

A specific service tool will only operate with the ProAct Digital Speed Control part numbers listed on the Home page.

Once the CAN XCP connection is made, the tool will navigate to Main Page.

Main Page



From the Main page, one can quickly navigate to the parameter menu's 0 ~ 6 which are almost identical to the original menu's available on the old ProAct Digital Speed Control driver's Handheld

From any Toolkit page, one can return to this Main page by pressing the home navigation button located at the top to the right.



Dynamics Tuning

The Dynamics Tuning page can be helpful for optimizing the controller's dynamics settings for closed loop speed control.

Only the selected dynamics settings (normal or alternate) are displayed and accessible from this page.

An embedded trend can visually aid in optimizing speed/load disturbance step responses.

When speed/load cannot be changed externally, the Actuator Bump function may help.

Actuator Bump
one-time trigger

The Bump Amplitude will be added to the current actuator output demand for the duration of Bump On time when the Actuator Bump one-time trigger button is pressed. As a result of this forced error, the speed controller will start to react.

Automatic Actuator Bump

Alternatively, the Automatic Actuator Bump function can be enabled, by ticking the box. An actuator bump disturbance will be retriggered after Bump Off Time has passed.



WARNING

Make sure Automatic Actuator Bump is unselected with testing and prevent from saving it in selected state to the control's non-volatile memory or a Toolkit settings file.

Min and Max speed monitoring can help determining optimize dynamics by capturing the minimum and maximum speed as a result of a load step test.

Clear

The respective Clear buttons will clear these values to the current speed.

Menu 1, 2 - Dynamics Settings

Menu 1: Dynamics Settings		Menu 2: Alternate Dynamics Settings	
	Gain BreakPoint (%) — Gain ()		Gain BreakPoint (%) — Gain ()
A	0 0.2500	A	0 0.1000
B	30 0.2500	B	30 0.1000
C	60 0.2500	C	60 0.1000
D	100 0.2500	D	100 0.1000
Stability	0.250 s	Stability	1.000 s
Compensation	0.100 s	Compensation	0.200 s
Gain Ratio	1.000	Gain Ratio	1.000
Window Width	60.0 rpm	Window Width	60.0 rpm

The four Gain set points and break points determine the actuator response to a change in speed or load. These settings can vary as a percent of existing load in nonlinear fuel systems. The adjustments are settings that affect the stability and transient performance of the engine. A large number will provide a faster response to an error between actual speed and reference speed. A small number will provide a slower response to an observed error in speed.

Gain becomes an important portion of the programming that determines the response and stability of an engine.

The control provides two sets of dynamics. Menu 1 sets the primary (normal) dynamics. Menu 2 provides a second set of dynamics for use with an alternate fuel or other conditions which require different control factors.

The set of dynamics being used is selected by the Alternate Dynamics contact input (open for normal dynamics and closed for alternate dynamics).




Figure 5-1. Dynamics Map Curves

The following descriptions apply to either set of dynamics. See Figure 5-1.

The four Gain and Gain Breakpoint settings in Menus 1, 2 provide different response scales to changes in load or speed depending on the existing actuator position. This allows the ProAct control to be programmed to provide a response scale that matches the engine response over the no load to full load range.

Table 5-1. Menu 1—Alternate Dynamics Settings*

Menu Item	Low Value	Default Value	High Value	Units
Gain A	0.0003	0.25	10	NA
Gain A break point	0	0	100	%
Gain B	0.0003	0.25	10	NA
Gain B break point	0	30	100	%
Gain C	0.0003	0.25	10	NA
Gain C break point	0	60	100	%
Gain D	0.0003	0.25	10	NA
Gain D break point	0	100	100	%
Stability	0	0.25	10	seconds
Compensation	0	0.1	10	seconds
Gain Ratio	1	1	50	NA
Gain Window	0	60	2000	rpm

Table 5-2. Menu 2—Alternate Dynamics Settings*

Menu Item	Low Value	Default Value	High Value	Units
Alt Gain A	0.0003	0.1	10	NA
Alt Gain A break	0	0	100	%
Alt Gain B	0.0003	0.1	10	NA
Alt Gain B break	0	30	100	%
Alt Gain C	0.0003	0.1	10	NA
Alt Gain C break	0	60	100	%
Alt Gain D	0.0003	0.1	10	NA
Alt Gain D break	0	100	100	%
Alt Stability	0	1	10	seconds
Alt Compensation	0	0.2	10	seconds
Alt Gain Ratio	1	1	50	NA
Alt Gain Window	0	60	2000	rpm

Menu 3—Speed Reference Settings

Menu 3: Speed Reference Settings


Rated Speed	1800.0	rpm	Speed Switch A On	600.0	rpm
Idle Speed	1200.0	rpm	Speed Switch A Off	540.0	rpm
Raise Limit	1890.0	rpm	Speed Switch B On	1200.0	rpm
Lower Limit	1200.0	rpm	Speed Switch B Off	1140.0	rpm
Accel Time	8.0	s	Speed Switch C On	2000.0	rpm
Decel Time	8.0	s	Speed Switch C Off	1900.0	rpm
Raise Rate	2500	rpm/min			
Lower Rate	2500	rpm/min			
Droop	5.00	%	L	4.0	Remote Speed Setpoint (rpm) -
Idle Droop	0.00	%	H	20.0	Remote Speed Setpoint (mA) -
Idle Droop BreakPoint	0.0	%		1710.0	Remote Speed Setpoint (rpm) -
				1890.0	Remote Speed Setpoint (rpm) -

Fast Start to Rated

Speed adjustments are the settings that affect the speed reference. Descriptions of each menu item follow.

1. Rated Speed Reference sets the normal operating speed of the engine in rpm.
2. Idle Speed Reference sets the speed in rpm at which the engine is operated at start-up. It sometimes is used during cool down.
3. Raise Limit is the maximum speed reference setting in rpm. It is used to limit the Raise Speed command and Remote Reference to a maximum. It normally is set at the maximum rated engine speed.
4. Lower Limit is the minimum speed reference setting in rpm. It is used to limit the Lower Speed command and Remote Reference. It normally is set at the minimum operating speed of the engine.

5. Accel Time is the time required for the control to ramp the engine speed from idle speed to rated speed. The time is set from 0 to 500 seconds. The ramp is started whenever the Idle/Rated switch is closed.
6. Decel Time is the time required for the control to ramp the engine speed from rated speed to idle speed. The time is set from 0 to 500 seconds. The ramp is started whenever the Idle/Rated switch is opened.



$t = \text{IDLE/RATED RAMP TIME (SECONDS)}$

$t_1 = \text{Accel Time}$ $t_2 = \text{Decel Time}$

041-023
93-3-25 RAM

Figure 5-2. Accel/Decel Example

IMPORTANT

Actual engine deceleration may be slower than set by the Decel Time set point. This occurs when the Decel Time set point is faster than system inertias will allow the engine to slow down in speed. This condition is indicated by the control actuator output going to the minimum fuel position. See Idle Droop below.

7. Raise Rate is the rate at which the speed reference is ramped when using the Raise command or when the Remote Speed Setting input is changed in the increase direction. The rate programmed is in rpm per minute. A step change in the remote input does not cause an immediate change in the reference, which is ramped to the new setting at the Raise Rate.
8. Lower Rate is the rate at which the speed reference is ramped when using the Lower Speed command or when the Remote Speed Setting input is changed in the decrease direction. The rate is set in rpm per minute. A step change in the remote input does not cause an immediate change in the reference, which is ramped to the new setting at the Lower Rate.
9. Droop is set as the percent rated speed will be decreased from no load to full load. Droop will be included in the engine control schedule only when the Isoch/Droop contact is open. The percentage of Droop entered is based on 75° of actuator travel. If less than full travel is used, the droop percentage must be increased proportionally.




Figure 5-3. Droop Curve

10. Idle Droop combined with the Idle Droop Breakpoint is used to limit speed undershoot when large decel rates are used from rated to idle.

Idle Droop is based on the actuator output when it drops below the Idle Breakpoint setting. Dependencies on linkage make the Idle Droop percentage relative, so large droop settings may be required to achieve the desired results.

11. Idle Droop Breakpoint is normally set equal to the actuator output obtained when the engine is unloaded and at low idle. When the output of the control drops below this setting or goes to minimum fuel during rapid engine deceleration, Idle Droop will raise the speed reference. This brings the engine back under control sooner and reduces speed undershoot. Speed undershoot may occur because the time required for the control to return to the new fuel setting is dependent on control dynamics and linkage adjustment.




Figure 5-4. Idle Droop

12. Fast Start to Rated feature provides a fast start-up to rated speed. When the Fast Start feature is enabled and the Rated contact is closed when the engine is started, the speed reference will be instantly set to Rated speed setpoint, allowing quick engine startup. Only in this special case it's allowed to have the triple start fuel limiter speed setpoints set higher than Idle speed setpoint for fast open loop starting of the engine. When Fast Start is enabled, but Idle is selected when the engine is started, the engine will start to Idle.
13. Speed Switch A ON sets the rpm that will turn on Speed Switch A.
14. Speed Switch A OFF sets the rpm that will turn off Speed Switch A.
15. Speed Switch B ON sets the rpm that will turn on Speed Switch B.
16. Speed Switch B OFF sets the rpm that will turn off Speed Switch B.
17. Speed Switch C ON sets the rpm that will turn on Speed Switch C.
18. Speed Switch C OFF sets the rpm that will turn off Speed Switch C.

The speed switch changes state at the selected speed position. Each switch allows 500 mA to sink to the negative of the power supply when closed.




Figure 5-5. Speed Switch Settings

19. 20 mA Remote Reference is the engine speed desired when 20 mA is applied to the Remote Speed Reference input. The desired speed is set in rpm. (***option**)
20. 4 mA Remote Reference is the engine speed desired when 4 mA is applied to the Remote Speed Reference input. The desired speed is set in rpm. (***option**)

Table 5-3. Menu 3—Speed Reference Settings*

Menu Item	Low Value	Default Value	High Value	Units
Rated Speed	0	1800	2100	rpm
Idle Speed	0	1200	2100	rpm
Raise Limit	0	1890	2100	rpm
Lower Limit	0	1200	2100	rpm
Accel Time	0	8	500	seconds
Decel Time	0	8	500	seconds
Raise Rate	0	2500	99999	rpm/minute
Lower Rate	0	2500	99999	rpm/minute
Droop	0	5	100	%
Idle Droop	0	0	100	%
Idle Droop BP	0	0	100	%
Speed Switch A On	0	600	2100	rpm
Speed Switch A Off	0	540	2100	rpm
Speed Switch B On	0	1200	2100	rpm
Speed Switch B Off	0	1140	2100	rpm
Speed Switch C On	0	2000	2100	rpm
Speed Switch C Off	0	1900	2100	rpm
Remote Speed	0	1710	2100	rpm (*option)
Remote Speed	0	1890	2100	rpm (*option)
Fast Start to Rated	FALSE	TRUE or FALSE	TRUE	NA (*option)

Menu 4—Limiter Settings

Menu 4: Limiter Settings

Start Fueling	<input type="text" value="1"/>	Max Fuel Limit	<input type="text" value="100.0"/>	%
Start Ramp Rate	<input type="text" value="1.000"/>	Transient Limit	<input type="text" value="0.0"/>	%/s
Start Fuel Limit	<input type="text" value="20.0"/>	Transient Time	<input type="text" value="0.0"/>	%
Start Speed	<input type="text" value="400.0"/>	Min Torque Limit	<input type="text" value="50.0"/>	rpm
Stop Speed	<input type="text" value="300.0"/>	Torque Limit BP	<input type="text" value="1500.0"/>	rpm
		Torque Limit at BP	<input type="text" value="70.0"/>	%
		Max Torque Limit	<input type="text" value="90.0"/>	%
		Fuel Rack BP (%)		Fuel Rack Limit (%)
	<input type="text" value="1"/>	<input type="text" value="10.0"/>	<input type="text" value="100.0"/>	
	<input type="text" value="2"/>	<input type="text" value="20.0"/>	<input type="text" value="100.0"/>	
	<input type="text" value="3"/>	<input type="text" value="30.0"/>	<input type="text" value="100.0"/>	
	<input type="text" value="4"/>	<input type="text" value="40.0"/>	<input type="text" value="100.0"/>	
	<input type="text" value="5"/>	<input type="text" value="50.0"/>	<input type="text" value="100.0"/>	

Fuel limiters limit the actuator output from the control. Descriptions of each menu item follow.

1. Maximum Fuel Limit sets the maximum percent actuator output when rated speed is selected. If the actuator linkage is correctly set so the actuator is providing the maximum position stop, 3° in advance of the butterfly valve maximum position, this item may be set at 100%. If the actuator must reach maximum before it reaches its maximum stop, the entry must be below 100%.

NOTICE

Damage to the butterfly valve and possible jamming of the valve in the wide open position is possible if linkage is not designed to reach maximum actuator position at least 3° in advance of maximum butterfly valve position.

The Maximum limit may be used to limit the horsepower developed in the engine.

2. Transient Limit is used when the maximum fuel limit is controlling the output horsepower of the engine. The transient limit allows overfueling of the engine by the amount tuned into the control. This allows the engine to accelerate to the rated load.
3. Transient Time is the amount of time that the Transient Limit is allowed to operate.
4. Minimum Torque Limit is the percent actuator output allowed when the engine speed is at or below the Lower Limit speed setting (Menu 3). The torque limiter provides a value between Minimum Torque Limit and Breakpoint Torque Limit when engine speed is between these two settings. This sets the torque limit slope below the Breakpoint position.
5. Torque Limit Breakpoint (BP) is the engine speed at which the slope of the torque limiter output changes. The Torque Limit Breakpoint must be set between the Raise and Lower Limits described under Menu 3.
6. Torque Limit at Breakpoint (BP) is the percent actuator output at the engine speed set by the Torque Limit Breakpoint described above.
7. Maximum Torque Limit is the maximum percent actuator output when the engine speed is at the Raise Limit speed setting. The torque limiter provides a value between the Breakpoint Torque Limit and Maximum Torque Limit when engine speed is between these two settings. This sets the slope above the torque limit breakpoint setting.
8. Start Fueling sets the number of enabled start fuel limits, 1, 2 or 3
9. Start Ramp Rate is a tunable ramp of the actuator output to ensure starting of cold engines. The control ramps the position of the actuator from the Start Fuel Limit open at a controlled rate until the engine starts or Max Fuel Limit is reached. After the engine has started, the fuel limits will be set by the Maximum Fuel Limit or the Torque Limit, whichever is less. In case of multiple start fuel limits (Start Fueling = 2 or 3), ramping only happens from the first start fuel limit point.
10. Start 1-2 Ramp Rate defines the rate at which the fuel limit is ramped to Start Fuel Limit 2, once Start Speed BP 1 has been reached.
11. Start 2-3 Ramp Rate defines the rate at which the fuel limit is ramped to Start Fuel Limit 3, once Start Speed BP 2 has been reached.
12. Start Fuel Limit 1 is a limit that is in place while the engine is starting. This limit helps reduce smoke on diesel engines and prevents overfueling during the start of gas engines. When Start Fueling = 1, this limit is removed when the engine reaches Start Speed. When Start Fueling = 2 or 3, the start fuel limiting sequence continues once Start Speed BP 1 has been reached.

13. Start Fuel Limit 2 is a limit that is in place while the engine is starting. This limit helps reduce smoke on diesel engines and prevents overfueling during the start of gas engines. When Start Fueling = 2, this limit is removed when the engine reaches Start Speed. When Start Fueling = 3, the start fuel limiting sequence continues once Start Speed BP 2 has been reached.
14. Start Fuel Limit 3 is a limit that is in place while the engine is starting. This limit helps reduce smoke on diesel engines and prevents overfueling during the start of gas engines. When Start Fueling = 3, this limit is removed when the engine reaches Start Speed.
15. Start Speed sets the speed in rpm that will remove the start-fuel limit from the control system. When Start Speed is obtained, the speed ramps to idle or rated speed, depending on the selection made. After start speed is attained, the control uses the Maximum Fuel and Torque limits.
16. Stop Speed sets the speed in rpm that will force the actuator to go to 0% when engine speed goes below this threshold. If speed recovers, speed control will be re-enabled, but the start fuel limiter sequence will be active again until run speed has been reached.

Figure 4-12 illustrates the breakpoint and these adjustments.




Figure 5-6. Complete Fuel Limit Map

17. Fuel Rack BP (%) versus Fuel Rack Limit (%) lookup table defines what Fuel Rack Limit (%) will be applied at each of the 5 fuel rack breakpoints (%) input values. The Fuel Rack Limiter is an absolute fuel limiter, downstream of all other limiters. (***option**)
18. Boost (bar) versus Boost Limit (%) lookup table defines what Boost Limit (%) will be applied at each of the 3 boost pressure breakpoints (bar) input values. (***option**)

Table 5-4. Menu 4—Limiter Settings*

Menu Item	Low Value	Default Value	High Value	Units
Start Fueling	1	1	3	
Start Ramp Rate	0	1	20	%/s
Start 1-2 Ramp Rate	0	100	2000	%/s
Start 2-3 Ramp Rate	0	100	2000	%/s
Start Fuel Limit 1	0	20	100	%
Start Fuel Limit 2	0	40	100	%
Start Fuel Limit 3	0	40	100	%
Start Speed BP 1	0	40	2100	rpm
Start Speed BP 2	0	40	2100	rpm
Start Speed	0	400	2100	rpm
Stop Speed	0	300 or 1	1200	rpm (*option)
Max Fuel Limit	0	100	100	%
Transient Limit	0	0	100	%
Transient Time	0	0	10	s
Min Torque Limit	0	40	100	%
Torque Limit BP	0	1500	2100	rpm
Torque Limit at BP	0	70	100	%
Max Torque Limit	0	90	100	%
Fuel Rack BP 1	0	10	100	% (*option)
Fuel Rack BP 2	0	20	100	% (*option)
Fuel Rack BP 3	0	30	100	% (*option)
Fuel Rack BP 4	0	40	100	% (*option)
Fuel Rack BP 5	0	50	100	% (*option)
Fuel Rack Limit 1	0	100	100	% (*option)
Fuel Rack Limit 2	0	100	100	% (*option)
Fuel Rack Limit 3	0	100	100	% (*option)
Fuel Rack Limit 4	0	100	100	% (*option)
Fuel Rack Limit 5	0	100	100	% (*option)
Boost 1	0	1	100	bar (*option)
Boost 2	0	2	100	bar (*option)
Boost 3	0	5	100	bar (*option)
Boost Limit 1	0	100	100	% (*option)
Boost Limit 2	0	100	100	% (*option)
Boost Limit 3	0	100	100	% (*option)


Menu 5—Monitor Menu

Menu 5: Monitor Menu			
		Inputs / Status	Inputs / Status
Speed	<input type="text" value="0.0"/> rpm	<input checked="" type="checkbox"/> Run / Stop Switch	<input checked="" type="checkbox"/> Isoch / Droop Switch
Speed Reference Ramp	<input type="text" value="400.0"/> rpm	<input checked="" type="checkbox"/> Rated / Idle Switch	<input checked="" type="checkbox"/> Speed Switch A
Speed Reference Final	<input type="text" value="400.0"/> rpm	<input checked="" type="checkbox"/> Raise Switch	<input checked="" type="checkbox"/> Speed Switch B
Speed Control Output	<input type="text" value="0.0"/> %	<input checked="" type="checkbox"/> Lower Switch	<input checked="" type="checkbox"/> Speed Switch C
Actuator Position (mapped)	<input type="text" value="5.8"/> %	<input checked="" type="checkbox"/> Alternate Dynamics Switch	<input checked="" type="checkbox"/> Fault Lamp
Aux Input	<input type="text" value="-0.001"/> V	<input checked="" type="checkbox"/> Remote Reference Switch	
Fuel Rack Limiter	<input type="text" value="-1.208"/> mA		
Fuel Rack Limiter	<input type="text" value="100.0"/> %		

Values displayed are continuously updated. Descriptions of each menu item follow:


1. Speed displays the current engine speed in rpm.
2. Speed Reference Ramp displays the current speed reference ramp value in rpm. Note that this may not be the current speed of the engine due to the effect of idle droop, fuel limiters, auxiliary input, or droop.
3. Speed Reference Final displays the final speed reference value in rpm. This is the speed reference ramp value after applying speed biases droop, idle droop & the auxiliary input.
3. Speed Control Output displays the current speed control output percentage.
4. Actuator Position (mapped) displays the actuator position demand output percentage after applying the actuator mapping curve.
5. Aux Input displays the voltage on the Aux Input.
6. Remote Speed setting displays the analog input in mA or V, and the respective remote speed setting setpoint in rpm. (***option**)
7. Fuel Rack Limiter displays the analog input in mA or V, and the respective Fuel Rack Limiter input value in %. (***option**)
8. Boost Pressure displays the analog input in mA or V, and the respective Boost Pressure input value in bar. (***option**)
9. Run/Stop Switch Status displays the status of the discrete input at terminal 23. Closed indicates 24 Vdc is applied to the input selecting the run position. Open selects minimum fuel or the stop position.
10. Idle/Rated Switch Status displays the status of discrete input at terminal 17. Closed indicates 24 Vdc is applied to the input selecting rated speed and the maximum fuel limit is selected. Open indicates idle speed and the idle fuel limit.
11. Raise Switch Status displays the status of discrete input at terminal 19. Closed indicates 24 Vdc is applied to the input selecting raise speed.
12. Lower Switch Status displays the status of discrete input at terminal 18. Closed indicates 24 Vdc is applied to the input selecting lower speed.
13. Alternate Dynamics Switch Status displays the status of discrete input at terminal 20. Closed indicates 24 Vdc is applied to the input selecting the Alternate Dynamics.
14. Remote Reference Switch Status displays the status of discrete input at terminal 21. Closed enables the remote speed setting at terminals 14 and 15 and disables the Raise and Lower switches.
15. Isoch / Droop Switch displays the status of the contacts at terminal 16. Open is droop, closed is in isochronous speed control mode.
16. Speed Switch A, terminal 3, indicates the on/off position of the switch.
17. Speed Switch B, terminal 4, indicates the on/off position of the switch.
18. Speed Switch C, terminal 5, indicates the on/off position of the switch.
19. Fault Lamp indicates the switch position at terminal 6. This switch is on when a fault has been detected.

Menu 6a—Configuration Set Points



In order to make configuration changes, one needs to be logged on at an appropriate security level, and the engine shall be stopped (Run/Stop switch open).

Pressing the **ENTER CONFIGURATION** button will enter Configuration mode and allow configuration settings to be changed for 15 minutes, after which Configuration mode will be exited automatically.



1. Failsafe Function.

! WARNING

The Failsafe function causes the ProAct control to issue a minimum fuel signal should the MPU signal fail. Should the function be disabled (to permit a fuel position while cranking or for test procedures), it must be enabled again to prevent overspeed should the signal fail while the engine is operating. Engine overspeed can damage equipment and cause personal injury or death.

! WARNING

The Failsafe function must be enabled during normal engine operation to prevent possible overspeed should the MPU signal be lost for any reason. As soon as the control senses engine speed, the failsafe becomes enabled. The function can be overridden to allow some slow cranking engines to start, and to test parts of the governor system without running the engine. Failure to enable the Failsafe function could allow overspeed with resulting damage to equipment and possible personal injury or death.

2. Dynamics Map Linear or Nonlinear. This setting shall be kept at linear, as nonlinear is not implemented.
3. Number of Gear Teeth is the number of teeth or holes in the gear or flywheel that drives the speed-sensing device. If the gear is running at camshaft speed (one-half engine speed) then you must enter one-half the number of teeth on the gear.

The control requires the number of teeth seen by the MPU per engine revolution.

IMPORTANT

Best control performance will be obtained when sensing speed from a gear rotating at full engine speed. Slower-speed gears (such as the camshaft) provide a lower sampling rate which reduces control response time.

! WARNING

The number of gear teeth is used by the control to convert pulses from the speed-sensing device to engine rpm. To prevent possible serious injury from an overspeeding engine, make sure the control is properly programmed to convert the gear-tooth count into engine rpm. Improper conversion could cause engine overspeed.

4. Speed Filter Type determines the type of MPU algorithm that will be run.
 Engine cycle = 2 revolutions of crankshaft on a 4-stroke engine
 - The speed is sensed once every 1/16th of an engine cycle and averaged with the previous 15 samples. There are 16 speed samples in the average.
 - This function has not been implemented. Defaulted to Speed Filter Type 4.
 - The speed period is sampled once every 1/SAMPLES of an engine cycle. The last SAMPLES samples are averaged to determine the speed. For example, if SAMPLES = 10, then the speed period is sampled every 1/10th of an engine cycle. The speed is the average of the last 10 samples; therefore the speed is the average of the last 10 samples taken during the last engine cycle.
 - This function is specifically designed to give readings at low speeds without the delay associated with other types of speed sensing blocks. The speed period is sampled on every gear tooth. The speed is determined from the average of the last 2 gear tooth samples.

**WARNING**

Speed Filter Type 4 should only be used in applications where GEAR TEETH FREQUENCIES are below 1000 Hz. Gear teeth frequencies higher than 1000 Hz may result in the control resetting, causing the engine to shut down.

- Adaptive Rotational Filter. The algorithm breaks up the engine cycle according to the following equation:

Teeth or pulses before a new sample = $(\text{NUM_TEETH} * \text{REVS_CYCL}) / \text{SAMPLES}$;
It is capable of changing the number of pulses for each sample period such that it calculates speed over the same section of the speed sensing gear each engine revolution. The block will then add a separate bias to the speed calculation for each section based on the average speed over an entire engine revolution.

**WARNING**

Speed Filter Type 5 should only be used in slower speed engine and hydro turbine applications.

5. #Speed Samples. Typically this should be set to the number of cylinder the engine has for best torsional speed filtering effect. Changing the value from the default will impact the dynamics of the speed control, requiring retuning of the speed control.

IMPORTANT

To maintain compatibility with the legacy ProAct driver settings, it is important to NOT change the speed sensing defaults values of: Type=3, Samples=7 or Type=3, Samples=4 (*option)


6. Analog Input Function. Allows to change the function of the analog input from 1: Remote Speed Setpoint, 2: Fuel Rack Limiter or 3: Boost Pressure
7. Analog Input Analog Type. Allows to change the analog input from 1: 4-20 mA to 2: 0-5 V input signal type
8. Analog input Scaling. Define the 4 and 20 mA (or 0 and 5 V) output values for the input signal type.
9. Analog Input Gain. The Gain is used to shift the high-end calibration of the input. The output, in engineering units (mA or V), is multiplied by the gain.
10. Analog Input Offset. The Offset is used to shift the low-end calibration of the input. The offset, in engineering units (mA or V), is added to the output.
11. Range Limits High. Defines the analog input high threshold in mA or V for the corresponding alarm
12. Range Limits Low. Defines the analog input low threshold in mA or V for the corresponding alarm
13. Range Limits Fault Delay. Defines time the analog input value needs to be out of range before the corresponding alarm will be triggered
14. Range Limits Out of range alarm High ?. When checked, will enable the high alarm
15. Range Limits Out of range alarm Low ?. When checked, will enable the low alarm
16. AUX input Gain. The Gain is used to shift the high-end calibration of the input. The AUX output, in engineering units (V), is multiplied by the gain.
17. AUX input Offset. The Offset is used to shift the low-end calibration of the input. The offset, in engineering units (V), is added to the AUX output.

18. AUX Gain. The AUX input speed bias [rpm] is multiplied with this gain. Default value of 1.0 will result in a 3% rated speed bias per volt.

Table 5-5. Menu 6a - Settings*

Menu Item	Low Value	Default Value	High Value	Units
Failsafe Function	Disabled	Enabled	Enabled	NA
Dynamics Map	Nonlinear	Linear	Linear	NA
Number of Gear Teeth	4	60	720	NA
Speed Filter Type	1	3	5	NA
#Speed Samples	2	14, 7 or 4	40	NA (*option)
Function	1	2 or 1	3	NA (*option)
Remote Speed Setp (mA)	0	4	20	mA (*option)
Remote Speed Setp (mA)	0	20	20	mA (*option)
Remote Speed Setp (V) L	0	0.5	5.5	V (*option)
Remote Speed Setp (V)	0	4.5	5.5	V (*option)
Remote Speed Setp	0	1710	2100	% (*option)
Remote Speed Setp	0	1890	2100	% (*option)
Fuel Rack Limiter (mA) L	0	4	20	mA (*option)
Fuel Rack Limiter (mA) H	0	20	20	mA (*option)
Fuel Rack Limiter (V) L	0	0.5	5.5	V (*option)
Fuel Rack Limiter (V) H	0	4.5	5.5	V (*option)
Fuel Rack Limiter (%) L	0	0	100	% (*option)
Fuel Rack Limiter (%) H	0	100	100	% (*option)
Boost Pressure (mA) L	0	4	20	mA (*option)
Boost Pressure (mA) H	0	20	20	mA (*option)
Boost Pressure (V) L	0	0.5	5.5	V (*option)
Boost Pressure (V) H	0	4.5	5.5	V (*option)
Boost Pressure (bar) L	0	0	10	bar (*option)
Boost Pressure (bar) H	0	100	10	bar (*option)
Analog Input Gain	0.1	1	10	NA
Analog Input Offset	-0.25	0	0.25	mA / V
Range limit High (mA)	0	20.5	25	mA (*option)
Range limit Low (mA)	0	2	25	mA (*option)
Range limit High (V)	0	4.8	5.5	V (*option)
Range limit Low (V)	0	0.2	5.5	V (*option)
Out of range alarm High	FALSE	TRUE	TRUE	NA
Out of range alarm Low	FALSE	TRUE	TRUE	NA
AUX Input Gain	0.1	1	10	NA
AUX Input Offset	-0.25	0	0.25	V
AUX Gain	0.01	1	100	NA

Menu 6b: Configuration / Actuator Test



This page provides calibration and test modes to setup the ProAct actuator stroke vs position feedback.

For a ProAct actuator intended for speed control applications, its position sensor will output a high voltage at 0° position, and a low voltage at 75° position, measurable at terminals 8 and 9.

A typical range could be 3.1 ~ 1.9 V, resulting in an internal rescaled range from 0.8 to 4.4 V

The internal rescaled position feedback voltage will be used for the digital position control loop of the ProAct actuator, and needs to be calibrated.

Also, Friction and Inertia need to be properly set for the fuel rack linkage connected to the ProAct actuator output shaft.



WARNING

Actuator Calibration and Test modes can only be performed when the engine is stopped and the Run contact is open.

Manual Calibration



WARNING

Actuator calibration will change the system performance.

Do not use unless there is a valid reason for changing the actuator Min & Max actuator position calibration.

In Manual Calibration one needs to manually move the actuator to minimum (typically 0 deg) and maximum position (typically 75 deg) and adjust the Min and Max voltage by hand to match the corresponding Actual internal position feedback voltage.



IMPORTANT

The Min & Max actuator calibration voltages cannot be uploaded from a settings file but need to be adjusted and saved on the actual driver itself by either manual or automatic calibration and saving the settings to non-volatile memory.

Automatic Calibration



WARNING

Actuator Calibration will change the system performance. Do not use unless there is a valid reason for changing the actuator Min & Max actuator position calibration.

In Automatic Calibration the control will drive the actuator with a fixed negative current to minimum position (typically 0 deg), and then sample Actual internal position feedback voltage. Next it will drive the actuator with a fixed positive current to maximum position (typically 75 deg), and then sample Actual internal position feedback voltage again.

At the end on the Automatic Calibration, the sampled voltages can be committed to the Min & Max voltages by pressing the “Use Auto calibrated Min/Max value” pushbutton.

Automatic Calibration
Exit

Use Auto calibrated Min/Max values

Calibrated Actuator Control Min/Max values

Min V

Max V

Current Actuator Control Min/Max values

Min V

Max V

■ Stop
 ■ Freeze View
 ■ Zoom In
 ■ Zoom Out
 ■ Zoom Full

■ Properties...
 ■ Export...

20 seconds 3:18:38 PM

Name	Value	Units	Minimum	Maximum
Actuator Position	-0.049204...	°	-10	90
Actuator Position	0.114331...	%	-10	110
Current	-0.952749...	A	-15	15
Actual (internal) Voltage	0.9242979	V	0	5

IMPORTANT


Calibration assumes a disconnected fuel rack, so the actuator can reach the full stroke of 0 and 75 degrees. Calculated position in degrees will be incorrect when Min/Max don't match 0~75 degrees actuator travel.

Inertia Test

Inertia Test will perform an automated actuator position step profile from 0% to 30% to 60% to 30% to 0% to help set the inertia value to a correct value, by observing the actuator response, aided by the embedded trend.

The inertia setting calibrates the position controller to the load inertia. A setting of zero represents the actuator shaft with no load attached. Higher load inertia requires a higher inertia setting. If the inertia setting is too low, there may be a slow oscillation when the actuator should be steady, or the step response may show excessive overshoot and ringing. If the inertia setting is too high, a high frequency oscillation or limit cycle may be seen. If a range of values is seen to provide adequate response, the lowest value that does not produce overshoot should be chosen.

See Inertia Calibration for more details and a tuning procedure.



Friction Test

Friction Test will set the actuator control to current mode. The friction setting represents the actuator current required to overcome static load friction.

See Friction Calibration for more details and a tuning procedure.

Friction Test

Inertia Test

Finish

Adjust Current to determine actuator friction value

Current A

Friction A

The friction setting represents the actuator current required to overcome static load friction. Where no spring return is present, the Input Current value should be increased until the actuator just begins to move. That value of Input Current should then be entered as the Friction Setting. Ideally, this should be done in the middle of the travel range, and not at either end.

Where a return spring is present, the input current should be gradually increased until the actuator begins to move against the spring, then gradually decreased until it moves in the opposite direction. The Friction Setting should be one-half of the difference between these two values.

For example, if it takes 0.7 A to begin moving against the spring, and at 0.5 A the actuator moves with the spring in the opposite direction, set the Friction Setting at $(0.7 - 0.5) / 2 = 0.1$ A.

If the friction setting is too low, the actuator may not respond well to small changes in the position demand. If the friction setting is too high, a high frequency oscillation or limit cycle will be seen.

Stop Freeze View Zoom In Zoom Out Zoom Full Properties... Export...

3:36:38 PM

Name	Value	Units	Minimum	Maximum
Actuator Position	14.92742	°	-10	90
Actuator Position	19.5248375	%	-10	110
Current	0.13874878	A	-15	15
Actual (internal) Voltage	1.58852267	V	0	5

Verify Position

This test mode allows the actuator to be positioned by changing the Position demand value and observe correct actuator response and feedback signals.

Verify Position

Finish

Adjust Position demand value

To verify actuator calibration

Position (mapped) %

Position demand value %

Stop
Freeze View
Zoom In
Zoom Out
Zoom Full
Properties...
Export...

3:41:46 PM

Name	Value	Units	Minimum	Maximum
■ Actuator Position	37.9048	°	-10	90
■ Actuator Position	50.0015068	%	-10	110
■ Current	0.545751	A	-15	15
■ Actual (internal) Voltage	2.62881565	V	0	5


Actuator Position Mapping

Actuator Position Mapping allows to setup a non-linear position demand curve, with 2 adjustable points, BP 1 (X,Y) and BP 2 (X,Y).



WARNING

Modifying the Actuator Position Mapping will change the system performance. Do not use unless there is a valid reason for changing the actuator position mapping default settings.



In cases where the fuel rack cannot be disconnected to perform a complete 75 degree automatic calibration stroke, there may be need to perform the automatic calibration stroke on a limited actuator travel. Position demand 0~100% will then be based on a smaller actuator travel, resulting in a different position response compared to the legacy ProAct Digital Speed Control which has no provisions for end-user actuator position calibration.

Table 5-5. Menu 6b Settings

Menu Item	Low Value	Default Value	High Value	Units
Min	0	0.649 **	5	V ***
Max	0	4.624 **	5	V ***
Friction	0	0.1	4	A
Inertia	0	0	20	NA
BP 1 - X	0	10	49	%
BP 1 - Y	0	10	49	%
BP 2 - X	51	90	100	%
BP 2 - Y	51	90	100	%

** Certain ProAct Digital Speed Control versions may have different default values


*** Cannot be uploaded to ProAct Digital Speed Control from a settings file

NOTICE

To prevent possible damage to the engine resulting from improper control settings, make sure you **SAVE** the set points before removing power from the control. Failure to **SAVE** the set points before removing power from the control causes them to revert to the previously saved settings.

Menu 0: Diagnostics

Logged Errors provides a means of recording errors that the control detects. The error log will be saved, even if power to the control is lost. The driver has no real time clock, but events are “time”-stamped by the current Run Hours & Start Counter when they occur. The cumulated number of times an event occurred will be indicated by the “Occurrences” field.



Inactive errors can be cleared from the log by the “Reset All” pushbutton.

The following event types are supported:

- **ALM** Alarm event only, engine can be started
- **CFG** Configuration Error, engine starting & running will be inhibited
- **GOV** Governor Fault, discrete output will be activated
- **SD** Shutdown event, engine will be stopped.

The RUN contact needs to open and to close to clear the event and be able to start again.

Table 5-6. Diagnostic Event Descriptions

Event #	Description	Event Type
2	Setpoint Start > Idle	(CFG)
10	Setpoint Start > Limit Setpoint Lower	(CFG)
11	Remote Reference range fault Low	(ALM)
12	Remote Reference range fault High	(ALM)
13	Rack Fuel Limiter range fault Low	(ALM)
14	Rack Fuel Limiter range fault High	(ALM)
15	Boost range fault Low	(ALM)
16	Boost range fault High	(ALM)
19	Actuator Position Feedback Error (Stopped)	(ALM)
21	Actuator Position Feedback Error (Running)	(GOV SD)
22	Speed Sensor fault. loss of speed	(GOV SD)
26	Emergency Shutdown from HMI	(GOV SD)
27	Position Sensor 5V Supply Low	(GOV SD)
28	Position Sensor High	(GOV SD)
29	Position Sensor Low	(GOV SD)
30	Supply Voltage High	(GOV SD)
31	Supply Voltage Low	(GOV SD)
32	EEPROM fault (primary)	(GOV SD)
33	EEPROM fault (secondary)	(GOV SD)
34	Motor Common Mode Current Fault	(GOV SD)
35	Motor Differential Mode Current Fault	(GOV SD)

Events 11~16 indicate the analog input signal mA or V are outside the normal range, exceeding their respective low or high threshold value. See Menu 6a—Configuration Set Points

Event 30 will assert when the power supply voltage > 32 V

Event 31 will assert when the power supply voltage < 18 V (model II actuators) or <10 V (model I)

In case of Events 32, 33, the driver needs to be returned to Woodward for repairs.

Event 34, 35 indicate either a driver & actuator wiring fault, a driver output fault or an actuator fault.

Hour and Event Counter

Non Volatile Memory

● Alarm

● Initialized

Total number of writes 54

Non Volatile Memory

Total Number of Writes: Counts the number of times the non-volatile memory has been written to.

Power-on hours

Current value 163.2 hrs

Running hours

Current value 1.4 hrs

Start counter

Current value 9

Power-on Hours: The total number of hours the control has been powered.

Running Hours: The total number of hours the engine speed has been greater than “Starting Speed” and not less than “Stop Speed”.

Start Counter: The total number of times the engine has been started and reached “Idle Speed”

Enter Pre-Set mode

Apply

Cancel

Enter Pre-Set Mode: Button when left clicked and then “Apply” left clicked will allow the user to pre-set the values above.

System Page

The System page shows values related to the software and hardware.

Remove 10% max tune limit

Enable: When left clicked, this button will remove (override) the 10% tune limit for 1 hour. After the hour, the maximum tuning limit will be enforced again.

Disable: When left clicked, this button will re-enforce the 10% maximum tuning limit by disabling the override.

XCP & Security

This page will only be available when logged in at the OEM security level. Menu item details are listed below.

Enable XCP connection(s): Select the enabled XCP connected instances, XCP1, XCP2 or both. For setup and monitoring using Toolkit, XCP1 instance will suffice.

CAN baud rate: Select the appropriate CAN communication baud rate, 125 kbps to 1 Mbps

XCP Security Passwords: When logged in at the OEM security level, the security level passwords may be changed to different values.



WARNING

When the security level passwords have been changed, saved and forgotten, the control can only be restored to factory default settings by returning it to Woodward for repair.

Table 5-7. XCP & Security Menu Items, Values, and Units

Menu Item	Low Value	Default Value	High Value	Units
Enable XCP	XCP1	XCP1	XCP1 & XCP2	NA
CAN baud rate	125	500	1000	kbps
Level 1 – Operator	0	0	99999999	NA
Level 3 – Service	0	1111	99999999	NA
Level 5 – Service	0	1112	99999999	NA
Level 7 – OEM	0	1212	99999999	NA

NOTICE

Certain ProAct Digital Speed Control versions may have different default XCP security passwords. Contact the OEM for your connection details.

Chapter 6. System Troubleshooting

Table 6-1. System Troubleshooting Chart

Problem	Cause	Remedy
Prime mover will not start. Actuator not moving to start fuel position.	Supply voltage polarity reversed, or no supply voltage.	Check for supply voltage from terminals 24 (+) to 25 (-). Reverse leads if polarity is incorrect.
	Actuator not responding to input signal from control.	If there is a voltage output at control terminals 1 (+) and 2 (-), but the actuator does not move, check the wiring to the actuator for opens or shorts. Check the polarity of the actuator and feedback.
If the actuator moves to start position, a problem with the prime mover fuel supply is indicated.		Check actuator and linkage for proper installation and operation. Problems may be direction of rotation, linkage, worn components, or improper adjustment.
	Start fuel limit set too low.	Increase start fuel limit until prime mover starts. Increase Start Ramp.
	Speed setting too low on initial start.	Speed setting may be lower than cranking speed. Control should be set for rated speed. Increase Rated Speed setting.
		NOTICE
	Idle Speed setting may be set too low.	Adjust idle speed.
	Run/Stop contact open.	Check terminal 23. Run/Stop contact must be closed for normal operation. Check monitor menu for switch position.

Table 6-1. System Troubleshooting Chart (cont'd.)

Problem	Cause	Remedy
Prime mover will not start. Actuator not moving to start fuel position. (cont.)	Speed sensor signal not clearing failed speed signal circuit.	<p data-bbox="828 231 1421 294">Check wiring for proper connection. Check shields for proper installation.</p> <p data-bbox="828 315 1421 451">Speed sensor not spaced properly. Check for at least 1.0 Vac at terminals 10 and 11 during cranking. If less than 1.0 Vac, magnetic pickup may be spaced too far from gear. Make sure there are no metal chips on end of pickup.</p> <p data-bbox="828 472 1421 556">Check the number of teeth seen by the MPU per engine revolution against the number entered in step 2 of Menu 6.</p> <p data-bbox="828 577 1421 703">If no voltage is present, magnetic pickup may be open-circuited or shorted. Make resistance check with the leads disconnected from control. Should be 100 to 300 Ω.</p> <p data-bbox="828 724 1421 756">Check Error Menu 0 for faults.</p> <div data-bbox="852 777 1104 840" style="border: 1px solid black; padding: 2px; text-align: center;">  WARNING </div> <p data-bbox="828 840 1421 976">The Failed Speed Signal must be enabled for routine operation of the engine to ensure shutdown and prevent possible life threatening overspeed should the MPU signal be lost at some future time.</p> <p data-bbox="828 997 1421 1029">Check Monitor Menu for Speed When Cranking.</p> <div data-bbox="852 1060 1104 1123" style="border: 1px solid black; padding: 2px; text-align: center;">  WARNING </div> <p data-bbox="828 1123 1421 1260">Be prepared to make an emergency shutdown when starting the engine, turbine, or other type of prime mover, to protect against runaway or overspeed with possible personal injury, loss of life, or property damage.</p> <hr/> <p data-bbox="454 1260 828 1287">Faulty ProAct control.</p> <p data-bbox="828 1260 1421 1287">Replace control.</p>

Table 6-1. System Troubleshooting Chart (cont'd.)

Problem	Cause	Remedy
Prime mover overspeeds only on starts.	Control adjustment.	Control may be adjusted for sluggish operation causing overspeed on start. Slowly adjust GAIN for fastest stable response. Stability may be adjusted too low. Increase Stability setting. Start Fuel Limit may be too high. Start Ramp may be too high. Start speed may be too low. Wrong set of dynamics may have been selected.
	Linkage/Coupling.	On diesel installations verify that fuel rack is not binding and linkage is properly adjusted. It may be necessary to determine if the fuel rack is quickly following the actuator. On carburetor installations check that the butterfly is not binding. Check linkage or coupling adjustment.
	Overspeed Device.	Verify proper operation of overspeed protection devices to determine if a shutdown is occurring without an overspeed condition.
	ProAct control.	If the control does not cut back the actuator output (Menu 5), the ProAct control may be faulty. If the signal is cut back, look for a problem in the linkage or actuator.
Prime mover overspeeds after operating at rated speed for some time.	Prime mover.	Check for proper operation of prime mover fuel system. If actuator moves toward minimum fuel during overspeed, problem may not be connected with the governor.
Speed not regulated (hunting).	Incorrect dynamics programmed in control or incorrect dynamics program selected.	Improve dynamics settings or select correct dynamics program.
Low speed is not regulated at idle speed.	Actuator and linkage.	The Idle Speed setting may be below the minimum-fuel position of the actuator or prime mover fuel stop. In this case, the output voltage to the actuator will be zero. The engine will be maintained at the minimum-fuel position by the actuator or the prime mover minimum-fuel stop. These conditions indicate that the prime mover minimum-fuel position should be decreased by linkage adjustment (diesel engine) or low-idle set screw (gas engine), or the Idle Speed setting should be raised. If this action does not correct the problem, the control may be faulty.
Prime mover does not decelerate when Rated contact is open.	Faulty Rated contact.	Check Idle/Rated contact. Remove wire from terminal 17. Prime mover should decelerate.
	ProAct control ramp circuitry.	A faulty Rated contact may remain in the accelerate position with the contact open. If the Rated contact is operative, loss of idle control may be due to a faulty circuit.

Table 6-1. System Troubleshooting Chart (cont'd.)

Problem	Cause	Remedy
Prime mover will not stabilize at rated no-load speed. The instability may occur at no load or it may vary with load. Control may be erratic.	ProAct control.	Adjust GAIN, Stability, and ACTUATOR COMPENSATION in Menu 1 or 2. Check Gain Breakpoint for the lower speeds.
	Necessary external wires not properly shielded. (Electrical noise, caused by wiring carrying an ac voltage, stray magnetic fields from transformers, etc., can be picked up by improperly shielded wire. Noise will cause instability if picked up by magnetic pickup, position feedback, auxiliary input, or remote reference lines.)	The following tests will isolate noise and interference.
		Verify that the switchgear frame, governor chassis, and prime mover have a common ground connection. Temporarily remove the battery-charger cables from the control battery system.
		If the prime-mover operation is significantly improved by these modifications, replace the wires one at a time to locate the source of the trouble.
	External wiring may require additional shielding or rerouting from high-current lines or components.	
	If the problem cannot be solved by these checks, it will be necessary to remove the control from the switchgear. Temporarily mount the control next to the prime mover and connect only a battery, magnetic pickup, and actuator to the control (use a separate battery placed next to the prime mover). After starting the prime mover, if necessary, apply load to check stability.	
	If stability occurs when the control is mounted next to the prime mover, return the control to the switchgear. Run new magnetic pickup, actuator feedback, and battery power lines. Shield all wires to the control. Route all wires through conduit or an outer shield. Tie the outer shield to system ground at the end opposite to the control.	
Prime mover may not be receiving fuel as called for by the actuator voltage.		Check actuator linkage to fuel-controlling mechanism for any lost motion, binding, or excessive loading. Verify a steady fuel pressure of proper value.
Prime mover not operating properly.		Prime mover may be causing speed variations. Control engine manually to determine if instability is in prime mover or governor control. Verify proper adjustment of fuel control linkage.
Input voltage low.		Check supply voltage. It should be at least 18 Vdc, not more than 32 Vdc.
Prime mover will not accept full load.	Prime mover.	If droop occurs near the full-load point only, it is possible the prime mover is not producing the power called for by the fuel control, or is being overloaded. Either is indicated if the fuel control is at maximum position.
	ProAct control.	Check Max Fuel Limit setting. Increase if required. Check Torque Limiter settings. Increase if required. Check droop setting. Set to 0 if required. Check Aux Input terminals to see if the auxiliaries are out of range. Maximum voltage is 2.5 Vdc. Check linkage from actuator to fuel rack.

Chapter 7.

Product Support and Service Options

Product Support Options

If you are experiencing problems with the installation, or unsatisfactory performance of a Woodward product, the following options are available:

1. Consult the troubleshooting guide in the manual.
2. Contact the **OE Manufacturer or Packager** of your system.
3. Contact the **Woodward Business Partner** serving your area.
4. Contact Woodward technical assistance via email (EngineHelpDesk@Woodward.com) with detailed information on the product, application, and symptoms. Your email will be forwarded to an appropriate expert on the product and application to respond by telephone or return email.
5. If the issue cannot be resolved, you can select a further course of action to pursue based on the available services listed in this chapter.

OEM or Packager Support: Many Woodward controls and control devices are installed into the equipment system and programmed by an Original Equipment Manufacturer (OEM) or Equipment Packager at their factory. In some cases, the programming is password-protected by the OEM or packager, and they are the best source for product service and support. Warranty service for Woodward products shipped with an equipment system should also be handled through the OEM or Packager. Please review your equipment system documentation for details.

Woodward Business Partner Support: Woodward works with and supports a global network of independent business partners whose mission is to serve the users of Woodward controls, as described here:

- A **Full-Service Distributor** has the primary responsibility for sales, service, system integration solutions, technical desk support, and aftermarket marketing of standard Woodward products within a specific geographic area and market segment.
- An **Authorized Independent Service Facility (AISF)** provides authorized service that includes repairs, repair parts, and warranty service on Woodward's behalf. Service (not new unit sales) is an AISF's primary mission.
- A **Recognized Engine Retrofitter (RER)** is an independent company that does retrofits and upgrades on reciprocating gas engines and dual-fuel conversions, and can provide the full line of Woodward systems and components for the retrofits and overhauls, emission compliance upgrades, long term service contracts, emergency repairs, etc.

A current list of Woodward Business Partners is available at www.woodward.com/directory.

Product Service Options

Depending on the type of product, the following options for servicing Woodward products may be available through your local Full-Service Distributor or the OEM or Packager of the equipment system.

- Replacement/Exchange (24-hour service)
- Flat Rate Repair
- Flat Rate Remanufacture

Replacement/Exchange: Replacement/Exchange is a premium program designed for the user who is in need of immediate service. It allows you to request and receive a like-new replacement unit in minimum time (usually within 24 hours of the request), providing a suitable unit is available at the time of the request, thereby minimizing costly downtime.

This option allows you to call your Full-Service Distributor in the event of an unexpected outage, or in advance of a scheduled outage, to request a replacement control unit. If the unit is available at the time of the call, it can usually be shipped out within 24 hours. You replace your field control unit with the like-new replacement and return the field unit to the Full-Service Distributor.

Flat Rate Repair: Flat Rate Repair is available for many of the standard mechanical products and some of the electronic products in the field. This program offers you repair service for your products with the advantage of knowing in advance what the cost will be.

Flat Rate Remanufacture: Flat Rate Remanufacture is very similar to the Flat Rate Repair option, with the exception that the unit will be returned to you in “like-new” condition. This option is applicable to mechanical products only.

Returning Equipment for Repair

If a control (or any part of an electronic control) is to be returned for repair, please contact your Full-Service Distributor in advance to obtain Return Authorization and shipping instructions.

When shipping the item(s), attach a tag with the following information:

- return number;
- name and location where the control is installed;
- name and phone number of contact person;
- complete Woodward part number(s) and serial number(s);
- description of the problem;
- instructions describing the desired type of repair.

Packing a Control

Use the following materials when returning a complete control:

- protective caps on any connectors;
- antistatic protective bags on all electronic modules;
- packing materials that will not damage the surface of the unit;
- at least 100 mm (4 inches) of tightly packed, industry-approved packing material;
- a packing carton with double walls;
- a strong tape around the outside of the carton for increased strength.

NOTICE

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Replacement Parts

When ordering replacement parts for controls, include the following information:

- the part number(s) (XXXX-XXXX) that is on the enclosure nameplate;
- the unit serial number, which is also on the nameplate.

Engineering Services

Woodward's Full-Service Distributors offer various Engineering Services for our products. For these services, you can contact the Distributor by telephone or by email.

- Technical Support
- Product Training
- Field Service

Technical Support is available from your equipment system supplier, your local Full-Service Distributor, or from many of Woodward's worldwide locations, depending upon the product and application. This service can assist you with technical questions or problem solving during the normal business hours of the Woodward location you contact.

Product Training is available as standard classes at many Distributor locations. Customized classes are also available, which can be adjusted to your needs and held at one of our Distributor locations or at your site. This training, conducted by experienced personnel, will assure that you will be able to maintain system reliability and availability.

Field Service engineering on-site support is available, depending on the product and location, from one of our Full-Service Distributors. The field engineers are experienced both on Woodward products as well as on much of the non-Woodward equipment with which our products interface.

For information on these services, please contact one of the Full-Service Distributors listed at www.woodward.com/directory.

Contacting Woodward's Support Organization

For the name of your nearest Woodward Full-Service Distributor or service facility, please consult our worldwide directory at www.woodward.com/directory, which also contains the most current product support and contact information.

You can also contact the Woodward Customer Service Department at one of the following Woodward facilities to obtain the address and phone number of the nearest facility at which you can obtain information and service.

**Products Used in
Electrical Power Systems**

<u>Facility</u>	<u>Phone Number</u>
Brazil	+55 (19) 3708 4800
China	+86 (512) 6762 6727
Germany:	
Kempen	+49 (0) 21 52 14 51
Stuttgart	+49 (711) 78954-510
India	+91 (124) 4399500
Japan	+81 (43) 213-2191
Korea	+82 (51) 636-7080
Poland	+48 12 295 13 00
United States	+1 (970) 482-5811

**Products Used in
Engine Systems**

<u>Facility</u>	<u>Phone Number</u>
Brazil	+55 (19) 3708 4800
China	+86 (512) 6762 6727
Germany	+49 (711) 78954-510
India	+91 (124) 4399500
Japan	+81 (43) 213-2191
Korea	+82 (51) 636-7080
The Netherlands	+31 (23) 5661111
United States	+1 (970) 482-5811

**Products Used in Industrial
Turbomachinery Systems**

<u>Facility</u>	<u>Phone Number</u>
Brazil	+55 (19) 3708 4800
China	+86 (512) 6762 6727
India	+91 (124) 4399500
Japan	+81 (43) 213-2191
Korea	+82 (51) 636-7080
The Netherlands	+31 (23) 5661111
Poland	+48 12 295 13 00
United States	+1 (970) 482-5811

Technical Assistance

If you need to contact technical assistance, you will need to provide the following information. Please write it down here before contacting the Engine OEM, the Packager, a Woodward Business Partner, or the Woodward factory:

General

Your Name _____

Site Location _____

Phone Number _____

Fax Number _____

Prime Mover Information

Manufacturer _____

Engine Model Number _____

Number of Cylinders _____

Type of Fuel (gas, gaseous, diesel, dual-fuel, etc.) _____

Power _____

Output Rating _____

Application (power generation, marine, etc.) _____

Control/Governor Information

Control/Governor #1

Woodward Part Number & Rev. Letter _____

Control Description or Governor Type _____

Serial Number _____

Control/Governor #2

Woodward Part Number & Rev. Letter _____

Control Description or Governor Type _____

Serial Number _____

Control/Governor #3

Woodward Part Number & Rev. Letter _____

Control Description or Governor Type _____

Serial Number _____

Symptoms

Description _____

If you have an electronic or programmable control, please have the adjustment setting positions or the menu settings written down and with you at the time of the call.

Appendix A.

Menu Summary

Initial Prestart Settings

These tables are provided for the convenience of the ProAct user. Each number should be recorded as it is programmed with the Hand Held Programmer. Any changes should be noted so the adjustment can be referenced from its original setting.

Menu 1—Dynamics Settings

Table A-1. Menu 1—Dynamics Settings

Menu Item	Default Setting	Gas Engine Prestart Setting	Diesel Engine Prestart Setting	Actual Setting
Gain A	0.25	0.025	0.050	
Gain A break point	0 %	100 %	100 %	
Gain B	0.25	0.025	0.050	
Gain B break point	30 %	100 %	100 %	
Gain C	0.25	0.025	0.050	
Gain C break point	60 %	100 %	100 %	
Gain D	0.25	0.025	0.050	
Gain D break point	100 %	100 %	100 %	
Stability	0.25 sec.	1.0 sec.	1.0 sec.	
Compensation	0.10 sec.	0.15 sec.	0.15 sec.	
Gain Ratio	1.0	1.0	1.0	
Gain Window	60 rpm	60 rpm	60 rpm	

Menu 2—Alternate Dynamics Settings

Table A-2. Menu 2 —Alternate Dynamics Settings

Menu Item	Default Setting	Gas Engine Prestart Setting	Diesel Engine Prestart Setting	Actual Setting
Alt Gain A	0.10	0.025	0.050	
Alt Gain A break	0 %	100 %	100 %	
Alt Gain B	0.10	0.025	0.050	
Alt Gain B break	30 %	100 %	100 %	
Alt Gain C	0.10	0.025	0.050	
Alt Gain C break	60 %	100 %	100 %	
Alt Gain D	0.10	0.025	0.050	
Alt Gain D break	100 %	100 %	100 %	
Alt Stability	1.0 sec.	1.0 sec.	1.0 sec.	
Alt Compensation	0.20 sec.	0.15 sec.	0.15 sec.	
Alt Gain Ratio	1.0	1.0	1.0	
Alt Gain Window	60 rpm	60 rpm	60 rpm	

Menu 3—Speed Reference Settings

Table A-3. Menu 3—Speed Reference Settings

Menu Item	Default Setting	Actual Setting
Rated Speed	1800 rpm	
Idle Speed	1200 rpm	
Raise Limit	1890 rpm	
Lower Limit	1200 rpm	
Accel Time	8 sec	
Decel Time	8 sec	
Raise Rate	2500 rpm/min	
Lower Rate	2500 rpm/min	
Droop	5 %	
Idle Droop	0 %	
Idle Droop break point	0 %	
Fast Start to Rated	TRUE	
Speed Switch A On	600 rpm	
Speed Switch A Off	540 rpm	
Speed Switch B On	1200 rpm	
Speed Switch B Off	1140 rpm	
Speed Switch C On	2000 rpm	
Speed Switch C Off	1900 rpm	
Remote Speed Setpoint	4 mA	
Remote Speed Setpoint (V)	0.5 V	
Remote Speed Setpoint	1710 rpm	
Remote Speed Setpoint	20 mA	
Remote Speed Setpoint (V)	4.5 V	
Remote Speed Setpoint	1890 rpm	
Fuel Rack Limiter (mA)	4 mA	
Fuel Rack Limiter (V)	0.5 V	
Fuel Rack Limiter (%)	0 %	
Fuel Rack Limiter (mA)	20 mA	
Fuel Rack Limiter (V)	4.5 V	
Fuel Rack Limiter (%)	100 %	
Boost Pressure (mA)	4 mA	
Boost Pressure (V)	0.5 V	
Boost Pressure (bar)	0 bar	
Boost Pressure (mA)	20 mA	
Boost Pressure (V)	4.5 V	
Boost Pressure (bar)	6 bar	

Menu 4—Limiter Settings

Table A-4. Menu 4—Limiter Settings

Menu Item	Default Setting	Actual Setting
Start Fueling	1	
Start Ramp Rate	1 %/s	
Start Ramp 1-2 Rate	100 %/s	
Start Ramp 2-3 Rate	100 %/s	
Start Fuel Limit 1	20 %	
Start Fuel Limit 2	40 %	
Start Fuel Limit 3	40 %	
Start Speed break point 1	400 rpm	
Start Speed break point 1	400 rpm	
Start Speed	400 rpm	
Stop Speed	300 or 0 rpm	
Max Fuel Limit	100 %	
Transient Limit	0 %	
Transient Time	0 sec.	
Min Torque Limit	40 %	
Torque Limit break point	1500 rpm	
Torque Limit at break point	70 %	
Max Torque Limit	90 %	
Fuel Rack break point 1	10 %	
Fuel Rack Limit 1	100 %	
Fuel Rack break point 2	20 %	
Fuel Rack Limit 2	100 %	
Fuel Rack break point 3	30 %	
Fuel Rack Limit 3	100 %	
Fuel Rack break point 4	40 %	
Fuel Rack Limit 4	100 %	
Fuel Rack break point 5	50 %	
Fuel Rack Limit 5	100 %	
Boost 1	1 bar	
Boost Limit 1	100 %	
Boost 2	2 bar	
Boost Limit 2	100 %	
Boost 3	5 bar	
Boost Limit 3	100 %	

Menu 6a—Configuration Set Points

Table A-5. Menu 6a—Configuration Set Points

Menu Item	Default Setting	Actual Setting
Failsafe Function	Enabled	
Dynamics Map	Linear	
Number of Gear Teeth	60	
Speed Filter Type	3	
#Speed Samples	7 or 4	
Function	1 or 2	
Remote Speed Setpoint	4 mA	
Remote Speed Setpoint (V)	0.5 V	
Remote Speed Setpoint	1710 rpm	
Remote Speed Setpoint	20 mA	
Remote Speed Setpoint (V)	4.5 V	
Remote Speed Setpoint	1890 rpm	
Fuel Rack Limiter (mA)	4 mA	
Fuel Rack Limiter (V)	0.5 V	
Fuel Rack Limiter (%)	0 %	
Fuel Rack Limiter (mA)	20 mA	
Fuel Rack Limiter (V)	4.5 V	
Fuel Rack Limiter (%)	100 %	
Boost Pressure (mA)	4 mA	
Boost Pressure (V)	0.5 V	
Boost Pressure (bar)	0 bar	
Boost Pressure (mA)	20 mA	
Boost Pressure (V)	4.5 V	
Boost Pressure (bar)	6 bar	
Analog Input Gain	1.0	
Analog Input Offset	0.0 mA or V	
Range limit High (mA)	20.5 mA	
Range limit Low (mA)	2.0 mA	
Range limit High (V)	4.8 V	
Range limit Low (V)	0.2 V	
Out of range alarm High	TRUE	
Out of range alarm Low	TRUE	
AUX Input Gain	1.0	
AUX Input Offset	0.0 V	
AUX Gain	1.0	

Menu 6b—Configuration Set Points

Table A-6. Menu 6b—Configuration Set Points

Menu Item	Default Setting	Actual Setting
Min	0.7 V	
Max	4.7 V	
Friction	0.1 A	
Inertia	0	
Break Point 1 – X	10 %	
Break Point 1 – Y	10 %	
Break Point 2 – X	90 %	
Break Point 2 – Y	90 %	

Be sure to save any changed set points to the controller and to a .WSET file before removing power from the control.

Appendix B.

Actuator Calibration

The actuator and control can be calibrated to minimize the variation in gain and actuator position while mimicking the legacy ProAct Digital Speed Control behavior. The actuator calibration is specific to the individual control and actuator pair. A replacement of either component will require a recalibration.

Actuator Calibration Procedure

The actuator must be disconnected from any linkage to allow for full actuator travel. Next, follow the [Automatic Calibration](#) procedure detailed in [Menu 6b: Configuration / Actuator Test](#). Once the calibration has been successfully completed, the Actuator Position Map must be configured to the following values:

Actuator Position Mapping	
BP 1 - X	6.8 %
BP 1 - Y	0.0 %
BP 2 - X	90.3 %
BP 2 - Y	100.0 %

Lastly, save the settings to the control.



WARNING

Modifying the Actuator Position Mapping will change the system performance. Do not use unless there's a valid reason for changing the actuator position mapping default settings.

Appendix C.

Migrate from Old to New (RoHS) ProAct Digital Speed Control

If familiar with the old ProAct Digital Speed Control, this chapter may help you transition quickly to the new RoHS ProAct Digital Speed Control.

1. Prepare a list of all parameter settings found on the old ProAct driver, using the Handheld controller. Parameter menu's 1, 2, 3, 4 and Configuration menu 6.
2. Install CAN communication interface tool and Toolkit service tool per [Chapter 4. Operation and Adjustment.](#)
3. Enter all parameter settings per Toolkit service tool, [Chapter 5. Service Tool Pages.](#)
4. **NEW:** Set up the Inertia and Friction parameters per [Chapter 5. Service Tool Pages and Inertia Test & Friction Test.](#)
5. Make sure there are no diagnostic alarms per [Chapter 5. Service Tool Pages Menu 0: Diagnostics.](#)
6. Save settings to ProAct driver, and save settings to a file for future reference per [Appendix D. Toolkit Settings Management.](#)


Appendix D.

Toolkit Settings Management

The following content describes the basic procedures and helpful hints for settings management.

To save any parameter setting changes, press the “Save Values” button, or select “Save Values” under the menu “Device.”

When cycling power on the ProAct Digital Speed Control, unsaved settings will be lost.



Downloading Settings from Device (ProAct Digital Speed Control → PC)



WARNING

Before attempting to download settings from the device, ensure the engine is in a stopped and safe operational state.

Step 1: Invoke Settings Reader

Invoke the settings reader wizard in ToolKit by going to the Settings menu item and clicking **Save Settings from Device to File**.




Figure D-1. Read Settings from Device Wizard

Step 2: Create Settings File

The first dialog requests for a settings filename (*.wset) to be saved. Set the desired ProAct Digital Speed Control settings filename and file-path.

IMPORTANT

It's highly suggested to use a standard filename nomenclature and/or folder structure in addition to maintaining relevant system notes when saving settings.



Figure D-2. Save Settings File Selection Dialog

Step 3: Establish Device Connection

If a connection to the device already exists, ToolKit will confirm and utilize the active connection to save the settings; otherwise it will provide Network Connection/Selects prompts as illustrated in Figures E-13 and E-14.




Figure D-3. Save Settings Network Selection Dialog





Figure D-4. Save Settings Device Selection Dialog

Step 4: Security Login

If not logged in to the control yet, there will be security login popup window.



Only settings you have access to at your login level will be downloaded from the control.

Step 5: Save Operation

After successfully logging in (if required), the settings save operation will commence and settings values will be uploaded from the control **into memory** (not written to file at this point). If the upload process completes successfully an optional notes dialog will be shown that allows for textual information to be attached to the settings file. After entering any desired notes, clicking *Next* will finalize the operation and write the settings file to the disk and the user will be prompted with a success dialog that indicates the process completed successfully and the file was saved to disk. If an error occurred, an error prompt will be posted instead with more information.




Figure D-5. Save Settings Progress Dialog




Figure D-6. Save Settings Attached Notes Dialog




Figure D-7. Save Settings Completion Dialog (Success)

IMPORTANT

If the successful settings saved dialog is not presented at the end of the settings operation, the settings file was NOT written to the disk, even if the download progress appeared to complete.

Uploading Settings to Device (PC → ProAct Digital Speed Control)

WARNING

Before attempting to upload settings to the device, ensure the engine is in a stopped and safe operational state.

Upload Settings

IO-Lock will be enforced when uploading settings files.

IMPORTANT

Before uploading a settings file to the device, ensure the existing settings currently in the device do not need to be saved (backup) prior to loading a new settings file. Existing settings in the device are unrecoverable after loading a settings file, unless previously saved.

Step 1: Invoke Settings Loader

Invoke the settings loader wizard in ToolKit by going to the Settings menu item and clicking Load Settings File to Device.




Figure D-8. Load Settings File to Device Wizard

Step 2: Select Settings File

The first dialog requests for the respective settings file (*.wset) to be loaded. Select the desired ProAct Digital Speed Control settings file.

NOTICE

Only load settings files that are associated with the ProAct Digital Speed Control software. Loading settings files from other applications can corrupt or render the software operationally unsafe.




Figure D-9. Load Settings File Selection Dialog

Step 3: Establish Device Connection

If a connection to the device already exists, ToolKit will confirm and utilize the active connection to load the settings; otherwise it will provide a Network Connection/Selects prompts as illustrated in Figures E-3 and E-4.




Figure D-10. Load Settings Network Selection Dialog





Figure D-11. Load Settings Device Selection Dialog

Step 4: Security Login

If not logged in to the control yet, there will be security login popup window.



Only settings you have access to at your login level will be uploaded to the control.

Step 5: Resolve Application Differences/Settings Conversion

If settings differences exist between the selected settings file and the current ProAct Digital Speed Control software in the device, ToolKit will provide a Settings Difference dialog that indicates the software version the settings file is associated with and if differences exist in the device software.

It's important to resolve any differences in settings or minimally confirm that any differences are not relevant before proceeding with the setting load operation.




Figure D-12. Load Settings Difference Warning Dialog




Figure D-13. Load Settings Difference Resolution Dialog

Step 6: Acknowledge Safety Warning

After settings resolution is complete and/or confirmed ToolKit will provide a prompt indicating that IOLock will be requested prior to the settings load. Carefully read the warning and ensure the system is in a stopped and safe operational state before proceeding. After accepting the safety warning, the settings load will begin.



Figure D-14. Load Settings Acknowledgement Dialog




Figure D-15. Load Settings Progress Dialog

Step 7: Settings Load Complete

After settings loading has finalized ToolKit will prompt with automatically execute a save and reset operation followed by a completion dialog indicating success or failure. If the settings operation did not complete successfully, reference the ToolKit diagnostic log for more detailed information on the cause of failure.



Figure D-16. Load Settings Completion Dialog (Success)

Technical Specifications

Input Voltage Rating: 10V-32VDC
 Input Current Rating: Steady State (@24VDC): 0.5 A (Model I), 1.7 A (Model II)
 Transient (@24VDC) 1.8 A (Model I), 6.7 A (Model II):

Operating Temperature –40 to +70 °C (–40 to +158 °F)
 Storage Temperature –55 to +105 °C (–67 to +221 °F)

Mechanical Vibration Validated to US MIL-STD 202F, Method 214A, Test Condition B
 0.04 G²/Hz, 10-2,000 Hz, 8.2 Grms, 1.5 hr/axis
 Mechanical Shock Validated to US MIL-STD-810F, Method 516.5, Procedure I
 40 G Peak, 11ms duration saw-tooth pulse

EMI, EMC Emissions:

EN 61000-6-4:2007 A1:2011 on DC Powered Device

Power Line Conducted Emissions AC power limit 150 kHz to 30 MHz
 Enclosure and Cables Radiated Emissions Limits 30 MHz to 6 GHz
 (3-6 GHz extrapolated from noise drop off below 1 GHz)

IACS UR E10 Rev 7 General Power Distribution Zone on DC

Powered Device Power Line Conducted Emissions Limit 10 kHz to 30 MHz

Enclosure and Cables Radiated Emissions Limits 150 kHz to 6 GHz
 (3-6 GHz extrapolated from noise drop off below 1 GHz)

EMC Immunity: **EN 61000-6-2:2005 & IACS UR E10 Rev 7 General Power Distribution Zone on DC Powered Devices**

Electrostatic Discharge (ESD) IEC61000-4-2

Radiated Immunity (RI) IEC 61000-4-3

80-4200 MHz 10VRMS/m + 1 kHz 80% depth AM

4.0-6.0 GHz 3VRMS/m + 1 kHz 80% depth AM (Deviation from IACS UR E10 Rev 7)

Electrical Fast Transients (EFT) IEC 61000-4-4 Surge IEC 61000-4-5

On Power & IO from power:

IO not connected to power is exempted because <30m in length.

Conducted RF (CRF) IEC 61000-4-6:

150 kHz to 80 MHz 10 VRMS + 1 kHz 80% depth AM

Conducted Low Frequency Immunity (CLFI):

Power Port 50 Hz to 12 kHz at 3.6VRMS or 2W on DC Power leads

ISO 16750-2:2012 & ISO 7637-2:2004+A1:

2008 Load Dump to 177V_{PK}

Humidity: 95% ±5% at 60 °C for 6 hrs non-condensing

Ingress Protection: IP2x per IEC 60529, 12mm, 10N

Revision History

Changes in Revision A—

- Clarified battery wire and actuator cable length descriptions and replaced incorrect values (Chapter 3)
- Updated Service Tool screenshots to reflect the change to integer values in the gain tables (Chapter 5)
- Updated EMI, EMC Emissions and EMC Immunity (Technical Specifications)
- Added several new captions under figures in multiple locations

Declarations

EU DECLARATION OF CONFORMITY

EU DoC No.: 00189-04-CE-02-01
Manufacturer's Name: WOODWARD INC.
Manufacturer's Contact Address: 1041 Woodward Way
 Fort Collins, CO 80524 USA
Model Name(s)/Number(s): ProAct Speed Control (RoHS)
The object of the declaration described above is in conformity with the following relevant Union harmonization legislation: Directive 2014/30/EU of the European Parliament and of the Council of 26 February 2014 on the harmonization of the laws of the Member States relating to electromagnetic compatibility (EMC)
 Directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment
 Exemption in use: 7(c)-I
Applicable Standards: EN61000-6-2:2005 EMC Part 6-2: Generic Standards - Immunity for Industrial Environments
 EN61000-6-4:2007/A1:2011 EMC Part 6-4: Generic Standards - Emissions for Industrial Environments

This declaration of conformity is issued under the sole responsibility of the manufacturer
 We, the undersigned, hereby declare that the equipment specified above conforms to the above Directive(s).

MANUFACTURER

Signature



Full Name

Mike Row

Position

Engineering Supervisor

Place

Woodward, Fort Collins, CO, USA

Date

25-July-2019

We appreciate your comments about the content of our publications.

Send comments to: icinfo@woodward.com

Please reference publication **35131**.



PO Box 1519, Fort Collins CO 80522-1519, USA
1041 Woodward Way, Fort Collins CO 80524, USA
Phone +1 (970) 482-5811

Email and Website—www.woodward.com

Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world. Complete address / phone / fax / email information for all locations is available on our website.