



Manual 37983 (Revision A, 05/2024) IKD-IN-16 external digital inputs

See Technical Manual 37972 for complete installation, operation, maintenance, and certification information. Use QR code or the following link to download product documentation: <http://wwdmanuals.com/ikd-in-16>

IMPORTANT



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DEFINITIONS

- **DANGER**—Indicates a hazardous situation which, if not avoided, will result in death or serious injury.
- **WARNING**—Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
- **CAUTION**—Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
- **NOTICE**—Indicates a hazard that could result in property damage only (including damage to the control).
- **IMPORTANT**—Designates an operating tip or maintenance suggestion.



WARNING

The engine, turbine, or other type of prime mover should be equipped with an overspeed shutdown device to protect against runaway or damage to the prime mover with possible personal injury, loss of life, or property damage.

The overspeed shutdown device must be totally independent of the prime mover control system. An overtemperature or overpressure shutdown device may also be needed for safety, as appropriate.



Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment. Practice all plant and safety instructions and precautions. Failure to follow instructions can cause personal injury and/or property damage.



Publications may have been revised or updated. To verify that you have the latest revision, be sure to check the *publications* page on the Woodward website:
www.woodward.com/publications

The latest version of most publications is available on the *publications* page. If your publication is not there, please contact your customer service representative to get the latest copy.



Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.


NOTICE

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

NOTICE

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual **82715**, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

Terminals IKD-IN-16



Contacting Woodward's Support Organization

For the name of your nearest Woodward Full-Service Distributor or service facility, please consult our worldwide directory published at www.woodward.com/directory.

You can also contact the Woodward Customer Service Department at one of the following Woodward facilities to obtain the address and phone number of the nearest facility at which you can obtain information and service.

Products Used In Electrical Power Systems	Products Used In Engine Systems	Products Used In Industrial Turbomachinery Systems
Facility ----- Phone Number Brazil ----- +55 (19) 3708 4800 China ----- +86 (512) 6762 6727 Germany:----- Kempen---- +49 (0) 21 52 14 51 Stuttgart - +49 (711) 78954-510 India ----- +91 (129) 4097100 Japan-----+81 (43) 213-2191 Korea-----+82 (51) 636-7080 Poland ----- +48 12 295 13 00 United States-----+1 (970) 482-5811	Facility ----- Phone Number Brazil ----- +55 (19) 3708 4800 China ----- +86 (512) 6762 6727 Germany ----- +49 (711) 78954-510 India ----- +91 (129) 4097100 Japan-----+81 (43) 213-2191 Korea-----+82 (51) 636-7080 The Netherlands--+31 (23) 5661111 United States-----+1 (970) 482-5811	Facility ----- Phone Number Brazil ----- +55 (19) 3708 4800 China ----- +86 (512) 6762 6727 India ----- +91 (129) 4097100 Japan-----+81 (43) 213-2191 Korea-----+82 (51) 636-7080 The Netherlands--+31 (23) 5661111 Poland ----- +48 12 295 13 00 United States-----+1 (970) 482-5811

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, no responsibility is assumed by Woodward unless otherwise expressly undertaken.

Copyright © Woodward 2024
All Rights Reserved



Woodward GmbH | Handwerkstrasse 29 | 70565 Stuttgart | Germany
 Telephone: +49 (0) 711 789 54-510 | Fax: +49 (0) 711 789 54-101
 E-mail: marketing_pg@woodward.com | Internet: <http://www.woodward.com>